

VOLKSWAGEN (Cont.)

All Other Models (Rear) — Toe-in is not adjustable. If toe-in is not within specifications, inspect rear suspension for wear or damage and repair or replace components as necessary.

spring plate until bubble is in center position. Adjust torsion bar one spline forward or rearward until correct specifications are obtained.

TORSION BAR ADJUSTMENT (REAR)

Type 1 — Using a suitable protractor, find deviation of vehicle from horizontal plane and note reading which will be used in setting angle of spring plate. Install spring plate on torsion bar and measure position with protractor. If not within specifications, adjust by moving torsion bar, one spline at a time, forward or backward until correct position is obtained.

Type 2 — Using a suitable protractor, check horizontal position of vehicle on one frame side member. Reading should be noted; it will be used in setting spring plate angle. Insert inner end of torsion bar in center anchor and press spring plate on outer end of torsion bar. Adjust protractor on unloaded

Torsion Bar Specifications

Application	Setting (Degrees)
Type 1	21 $\frac{1}{3}$ ± $\frac{5}{6}$
Type 2	
Kombi & Campmobile	
From Chassis 218 000 002	①21 ± $\frac{5}{6}$
From Chassis 212 2000 001	②23 ± $\frac{5}{6}$
Station Wagon	
From Chassis 218 000 002	①20 ± $\frac{5}{6}$
From Chassis 212 2000 001	②23 ± $\frac{5}{6}$

① — Man. Trans.

② — Man. Trans. and Auto. Trans.

VOLVO

ADJUSTMENT

TIRE INFLATION (COLD)

Before attempting to check or adjust wheel alignment, make sure tires are properly inflated. Refer to manufacturers specifications given in owner's manual.

CASTER

Caster cannot be adjusted. If not within specifications, check front end components for damage.

CAMBER

If camber is not within specifications, loosen nuts at strut assembly upper attachment. Use special tool 5038 (or equivalent) at strut upper attachment to adjust camber. Tighten lock nuts. Recheck camber.

TOE-IN

Place wheels in straight-ahead position and loosen lock nut and rubber dust boot outer clamp. Turn tie rods until toe is within specifications. Make sure length of tie rods does not differ more than .08" (2 mm). Measure difference between groove in tie rod and lock nut.