

Steering Columns

CHRYSLER CORP. IMPORTS FWD MODELS

Champ, Colt

DESCRIPTION

Collapsible steering system is comprised of a 2-piece (upper and lower) column shaft, joined by a collapsible (bellows type) section. The bellows section contracts axially under impact without affecting turning motion.

REMOVAL & INSTALLATION


STEERING COLUMN

Removal

1) Remove steering column cover. Pull out column switch connectors. Pull switch out toward steering wheel end.

NOTE: When removing steering column as an assembly, leave all connector clamps intact.

Fig. 1: Exploded View of Steering Column




2) Remove steering shaft upper coupling bolt. Remove bolts retaining steering column brackets to frame. Disconnect steering shaft from coupling (inside vehicle). Remove steering column assembly.

3) Remove intermediate shaft lower coupling bolt (at steering gear). Remove dust cover retaining bolts. Remove intermediate shaft (with dust cover) toward inside of vehicle.

Installation


1) Install dust cover to intermediate shaft. Make sure bearing side of cover faces steering shaft side of intermediate shaft. See Fig. 2 & 3.

Fig. 2: Determining Correct Intermediate Shaft Installation Position



2) Apply grease to bearing and dust cover. Install bearing (2-piece) into dust cover. Attach intermediate shaft lower joint to steering gear and temporarily tighten dust cover bolts. Now tighten lower joint clamp bolt.

Fig. 3: Dust Cover and Bearing Installation



3) Connect intermediate shaft upper joint to steering shaft. Attach steering column brackets to dash. Tighten clamp bolt of intermediate shaft and column bracket bolts.

4) Loosen dust cover bolts and position dust cover so no clearance exists between joint and dust cover sliding surfaces. Tighten dust cover bolts. Adjust steering wheel position if necessary.

OVERHAUL

STEERING COLUMN

Disassembly

1) Remove the 2-piece bearing from dust cover of intermediate shaft. Remove dust cover from intermediate shaft.

2) Remove snap ring from steering shaft (steering wheel end). Unlock steering wheel lock (with ignition key). Remove steering shaft from column by lightly tapping shaft with soft mallet.

3) If steering lock is to be removed, cut a slot in retaining screws with hacksaw. Use a flat blade screwdriver to remove screws. Remove steering lock. Always use new screws and bracket when replacing steering lock.

CHRYSLER CORP. IMPORTS FWD MODELS (Cont.)


4) If steering column bracket is removed, cut a slot in retaining bolt with hacksaw. Remove bolts with flat blade screwdriver. Always use new bolts when installing bracket to steering column.

Inspection

1) Check steering shaft for runout and length. Runout should be .02" (.5 mm) or less, length should be 23.06" (585.8 mm). Check for a worn or damaged bearing.

2) On intermediate shaft, check for play, noise or rough rotation in joints. Also check for a damaged dust cover. Replace components as required.

Fig. 4: Check Steering Shaft for Length and Damage



Reassembly

1) Install steering shaft in steering column and install snap ring. Install and tighten column tube bracket bolt until bolt head snaps off.

2) Fill bearing with grease and install in end of steering column. Make sure bearing is fully seated. Align steering lock with column boss. Make sure that steering lock is operational (by using ignition key to make lock function) before tightening lock retaining screw.

NOTE: Steering lock retaining screws are special one way design.

TIGHTENING SPECIFICATIONS

| Application | Ft. Lbs. (N.m) |
|--|----------------|
| Clamp Joint Bolts | |
| Upper and Lower | 11-14 (15-19) |
| Steering Wheel Nut | 25-32 (34-44) |
| Column Support Bracket Bolts | 7 (10) |
| Column Tube-to-Bracket Bolt | |
| Torque Required to Snap Head Off | 9 (12.0) |