

BENDIX SINGLE DIAPHRAGM

Chevrolet
Ford
GMC
Jeep

DESCRIPTION

Vacuum suspended, self-contained, vacuum-hydraulic unit which utilizes engine manifold vacuum and atmospheric pressure to provide its power. Vacuum power unit contains power piston assembly, which houses control valve, reaction mechanism, and return spring. Control valve consists of air valve, floating control valve assembly, and push rod. Reaction mechanism consists of reaction plate and levers. A vacuum check valve is mounted in front housing for connection to vacuum source.

REMOVAL & INSTALLATION

NOTE — Power brake unit can be removed without removing master cylinder or disconnecting hydraulic lines on Chevrolet, Ford and GMC models. Master cylinder must be removed on Dodge, Jeep and Plymouth models.

Removal — Disconnect vacuum line from power unit. Remove hydraulic lines from master cylinder. Disconnect pedal linkage and remove bolts holding power unit to firewall. Remove power unit from vehicle.

Installation — Reverse removal procedure, noting the following: Before attaching master cylinder, check push rod for proper length. See *Push Rod Adjustment*. If hydraulic lines were disconnected, bleed system before moving vehicle.

OVERHAUL

NOTE — Only Chevrolet and GMC recommend overhaul of power brake unit.

Disassembly — 1) Scribe mark housings for reassembly. Remove master cylinder from power unit and set aside. Remove front housing seal and piston rod. Attach assembly to suitable holding fixture (J-22805). **CAUTION** — Ensure proper tool alignment to avoid damage to check valve in front housing. Loosen lock nut and remove push rod clevis and lock nut, if

equipped. Remove dust boot retainer, dust boot, and silencer from diaphragm plate extension. Partially straighten four deepest tabs on rear housing. Place suitable wrench (J-9504) over studs on rear housing and attach with nuts and washers. Press down on wrench and rotate rear housing clockwise to separate. **CAUTION** — Housings are under internal spring tension. Remove wrench from housing.

2) Remove air filter from diaphragm plate extension. Remove diaphragm from groove in diaphragm plate. **CAUTION** — Protect and handle diaphragm carefully. Hold diaphragm plate so that push rod is in horizontal position. Depress rod slightly and rotate piston until air valve lock falls from diaphragm plate hub. Remove reaction disc from diaphragm plate bore (use push rod, or suitable tool, to push disc from seat). **CAUTION** — Do not chip diaphragm plate.

3) Remove rear shell bearing seal with punch or screwdriver. **CAUTION** — Remove seal only if new one is available. Do not reuse seal if it has been removed. Remove vacuum check valve and grommet.

Cleaning & Inspection — Use only denatured alcohol to clean all metal, plastic, and rubber parts. Blow out all passages, orifices, and valve holes with clean, dry air, and air dry all parts. Slight rust on inside of housing can be polished with crocus cloth or fine emery cloth. There should be no cuts, nicks, or distortion of any rubber part. If in doubt about condition of any part, replace part.

Reassembly — 1) Install vacuum check valve grommet (beveled edge on inside), dip check valve in clean, denatured alcohol and install. Install suitable holding fixture (J-22805) on front housing. Install new rear housing seal in center hole, using suitable tool (J-22677) to seat seal in recess (tool bottoms against housing when seal is in place).

2) Assemble diaphragm plate assembly as follows: Lubricate outer diameter of diaphragm plate and extension, valve, and plunger bearing surfaces, and outer edge of valve poppet. Install valve and rod into diaphragm plate extension. Depress push rod slightly and install air valve lock (lock must index and retain air valve). Install rolling diaphragm in diaphragm plate hub groove. Lubricate reaction disc and install disc (use master cylinder push rod to seat disc in diaphragm plate bore). If disc is not fully seated, push rod height will be gauged incorrectly during adjustment procedure.




Fig. 1 Exploded View of Bendix Single Diaphragm Assembly

BENDIX SINGLE DIAPHRAGM (Cont.)

3) Lubricate inside of bearing seal and diaphragm bead contact-surface of rear shell. Install diaphragm plate assembly in rear housing. Place air filter element over push rod and into diaphragm plate extension. Install filter retainer. With holding-fixture in place, position suitable wrench (J-9504) over studs on rear housing and position front and rear housings together. Press down on wrench and rotate counterclockwise (rear housing) to lock housings. Align scribe marks. Rebend tabs on rear housing (if tabs are cracked or broken, housing must be replaced). Remove wrench from housing. Install air silencers over push rod end. Install push rod boot and boot retainer. On clevis-type push rods, install lock nut and push rod clevis. Lightly lubricate piston rod (except rounded end). Guide rod into center bore until fully seated against reaction disc. Install front housing seal (in same manner as rear seal). Attach master cylinder.

ADJUSTMENT

PUSH ROD

Chevrolet & GMC — 1) Place power unit in a vise with front housing up. Remove front seal to ensure all vacuum is released from unit. Place master cylinder rod, flat end first, in piston rod retainer. Press down on rod with 40 to 50 pounds of pressure to make sure rod is seated.




Fig. 2 Checking Push Rod Height
Chevrolet and GMC Only

2) Place a suitable measuring gauge (J22647) over piston rod in such a position that it can be moved from left to right without contacting studs. The center section of gauge has two levels. The piston rod should always contact the lower level and never contact the highest level.

3) If the push rod does not contact gauge correctly, an adjustable push rod must be obtained. Adjust self locking screw on rod to obtain correct clearance with gauge. Apply silicone lubricant on the inside diameter of front housing seal and place seal in position in housing depression.

Ford Motor Co. — Check distance from outer end of booster assembly push rod to front face of booster. Use a gauge manufactured to specifications shown in illustration (see Fig. 3) Turn push rod screw in or out to obtain specified length of .980-.995".




Fig. 3 Checking Push Rod Height
Ford Motor Co. Only

Jeep — Push rod for Jeep models is non-adjustable.