

JEEP FLOATING CALIPER DISCS

Wagoneer
Cherokee
J-Series

DESCRIPTION

Floating caliper disc brake assembly uses a single piston caliper which "floats" on two pins. As brake pedal is depressed, hydraulic pressure is passed through a proportioning valve to brake caliper piston. This force is transmitted to inboard brake pad and against braking surface of rotor or disc. Pressure then moves outer caliper housing and pad inward on caliper mounting pins, thus forcing outer pad against outer braking surface of rotor. When brake is released, pressure is removed from cylinders and inherent rotor runout moves pistons back into cylinders to maintain sufficient rotor-to-pad clearance.




Fig. 1 Cutaway View of Jeep Floating Caliper

ADJUSTMENT & SERVICING

DISC PAD ADJUSTMENT

Automatic adjustment is provided by outward relocation of piston as lining wears.

BLEEDING SYSTEM

See *Hydraulic Brake Bleeding in this Section*.

REMOVAL & INSTALLATION

BRAKE PADS

Removal — 1) Drain 2/3 of brake fluid from front reservoir using bleeder screw at front outlet port. Raise and support vehicle and remove front wheels. Place "C" clamp on caliper. Solid end of clamp should contact back of caliper, and screw end should contact metal part of outboard shoes. Tighten clamp until caliper moves far enough to force piston to bottom of bore. This will back shoes off rotor surface, easing lining removal and installation.




Fig. 2 Using a "C" Clamp to Bottom Caliper Piston

2) Remove both Allen head mounting bolts and lift caliper off rotor. Rest caliper on front spring or other suitable support. Do not allow brake hose to support weight of caliper. Remove both shoe and lining assemblies (pads). Remove support spring from inboard shoe and note spring position for correct installation later. Remove sleeves from inboard ears of caliper. Remove rubber bushings from all holes in caliper ears.

Installation — To install, reverse removal procedures noting the following: Lubricate new bushings, sleeves, bushing grooves and small ends of mounting bolts with a silicone lubricant. Install rubber bushings in all caliper mounting ears. Shoe ears should rest on upper surface of caliper mounting ears and lower shoe tabs should fit into cutout in caliper.

BRAKE CALIPER

See preceding *Brake Pad* procedure. To remove caliper completely from vehicle, disconnect brake line at caliper and tape hole to prevent contamination.

DISC ROTOR

Removal — Raise vehicle and support with safety stands. Remove wheel and caliper. On models without front hubs, remove rotor hub cap, drive gear snap ring, drive gear, pressure spring and spring cup. On models with front hubs, remove screws attaching hub body to hub clutch and remove body front clutch. Remove large and small retaining rings. Remove hub clutch from axle shaft. Straighten lip of outer locknut retaining washer. Remove wheel bearing locknuts and washers. Remove rotor and wheel bearings.

Installation — 1) Lubricate bearings with EP-type water proof wheel bearing lubricant. Install bearing and new seal in rotor hub. Install rotor and inner lock nut and retaining washer.

NOTE — Bearing adjuster inner lock nut has locating peg on one side. When installed, peg must face away from bearing.

JEEP FLOATING CALIPER DISCS (Cont.)

2) Install wheel but do not tighten nuts. While rotating wheel, tighten inner locknut to 50 ft. lbs., and then back off $\frac{1}{6}$ turn. Install outer locknut and retaining washer. Tighten outer locknut to 50 ft. lbs.

NOTE — Be sure locating peg is engaged in one of the retaining washer holes before installing outer lock nut.

3) On models without front hubs, install pressure spring cup, pressure spring, drive gear and snap ring. Coat rim of chrome hub cap with Permatex No. 3 (or equivalent) and install cap in rotor hub.

CAUTION — Spring cup must be installed so recessed side of cup faces outboard bearing and flat side of cup faces pressure spring.

4) On models with front hubs, install hub clutch on axle. Install large and small hub retaining rings. Install hub body on clutch and tighten to 30 INCH Lbs.

5) Remove drive wheel and install caliper. Reinstall wheel and wheel cover if equipped.

OVERHAUL

Disassembly — 1) Remove caliper from vehicle and remove pads. If pads are to be reused, mark location in caliper. Clean caliper exterior with clean brake fluid. Drain residual fluid from caliper and place it on a clean working surface. Remove piston from caliper by applying compressed air to fluid port.

CAUTION — Use just enough pressure to ease piston out of bore. Protect piston from damage with folded cloths, do not try to catch piston with fingers, serious injury could result.

2) Pry dust boot out of bore with screwdriver. Do not scratch bore. Using a small plastic or wooden stick, pry piston seal from bore. Remove bleeder screw, sleeves and rubber bushings. Clean all parts in clean brake fluid. Blow parts dry with dry, filtered compressed air. **NOTE** — Do not clean bolts with abrasive; protective plating may be removed.

3) Examine parts for rust, corrosion, pitting, scratches, or cracks. Do not attempt to refinish piston in any way. Removal




Fig. 3 Exploded View of Floating Disc Brake Caliper Assembly

of nickel-chrome plating will lead to pitting, rusting, and eventual cocking in bore. Minor stains on piston bore can be polished with crocus cloth only. Do not use emery cloth or any other abrasive. Wash bore thoroughly with brake fluid after using crocus cloth.

Reassembly — 1) Lubricate bore and new seal with brake fluid and install seal in groove. Lubricate piston with brake fluid and install new dust boot on piston. Slide metal retainer portion of dust boot over open end of piston and push retainer toward back of piston until lip on fold seats in piston groove. Then push retainer portion of boot forward until boot is flush with rim at open end of piston and snaps into place.

2) Insert piston in bore being careful not to unseat piston seal. Push piston to bottom of bore (requires 50-100 lbs. pressure). Position dust boot retainer in counterbore at top of piston bore. Seat dust boot retainer with suitable tool (J-22904).

NOTE — Metal retainer portion of boot must be evenly seated in counterbore and fit below face of caliper. Install bleeder screw. Connect brake line to caliper using new copper gaskets. Install pads as outlined in Pad Removal and Installation. Install caliper over rotor, bleed brakes, and install wheel. Test system before moving vehicle.

ROTOR

Runout & Parallelism — 1) Surfaces must be parallel within specifications. Surfaces not parallel will cause pads to wear at an angle. Runout must not exceed specified amounts.

2) Other measurements to be checked are: Hub-to-Rotor Squareness which is measured from center line of bearing cups to rotor. Surface Flatness or Taper which is the difference in thickness between outer and inner edge of rotor. Thickness Variation which is variation in thickness on any single radius.

BRAKE SPECIFICATIONS

Application	Dimension
Rotor Diameter	
All (Exc. J-20).....	12.0"
J-20.....	12.5"
Rotor Thickness	
New.....	①
Minimum.....	1.215"
Parallelism.....	.003"
Hub-to-Bore Runout (Limit).....	.010"
Rotor Lateral Runout (Limit).....	.005"
Thickness Variation.....	.001"
Pad Thickness	
New.....	①
Minimum.....	②

① — Specification not available.

② — Specification not available. A wear sensor is fitted on pads which makes noise when pad wear allows it to come in contact with rotor.

TIGHTENING SPECIFICATIONS

Application	Torque
Bleeder Screw.....	40-140 INCH Lbs.
Brake Line-to-Caliper.....	160 INCH Lbs.
Caliper Mounting Bolts.....	30-40 ft.lbs.