

Wheel Alignment

CHRYSLER CORP. (Cont.)

CASTER & CAMBER (EXCEPT OMNI & HORIZON)

1) Check caster and camber readings and compare to specifications. Clean and loosen slightly the caster/camber pivot bar nuts, so that upper control arm may be repositioned in slots. See Fig. 9.

2) Place claw of adjusting tool C-4387 on pivot bar with pin of tool in tower or bracket holes. To adjust, move pivot bar in or out.

3) To set camber, move both ends of upper control rod in or out equal distances. To set caster, move one end of bar only.

4) To maintain camber, while adjusting caster, move ends of pivot bar the same distance, but in opposite directions (one end in, the other out).

5) Tighten pivot bar nuts to 150 ft. lbs. on Chrysler and 175 ft. lbs. on other models.

CASTER & CAMBER (OMNI & HORIZON)

NOTE — Caster is non-adjustable. No specifications were available from manufacturer at time of publication. Do not modify components by heating or bending.

To adjust camber, loosen cam and through bolts on each side. See Fig. 10. Rotate upper cam bolt to move top of wheel in or out to specified camber. Tighten bolts to 85 ft. lbs.




Fig. 10 Adjusting Camber & Toe (Front & Rear)
(Omni & Horizon)

FORD MOTOR CO.

ALL MODELS

TIRE INFLATION (COLD)

Inflate tires to manufacturers specifications. Specifications are found on glove box door, rear edge of drivers door, or door pillar on drivers side.

FAIRMONT & ZEPHYR

On Fairmont and Zephyr models the caster and camber are set at the factory and cannot be adjusted. Only toe is adjustable.

PINTO, MUSTANG II, & BOBCAT

CASTER & CAMBER

Install suitable tool (T74P-3000), one at each end of upper arm inner shaft and turn tool bolts in until bolt ends contact body metal. Loosen upper arm inner shaft-to-body attaching bolts. Inner shaft will move inboard until stopped by tool bolt ends. Turn tool bolts in or out until caster and camber are within specifications. See Fig. 11. Tightening tool bolts forces arm outward, loosening permits arm and inner shaft to move in-

board. Tighten upper arm inner shaft-to-body attaching nuts to 95-120 ft. lbs. Then loosen tool bolts and remove tools.




Fig. 11 Caster & Camber Adjustment
Pinto, Mustang II, & Bobcat

FORD MOTOR CO. (Cont.)

VERSAILLES, GRANADA, & MONARCH

CASTER

Caster is controlled by front suspension strut. To obtain positive caster, loosen strut rear nut and tighten front nut against bushing. To obtain negative caster, loosen strut front nut and tighten rear nut against bushing.

CAMBER

Camber is controlled by eccentric cam located at lower arm attachment to side rail. Loosen camber adjustment bolt nut at rear of body bracket. Spread body bracket at adjustment bolt area just enough to permit lateral travel of arm when adjustment bolt is turned. Rotate bolt and eccentric clockwise from high position to increase camber or counterclockwise to decrease camber. After adjustment, tighten lower arm eccentric bolt nut and strut front nut.

ALL OTHER MODELS

CASTER

1) Install alignment tools (T69P-3000-A) into frame holes and tighten tools fingertight against upper arm inner shaft. Then, using a wrench, tighten an additional turn. Loosen bolts attaching upper arm inner shaft to frame. Firmly tap bolt heads to loosen lower assemblies. See Fig. 12.

2) To obtain positive caster, tighten tool front hook nut or loosen rear hook nut. To decrease caster, tighten rear hook nut or loosen front hook nut. Check camber to see that it did not change. Tighten upper arm inner shaft attaching bolts to 120-140 ft. lbs.




Fig. 12 Caster & Camber Adjustment
All Other Models

CAMBER

1) To adjust camber angle, loosen inner shaft attaching bolts and tighten or loosen tool hook nuts to move inner shaft inboard or outboard as necessary. Using suitable tool (T69P-3000-A), camber can be checked without tightening inner shaft attaching bolts.

2) Move shaft inboard equally at both bolts to change camber in negative direction. Move shaft outboard equally at both bolts to change camber in positive direction.

GENERAL MOTORS

BUICK

TIRE INFLATION (COLD)

Before checking wheel alignment, ensure that tires are inflated to manufacturers specifications, found on tire placard on inside of glove box door or on drivers door jam.

RIDING HEIGHT

With car on smooth level floor, trunk empty and fuel tank full, bounce both front and rear of car several times and let car assume normal position. Measure the dimensions as shown in Fig. 13. If riding height is not within specified limits, install shims between upper end of spring and frame.




Fig. 13 Riding Height Measuring Points