

Seat Belt Starter Interlock Systems


1974 GENERAL MOTORS SEAT BELT-STARTER INTERLOCK SYSTEM

DESCRIPTION

Starter interlock is designed to prevent engine start when front seat belts, except center belt, are not fastened after occupying seat. A seat belt warning light and buzzer are also activated if belts are unfastened when vehicle is in forward drive mode. Components consist of three seat sensors and buckle switches, logic module, warning buzzer and light, interlock relay, override switch and related wiring. Logic modules are either mechanical relay or electronic design. Seat sensors are either beam type located under seat cushion or pressure sensitive type under trim cover.


OPERATION

Interlock logic module is always connected to battery power. When a seat sensor is actuated, module senses this and sends power to interlock relay coil opening the normally closed contacts. This opens circuit to starter solenoid preventing engine start. When seat belts are fastened, the module senses a circuit change and power to interlock relay is stopped and contacts close permitting engine start. Logic module prevents interlock relay from closing if buckle is activated before seat sensor.



4BU13

STARTER INTERLOCK COMPONENT LOCATIONS (TYPICAL)



4BU05

APOLLO STARTER INTERLOCK WIRING

4-90 Seat Belt Starter Interlock Systems

1974 GENERAL MOTORS SEAT BELT-STARTER INTERLOCK SYSTEM (Cont.)

2) Disconnect override relay, turn ignition to "START" while sitting with belt unfastened; if starter fails to crank, replace override relay. If starter cranks, turn ignition off and ground DK. GREEN wire, then turn ignition to "START". If starter cranks, go to step 3); if not, go to Seat and Belt Testing.

3) With ignition "ON", connect test light to ground and PINK wire (Oldsmobile 88, 98 & Toronado, GREEN-DOUBLE WHITE STRIPE) on interlock relay near fuse block. Test light should be on; if not, repair open from interlock relay to ignition switch. Test continuity of DK. GREEN wire from interlock relay to 3-wire connector and repair if necessary. If starter does not crank with belt unfastened, system is satisfactory. If starter still cranks with belt unfastened, and PINK and DK. GREEN wires are satisfactory, replace interlock relay.


3) Turn ignition "OFF", move seat forward and disconnect seat belt wire connector at position where there was no click. Connect a self-powered test light to both terminals in belt side of wire connector and connect belt buckle. If light fails; on vehicles with electronic module, or light comes on; vehicles with mechanical relay module, replace defective seat belt and stop test if problem is corrected.

4) Reconnect seat belt wire connector, remove module and disconnect both multiple connectors. Connect a self-powered test light to the two wires in 10-pin connector for seat belt in question. If test light fails, repair open circuit in one or both wires leading from belt connector to 10-pin connector. If light comes on, connect tester to ground and BLACK wire in 10-pin connector. If light comes on, replace module; if light fails, repair ground connection BLACK wire to body. **CAUTION** – To prevent replacement module failure, be certain interlock relay or reminder buzzer is not shorted internally.

5) Disconnect seat sensor connector at seat position where two clicks cannot be heard. Connect self-powered test light to terminals in sensor side of connector. Press on seat position and replace seat sensor if light fails. If light comes on, go to step 6).

6) Reconnect seat sensor. Remove module from under seat and disconnect both module connectors. Connect self-powered test light to BLACK wire in 4-wire connector and to wire leading to seat sensor in question. Press and release seat cushion. If test light comes on, replace module; if not, repair open circuit in one or both wires from 4-wire connector to seat sensor. Stop tests if problem is corrected.

7) Disconnect 3-wire connector near fuse block. Remove module from under seat and disconnect module connectors. Connect self-powered test light to DK. GREEN wire in 10-pin connector and ground. Light on, repair short in wire between connectors. Light off, go to step 8).




4CA03
CADILLAC STARTER INTERLOCK WIRING

SEAT & BELT SYSTEM TESTING

NOTE – Engine cranks when 3-wire connector near fuse block is disconnected or when turning ignition to "START" with seat belts unfastened and no one sitting on seats.

1) With ignition "ON", belts unfastened, 3-wire connector connected, press and release driver and passenger seat cushion. Interlock relay should click twice at each seat position. With two clicks at both positions, go to step 2); two clicks at one position only, go to step 5); and only one click or no click at both positions, go to step 7).

2) Sit on seat, hold seat belt release button in and connect belt. Relay should click when belt is fastened. **NOTE** – Holding release button prevents snap lock from making more noise than relay. Perform same test on opposite front seat position to determine which belt does not click relay when fastened. If relay clicks for one belt only, go to step 3). If relay does not click when belts are fastened, remove module from under seat and disconnect multiple connectors. Connect a self-powered test light to ground and BLACK wire in 10-pin connector. If light comes on, replace module; if not, repair ground wire.



4CH06
CHEVROLET STARTER INTERLOCK WIRING
(AUTOMATIC TRANSMISSION)

1974 GENERAL MOTORS SEAT BELT – STARTER INTERLOCK SYSTEM

buzzer and light go off after reconnecting 3-wire connector, replace module. **NOTE** – With Pontiac models, test center seat switch before replacing module as follows: Reconnect 10-wire connector and disconnect center seat switch. If buzzer and light go off, replace seat switch; if not, replace module.

STARTER DOES NOT CRANK & SEAT BELT LIGHT & BUZZER DO NOT OPERATE (CADILLAC ONLY)

Disconnect interlock diode connection near fuse block. Using a self-powered test light, test diode continuity in both directions. If tester lights both ways, replaced diode. If diode lights only in one way, check BLACK wire leading from diode harness connector for an open circuit.


REMOVAL & INSTALLATION

LOGIC MODULE

NOTE – The relay logic module is not interchangeable with the two variations of electronic modules used. Both electronic modules use slightly different wiring harnesses designed to bypass the operation of center seat sensor. This allows engine start without center occupant buckling seat belt. One harness by-passes module to center seat sensor with a jumper wire and the other harness by-pass is through module. The module with built-in by-pass can be used with either harness. Module without built-in by-pass can only be used with harness incorporating jumper wire (see illustration).

Logic Module Location (All Models) – Vega, Camaro and Nova module is under front seat, driver's side. Corvette module is near left rear quarter panel inside vehicle under carpet. For all other models, module is under front seat, passenger side.

Removal & Installation – Raise power operated seat to full up limit, or on other seats if necessary, detach seat at floor pan and tilt seat rearward. Disconnect module from retainer with a small screwdriver from under front seat bottom frame. Remove deflector from 4-wire connector. Disconnect 4-wire and 10-wire connectors from module using suitable tool (J-24388 or BT-7402-A). To install module, reverse removal procedure. **CAUTION** – To prevent replacement module failure, be certain interlock relay or reminder buzzer are not shorted internally.



4CH01

G.M. STARTER INTERLOCK SEAT SYSTEM COMPONENTS (TYPICAL)

SEAT SENSORS

Beam Type (All Bucket Seats) – Disconnect sensor feed wire connector under passenger seat. Disconnect seat assembly from floor pan or seat adjusters and tilt seat rearward. Disconnect sensor feed wire clip from seat frame and both ends of sensor from spring wire unit. To install sensor, reverse removal procedure making certain sensor is attached to top and at offset of third wire on spring and wire units.

Pressure Sensitive Type (All Full Width, 40-40, 60-40, and 50-50 Seats) – Where present, remove seat cushion side panel and control switch. Remove seat adjuster-to-floor pan attaching bolts (driver's side only on Cadillac 60-40 seat) and tilt seat rearward (passenger seat only on 40-40, 60-40, and 50-50 seats). On all split seats, remove outboard adjuster from seat frame. On bench seats, remove adjuster adjacent to affected sensor. Detach trim cover from side of seat cushion sufficiently to gain access to sensor. Disconnect sensor wire at connector under seat. Carefully break cement bond securing sensor to foam pad; then pull sensor wire up through hole in foam pad and remove sensor. To install sensor, reverse removal procedure. Prior to installing a new sensor, remove adhesive protective paper from bottom surface of sensor. **NOTE** – If repositioning used sensor, apply a small amount of trim cement to cushion and bottom of sensor. Then apply a strip of waterproof body tape over sensor to secure during trim reinstallation. Do not apply tape too tightly over switch.