

305" & 350" VIN CODES L, 8 & 4 V8 ENGINES

IDENTIFICATION CODING

ENGINE IDENTIFICATION

Engines can be identified by fifth digit of the Vehicle Identification Number located on the left upper side of the instrument panel and visible from outside the windshield. An additional engine code is stamped on the front right side of the cylinder block.

Application	VIN Code
305" 2-Bbl. (LG3)	G
305" 4-Bbl. (LG4)	H
350" 4-Bbl. (LM1)	L
350" 4-Bbl. (L48)	①8
350" 4-Bbl. (L82)	①4

① — Used on Corvette only.

ENGINE REMOVAL

See *Engine Removal* at end of ENGINE Section.

CYLINDER HEAD & MANIFOLDS

INTAKE MANIFOLD

Removal — 1) Drain radiator and remove air cleaner. Disconnect negative battery cable, upper radiator hose, heater hose at manifold, accelerator linkage at carburetor, and fuel line at carburetor. Disconnect crankcase ventilation lines and spark advance hose at distributor. Remove distributor cap and mark rotor position with chalk, then remove distributor.

2) Remove (as required) oil filler and air cleaner brackets, air compressor and bracket, accelerator return spring and bracket, and accelerator bellcrank. Remove alternator upper mounting bracket. Remove manifold attaching bolts, then remove manifold and carburetor as an assembly.

Installation — 1) Clean gasket and seal surfaces on manifold, block and cylinder heads. Install gaskets on cylinder heads and place a $\frac{3}{16}$ " bead of room temperature sealant on front and rear ridges of cylinder block.

2) Extend the bead $\frac{1}{2}$ " up each cylinder head to seal and retain manifold side gaskets. Seal at water passages.

3) Install manifold and torque bolts to specification in sequence shown in Fig. 1. Reverse removal procedure to complete installation.

NOTE — If crankshaft has been rotated while distributor was removed, time distributor to No. 1 cylinder.




Fig. 1 Intake Manifold Tightening Sequence

CYLINDER HEAD

Removal — 1) Remove intake manifold and carburetor as an assembly. Remove alternator lower mounting bolt and set unit aside. Remove A/C compressor and forward mounting bracket (if equipped).

NOTE — If equipped with A.I.R., disconnect hoses at injection tubing check valve.

2) Remove exhaust manifolds. Remove rocker arm cover, nuts, balls and rocker arms. Remove push rods.

NOTE — Valve mechanism components must be reinstalled in same location.

3) — Drain cooling system and remove cylinder head bolts. Remove cylinder head and gaskets.

Installation — Clean gasket surfaces on block and cylinder heads. Clean head bolt threads in block (dirt will affect torque). Use sealer on both sides of steel gaskets. Place gaskets in position on block with bead up. Install cylinder heads and bolts (with sealing compound on threads). Tighten in sequence shown in Fig. 2. Reverse removal procedure to complete installation.

NOTE — Do not apply sealer to composition steel asbestos gaskets.




Fig. 2 Cylinder Head Tightening Sequence

VALVES

VALVE ARRANGEMENT

E-I-I-E-E-I-I-E (Both banks, front to rear).

VALVE GUIDE SERVICING

Guides are integral with cylinder head. If valve stem clearance is excessive, use suitable tool set (J-5830) to ream guides to next oversize. Valves are available with standard, .003", .015", and .030" oversize stems.

General Motors V8 Engines

305" & 350" VIN CODES L, 8 & 4 V8 ENGINES (Cont.)

VALVE STEM OIL SEALS

An "O" ring type seal is installed in lower groove on valve stem after valve spring is compressed and before locks are installed. See *Valve Springs*.

VALVE SPRINGS

Removal - 1) Remove rocker arm cover, spark plug, rocker arms and push rods on cylinders to be serviced. Install air line adapter (J-23590) in spark plug port and apply compressed air to hold valves in place.

2) Using a valve spring compressor (J-4892), compress valve spring, remove valve locks and release tool. Remove valve cap, shield, spring and damper.

NOTE - Before installing old springs, check with a suitable spring tester (J-8056). Springs should be replaced if not within 10 pounds of specifications.

Installation - Position valve spring, damper, shield and retainer on valve stem. Compress spring and install oil seal in lower groove. Make sure seal is flat and not twisted. Install valve locks and release compressor tool. Check that locks are properly seated in upper groove in valve stem.

VALVE SPRING INSTALLED HEIGHT

Measure from spring seat (or top of shim) to top of the valve spring shield. If not within specifications, install 1/16" shim under spring. See Fig. 3.

CAUTION - Do not shim spring to give installed height less than specifications.

Application	① Installed Height
305" & 350"	
Intake	1 23/32"
Exhaust (VIN 8 & 4)	1 19/32"
Exhaust (Other Models)	1 23/32"

① - Specification is ± 1/32".




Fig. 3 Measuring Spring Installed Height

ROCKER ARM STUDS

NOTE - VIN 4 engines (350") use threaded rocker arm studs with push rod guides. Studs with damaged threads should be replaced. If threads in head are damaged or stripped, retap and install helical type insert. If helical insert is not available, replace head.

1) On all engines other than 350" VIN 4, rocker arm studs are available in .003" and .013" oversize. Remove old stud, using tool J-5802-1 (or equivalent) and a flat washer and nut. Ream stud hole before attempting to install new stud.

NOTE - Use suitable reamers (J-5715 for .003" oversize and J-6036 for .013" oversize).

2) Coat press-fit area of stud with hypoid axle lubricant. Drive stud in place using suitable tool (J-6880). Tool will bottom out on cylinder head when stud is installed at correct height.

HYDRAULIC VALVE LIFTER ASSEMBLY

NOTE - Lifters are serviced as complete assemblies only. Parts are not interchangeable between lifters. See Fig. 4.

1) If any component of lifter is worn or damaged, the complete lifter must be replaced. If lifters are disassembled for cleaning and inspection, be sure to reassemble and test with a leakdown tester following manufacturer's instructions.

NOTE - Check foot of lifter for concave wear pattern. If found, replace lifter. Lifters must be installed in original location.

2) Before installing lifters, coat foot of lifter with Molycote (or equivalent). An additive containing EP lubricant, such as EOS, should always be added to crankcase oil for break-in when new camshaft or lifters are installed.




Fig. 4 Hydraulic Valve Lifter Assembly

VALVE ADJUSTMENT

With No. 1 cylinder at TDC firing position, adjust exhaust valves No. 1,3,4,8 and intake valves 1,2,5,7 as follows:

305" & 350" VIN CODES L, 8 & 4 V8 ENGINES (Cont.)

1) Back off rocker arm stud adjusting nut until there is play in push rod, then tighten nut until push rod-to-rocker arm clearance is removed. Tighten nut one additional turn from this point (places lifter plunger in center of its travel).

2) Crank engine one complete revolution so No. 6 cylinder is at TDC firing position and adjust exhaust valves No. 2,5,6,7 and intake valves No. 3,4,6,8 in same manner.

PISTONS, PINS & RINGS

OIL PAN

See *Oil Pan Removal* at end of ENGINE Section.

PISTON & ROD ASSEMBLY

NOTE — New pistons must be installed in same cylinders for which they were fitted and used pistons in same cylinder from which they were removed.

Removal — 1) With oil pan, oil pump and cylinder head removed, use a suitable ridge reamer to remove any ridge or deposits on upper end of cylinder bore.

NOTE — Piston must be at bottom of stroke and covered with cloth to collect cuttings.

2) Inspect connecting rods and caps for cylinder identification and mark as necessary. Remove rod cap and install suitable guide on stud bolts to protect threads. Remove piston and rod assembly by pushing out top of block.




Fig. 5 Ring Gap Location

Installation — 1) Lightly coat pistons, rings and cylinder walls with engine oil. Make sure ring gaps are properly spaced and install ring compressor. See Fig 5. Install pistons with connecting rod bearing tang slot on side opposite camshaft.

NOTE — When installing rings on pistons, marked side of compression rings must be up.

2) Guide connecting rod onto crankshaft journal while tapping piston head with a hammer handle to seat connecting rod against crankshaft. Remove protective guides from studs and install mating rod cap. Tighten rod cap nuts.

NOTE — Connecting rods 1, 3, 5, and 7 are for the left bank; 2, 4, 6, and 8 for the right bank. Numbers on rods and caps must be on the same side when installed.

FITTING PISTONS

Measure pistons across centerline of piston pin. Measure cylinder bore diameter approximately $2\frac{1}{2}$ " from top of bore. The difference between the two diameters will be the piston-to-bore clearance. If clearance exceeds specifications, cylinder block must be rebored and oversize pistons installed. Pistons and rings are available in .001" and .030" oversize.

PISTON PINS

Measure piston pin and bore in piston. If clearance is not within specifications, replace piston and pin. Use suitable tool set (J-24086-20) and arbor press to press pin in and out of connecting rod. Check freedom of piston on pin after pressing operation. See Fig. 6.




Fig. 6 Piston Pin Installation Tools.

CRANKSHAFT & ROD BEARINGS

MAIN & CONNECTING ROD BEARINGS

NOTE — The following procedures are performed with the oil pan and oil pump removed. Bearings are precision insert type. No shims should be used for adjusting clearance and rods and caps should not be filed.

Connecting Rod Bearings — 1) After ensuring rod caps are marked for cylinder identification, remove rod caps. Use Plastigage method to check for proper bearing clearances. If not within specifications, new bearings must be installed.

305" & 350" VIN CODES L, 8 & 4 V8 ENGINES (Cont.)

2) New bearings are available in standard, .001" and .002" undersize for new crankshafts and .010" and .020" undersized for reconditioned crankshafts. Always check crankpins for out-of-round condition.

3) Selective fitting is required on each connecting rod. Coat bearing surfaces with oil, install rod cap and tighten. Check clearance between rods.

NOTE — Some connecting rod bearings may have been factory installed as .009" undersize for selective fitting.

Main Bearings — 1) Support crankshaft at both front and rear (damper and flywheel) and ensure that all bearing caps, other than one being checked, are tight. Starting with rear main bearing cap and working forward, remove one cap at a time and check bearing clearances using Plastigage method.

NOTE — When checking No. 1 main bearings remove all accessory drive belts to prevent tapered distortion of Plastigage.

2) If clearances are not within specifications, new bearings are available in standard, .001", .002", .009", .010" and .020" undersize. One half of a standard size bearing can be used in conjunction with one half of a .001" undersize bearing to obtain proper clearance.

NOTE — During production, .009" undersize bearings may have been installed for close tolerances. These bearings will be identified by a "9" stamped on one side of the undersize journal along with a spot of green paint. Also the cap will be painted light green on each side.

3) Never use an old bearing with a new bearing. Remove all main bearing upper halves (except rear main) by inserting a suitable tool in crankshaft oil hole. Rotate crankshaft in clockwise direction to roll bearing from engine. Oil new upper bearing and insert plain (unnotched) end between crankshaft and indented (notched) side of block. Rotate bearing into place.

4) To replace rear main bearing upper half, use a small drift punch and hammer to start bearing rotating out of block. Take care not to nick crankshaft journal. Use a pair of pliers (with taped jaws) to hold bearing thrust surface to oil slinger and rotate crankshaft to remove bearing. Oil new bearing and insert plain (unnotched) end between crankshaft and indented (notched) side of block. Use pliers, as in removing, to rotate bearing into place.

5) Main bearing caps are to be installed with arrow pointing forward. Tighten main bearing bolts except rear main. Torque rear main bolts 10-12 ft. lbs. and tap end of crankshaft first rearward, then forward to line up rear main bearing with crankshaft thrust face. Tighten all main bearing cap bolts. Rotate crankshaft to ensure there is no excessive drag.

REAR MAIN BEARING OIL SEAL

NOTE — Replace upper and lower seal halves as a unit. Install seal with lip facing front of engine. Remove oil pan and oil pump before servicing oil seal.

Removal — Remove rear main bearing cap and remove seal from cap. Use a small brass drift punch to tap upper seal until end protrudes far enough to be removed with pliers.

Installation — 1) Coat seal lips and bead with light engine oil, keeping oil off seal mating ends. To replace upper seal half, fabricate a tool from .004" shim stock. See Fig. 7. Position tip of tool between crankshaft and seal seat, then position seal between crankshaft and tip of tool so seal bead contacts tip of tool. Lip of oil seal must be toward front of engine.

NOTE — Line up thrust surfaces. See Step 5) under Main Bearings.

2) Roll seal around crankshaft using tool as a "shoehorn" to protect seal bead from sharp corner of seal seat surface. Remove tool, being careful not to withdraw seal.

CAUTION — Installation tool must remain in position until seal is positioned with both ends flush with block.




Fig. 7 Rear Main Oil Seal Installing Tool

3) Install lower seal in bearing cap, using tool as a "shoehorn". Feed seal into cap using light pressure with thumb and finger. Apply sealant to bearing cap interface, being careful to keep sealant off seal split line. Install bearing cap and tighten bolts.

TORSIONAL VIBRATION DAMPER

Removal — Remove fan, pulley, radiator and shroud. Remove accessory drive pulley and damper retaining bolt. Using a suitable puller, J-23523, remove damper from crankshaft.

NOTE — Unless additional service procedures, such as camshaft removal, are required radiator removal will not be necessary.

Installation — Use of proper tool, J-23523, is necessary to prevent movement of the inertia weight section of damper on hub. Coat seal contact area of damper with oil. Place damper over key on crankshaft and pull damper onto shaft. Install damper bolt and tighten.

CAMSHAFT

ENGINE FRONT COVER

Removal — Remove torsional damper and water pump. Remove crankcase front cover bolts and two oil pan-to-front cover attaching bolts. Remove front cover. Discard gasket.

Installation — 1) Make sure gasket surfaces on block and engine front cover are clean. Remove any excess oil pan gasket at oil pan and engine block junction. Apply a 1/8" bead of silicone rubber sealer at oil pan and block junction. Coat cover gasket with sealer and position on cover.

305" & 350" VIN CODES L, 8 & 4 V8 ENGINES (Cont.)

2) Position cover on cylinder block. Loosely install four top screws. Apply a bead of silicone sealer to bottom of oil pan-to-cover seal and position seal on cover.

3) Tighten screws alternately and evenly, while pressing downward on cover to align cover on dowel pins. Do not force holes over dowel pins, as holes will be distorted. Install remaining screws and tighten. Install torsional damper and water pump.

FRONT COVER OIL SEAL

Front Cover Installed on Engine — Remove crankshaft pulley and hub or torsional damper. Pry old seal out of cover from front side with screwdriver. Use care not to damage crankshaft. Install seal with open end of seal toward inside of front cover. Drive into place with suitable tool (J-23042). See Fig. 8.

Front Cover Removed From Engine — Pry old oil seal out of cover from front side with screwdriver. Support cover at sealing area and install new seal with open end of seal toward inside of front cover. Drive into place with suitable tool (J-23042). See Fig. 8.




Fig. 8 Front Cover Oil Seal Installation

TIMING CHAIN

Removal — Remove front cover and crank engine until timing marks are aligned. See Fig. 9. Remove camshaft sprocket-to-camshaft bolts. Remove sprocket and timing chain together.

NOTE — Sprocket is a light press fit on camshaft, dislodge by tapping lightly on lower edge of sprocket.

Installation — Install timing chain on camshaft sprocket and hold sprocket vertical with chain hanging and align marks on camshaft and crankshaft sprockets. Align dowel in camshaft with dowel hole in sprocket and install sprocket on camshaft. Draw sprocket onto camshaft using three mounting bolts.

CAUTION — Do not attempt to drive sprocket on shaft as plug at rear of camshaft can be dislodged. Tighten bolts and lubricate timing chain with oil.




Fig. 9 Timing Chain Sprocket Alignment

CAMSHAFT

NOTE — Camshaft may be removed without removing engine from vehicle using following procedure:

Removal & Installation — Remove valve lifters, radiator, grille, and engine front cover. Remove fuel pump and push rod. Remove camshaft sprocket and timing chain. Tap sprocket with plastic mallet to loosen it from shaft. Remove camshaft. To install, coat camshaft lobes with Molykote and journals with engine oil. Reverse removal procedure.

CAMSHAFT BEARINGS

NOTE — Following procedures are done with crankshaft and camshaft removed. If piston assemblies remain in engine, tape connecting rods to cylinder walls so they will not be in the way while replacing bearings.

Removal — 1) Drive camshaft rear plug from cylinder block. Use camshaft bearing tool J-6098 (or equivalent) with nut and thrust washer installed to end of threads. Index pilot in front bearing and install puller screw through pilot. Install tool with shoulder toward bearing, making sure sufficient number of threads are engaged.

NOTE — Remove bearings nearest center of engine first.

2) Using two wrenches, hold puller screw while turning nut. When bearing has been pulled from bore, remove tool and bearing from puller screw. Remove remaining bearings (except front and rear) in same manner. It is necessary to index pilot in rear bearing to remove rear intermediate bearing. Assemble remover and installer tool on driver handle and remove front and rear bearings by driving towards center of cylinder block.

Installation — Install front and rear bearings first. These bearings will act as guides for the pilot (tool) and will center remaining bearings as they are pulled into place. As each bearing is installed, make sure oil holes in bearings are aligned

305" & 350" VIN CODES L, 8 & 4 V8 ENGINES (Cont.)

with oil holes in block. No. 1 bearing oil hole must be positioned so that oil holes are the same distance from 6 o'clock position. Number 2 through 4 bearing oil holes must be positioned at 5 o'clock position (toward left side of engine and even with bottom of cylinder bore). No. 5 oil hole must be in 12 o'clock position. After all bearings have been installed, install new rear plug.

NOTE — Plug should be installed flush to $\frac{1}{32}$ " deep and parallel with rear surface of block.

CAMSHAFT LOBE LIFT

1) Remove rocker arm. Attach dial indicator to rocker arm stud or rocker arm cover mounting hole and adjust dial indicator to seat on push rod.

NOTE — Be sure push rod is seated in lifter socket.

2) Rotate crankshaft slowly until lifter is on heel of cam lobe (push rod will be in lowest position). Zero dial indicator and slowly bump engine over until push rod is fully raised.

CAUTION — If using an auxiliary starter switch, distributor primary lead must be disconnected from coil.

3) Compare total lift on dial indicator with specifications. Continue to rotate engine until indicator reads zero (for accuracy check on dial indicator).

Camshaft Lobe Lift

Application	① Lobe Lift
305"	
Intake2484"
Exhaust2633"
350" (VIN 4)	
Intake3000"
Exhaust3067"
350" (All Others)	
Intake2600"
Exhaust2733"

① — Specification is $\pm .002$ ".

ENGINE OILING

Crankcase Capacity — All engines, 4 quarts. Add 1 quart with oil filter change.

Oil Filter — Replace at first oil change then every second oil change after that.

Normal Oil Pressure (Hot) — 40 psi @ 2000 RPM.

Pressure Regulator Valve — In oil pump body. Not adjustable.

ENGINE OILING SYSTEM

Full pressure lubrication through a full flow oil filter is furnished by a gear-type oil pump. Main oil gallery feeds oil, through drilled passages, to camshaft and crankshaft to lubricate bearings. Valve lifter gallery feeds the valve lifters, which feed individual rocker arms through hollow push rods.




Fig. 10 Engine Oiling System

OIL PUMP

Disassembly — Remove pump cover and mark gear teeth so they may be reassembled with same teeth indexing. Remove idler gear and the drive gear and shaft from pump body. Remove pressure regulator valve retaining pin, valve and related parts. Pull oil pick-up tube from body, if necessary.

NOTE — If pump gears or body are damaged or worn, replacement of entire pump assembly is necessary. Do not disturb pick-up screen on pipe. This is serviced as an assembly only.

Reassembly — Apply sealer to end of pick-up pipe and tap in place, if removed. Install pressure regulator valve and drive gear and shaft into body. Install idler gear in body with smooth side of gear towards pump cover. Install pump cover and check drive shaft for free operation. Then install pump on rear main bearing cap. Be sure bottom of pickup screen is parallel with oil pan rails.




Fig. 11 Oil Pump Assembly

General Motors V8 Engines

6-123

305" & 350" VIN CODES L, 8 & 4 V8 ENGINES (Cont.)

ENGINE SPECIFICATIONS

GENERAL SPECIFICATIONS						
Engine	Net HP At RPM	Torque (Ft. Lbs. at RPM)	Compr. Ratio	Bore	Stroke	Displ. Cu. Ins.
305" V8 2-Bbl. VIN G 4-Bbl. VIN H	130@3200	245@2000	8.5-1	3.74"	3.48"	305
	160@4000	235@2400	8.5-1	3.74"	3.48"	305
350" V8 4-Bbl. VIN L 4-Bbl. VIN 8 4-Bbl. VIN 4	170@3800	270@2400	8.5-1	4.00"	3.48"	350
	195@4000	285@3200	8.5-1	4.00"	3.48"	350
	225@5200	270@3600	9.0-1	4.00"	3.48"	350

VALVE SPRINGS			
Engine	Free Length	PRESSURE (LBS.)	
		Valve Closed	Valve Open
305" V8	①2.03"	76-84@1.70"	194-206@1.25"
350" V8 VIN L VIN 8	①2.03"	76-84@1.70"	194-206@1.25"
Int. Exh.		76-84@1.70" 76-84@1.61"	194-206@1.25" 194-206@1.16"
VIN 4 Int. Exh.		76-84@1.70" 76-84@1.61"	194-206@1.25" 194-206@1.16"

CAMSHAFT			
Engine	Journal Diam.	Clearance	Lobe Lift
305" V8	1.8682-1.8692"	①	.2484" Int. .2667" Exh.
350" V8	1.8682-1.8692"	①	②.2600" Int. ③.2733" Exh.

- ① - End play is .004-.012".
- ② - 350" VIN 4, .3000".
- ③ - 350" VIN 4, .3067".

① - Damper Free Length is 1.86".

VALVES							
Engine & Valve	Head Diam.	Face Angle	Seat Angle	Seat Width	Stem Diameter	Stem Clearance	Valve Lift
305" V8 Int. Exh.	1.715-1.725"	45°	46°	.031-.063"	.3410-.3417"	.0010-.0027"	.373"
	1.495-1.505"	45°	46°	.063-.094"	.3410-.3417"	.0010-.0027"	.410"
350" V8 Int. Exh.	①1.935-1.945"	45°	46°	.031-.063"	.3410-.3417"	.0010-.0027"	②.390"
	③1.495-1.505"	45°	46°	.063-.094"	.3410-.3417"	.0010-.0027"	④.410"

- ① - VIN 4, 2.017-2.023".
- ② - VIN 4, .450".
- ③ - VIN 4, 1.595-1.605".
- ④ - VIN 4, .460".

PISTONS, PINS, RINGS						
Engine	PISTONS	PINS		RINGS		
	Clearance	Piston Fit	Rod Fit	Rings	End Gap	Side Clearance
305" & 350"	①.0007-.0017"	②.00025-.00035"	.0008-.0016"	1	.010-.020"	.0012-.0032"
			Interference	2	③.010-.025"	.0012-.0032"
			Fit	3	.015-.055"	.002-.007"

- ① - VIN 4, .0046-.0056".
- ② - VIN 4, .00045-.00055".
- ③ - VIN 4, .010-.023".

General Motors V8 Engines

305" & 350" VIN CODES L, 8 & 4 V8 ENGINES (Cont.)

ENGINE SPECIFICATIONS (Cont.)

CRANKSHAFT MAIN & CONNECTING ROD BEARINGS							
Engine	MAIN BEARINGS				CONNECTING ROD BEARINGS		
	Journal Diam.	Clearance	Thrust Bearing	Crankshaft End Play	Journal Diam.	Clearance	Side Play
305" V8							
2-Bbl. VIN G	①2.4484-2.4493"	①.0008-.0020"	No. 5	.002-.006"	2.0986-2.0998"	.0013-.0035"	④.006-.014"
4-Bbl. VIN H	②2.4481-2.4490"	②.0011-.0023"					
350" V8	③2.4479-2.4488"	③.0017-.0032"					
4-Bbl. VIN L							
4-Bbl. VIN 8							
4-Bbl. VIN 4							

- ① - Journal No. 1.
- ② - Journal Nos. 2, 3 and 4.
- ③ - Journal No. 5.
- ④ - 350" VIN 8 & 4 side play is .008-.014".

TIGHTENING SPECIFICATIONS	
Application	Ft. Lbs
Cylinder Head	65
Intake Manifold	30
Main Bearing Cap	①70
Connecting Rod Cap	45
Exhaust Manifold	②20
Flywheel Bolts	60
Camshaft Sprocket	20
Torsional Damper Bolt	60
Water Pump	30
Oil Pump	65
Clutch Pressure Plate	
350" VIN 8 & 4	30
All Others	35
Water Outlet	30
Oil Pan	
1/4" Bolts	6-7
5/16" Bolts	
350" VIN 8 & 4	14
All Others	22
Front Engine Cover	6-7
Oil Pump Cover	6-7

① - 350" VIN 4 outer bolts, 70 ft. lbs.
 ② - 350" VIN L inner bolts, 30 ft. lbs.