

6.0 LITER V8

IDENTIFICATION CODING

ENGINE IDENTIFICATION

Engine may be identified from Vehicle Identification Number stamped on a metal tab. The tab is attached to instrument panel close to windshield on driver's side of vehicle and is visible from outside. The VIN number contains 17 digits. The 8th digit identifies the engine and the 10th digit establishes the model year. Engine codes are also stamped on pad at rear of crankcase, behind intake manifold.

Engine Code	
Engine	Code
6.0L (368") MD/DFI [ⓐ]	9
ⓐ — Modulated Displacement/Digital Fuel Injection.	

SPECIAL ENGINE MARKS

Information identifying oversize components are stamped in following locations:

Oversize Cylinder Guides — On cylinder head gasket surface in line with oversize valve. Number indicates amount

Cylinder-to-Piston Relationship		
Letter	Cylinder Size Inches (mm)	Piston Size Inches (mm)
A	3.8000-3.8004 (96.52-96.53)	3.7990-3.7994 (96.49-96.50)
B	3.8004-3.8008 (96.53-96.54)	3.7994-3.7998 (96.50-96.51)
C	3.8008-3.8012 (96.54-96.55)	3.7998-3.8002 (96.51-96.52)
D	3.8012-3.8016 (96.55-96.56)	3.8002-3.8006 (96.52-96.53)
E	3.8016-3.8020 (96.56-96.57)	3.8006-3.8010 (96.53-96.54)

guide is oversize. For example, "3" indicates .003" (.076 mm) oversize.

Oversize Cylinder Bore — On cylinder head face of block. Letter indicates cylinder and piston sizes. See *Chart*. Double letters indicate cylinder has been bored .010" (.25 mm) over diameter indicated by single letter in chart.

ENGINE REMOVAL

See *Engine Removal at end of ENGINE Section*.

CYLINDER HEAD & MANIFOLDS

INTAKE MANIFOLD

Removal — 1) Disconnect negative battery cable, all hoses at air cleaner and remove air cleaner. Disconnect HEI connector. Disconnect throttle and cruise control linkage at throttle adapter plate. Disconnect right side spark plug wires at spark plugs and position out of way. Remove throttle return spring and downshift switch bracket.

2) Disconnect A/C compressor clutch wiring connector. Disconnect all vacuum hoses from manifold. Disconnect fuel line at throttle body and move slightly out of way. Disconnect canister hoses and distributor vacuum advance hose at intake manifold.

3) Discharge A/C compressor and disconnect refrigerant lines. Remove compressor. Disconnect PCV valve from rocker arm cover. Drain radiator and remove upper radiator hose from thermostat housing. Remove manifold bolts and manifold. Remove sheet metal manifold shield and gasket. Remove front and rear manifold to cylinder block rubber seals.

Installation — Coat ends of rubber seals with gasket cement and place over rails at front and rear of cylinder block. Tabs on seals should be positioned in holes in rails; beveled ends of gasket tucked under edge of cylinder head. Coat upper and lower port surface area of sheet metal gasket (do not coat ends) and position on engine. Complete installation by reversing removal procedure.





Fig. 1 6.0L Exhaust Manifold

6.0 LITER V8 (Cont.)

NOTE — Holes in gasket should engage dowel pins on cylinder heads.

EXHAUST MANIFOLD

Removal (Left Side) — 1) Remove air cleaner and tube assembly from air preheat stove. Remove nuts securing support bracket for shift linkage, if equipped, position out of way. Remove bolts securing air preheat stove and remove stove.

2) Remove oxygen sensor, if equipped. Disconnect exhaust pipe from manifold. Bend lock tabs from bolt heads and remove bolts. Remove exhaust manifold.

Removal (Right Side) — 1) Remove rear alternator brace and A.I.R. hoses (if equipped). Disconnect exhaust pipe from manifold and remove EFE valve.

2) Bend lock tabs from bolt heads and remove bolts. Remove exhaust manifold.

Installation — Apply thin coat of graphite lubricant to cylinder head mounting surfaces. Position manifold on cylinder head and tighten bolts. Bend lock tabs on bolt heads. To complete installation, reverse removal procedure.

CYLINDER HEAD

Removal — 1) Drain cooling system and remove intake and exhaust manifolds. Remove rocker arm covers. Disconnect electrical and ground connections from cylinder heads. Partially remove power steering pump from left cylinder head.

2) Disconnect heater hose from rear of right cylinder head. Remove alternator and A.I.R. pump. Identify rocker arm assemblies before removal for reinstallation in original positions. Remove rocker arm assemblies and push rods.

3) Install two $\frac{7}{16}$ -14 x 6 bolts in 2 rocker arm support bolt holes as lifting handles. Remove cylinder head bolts and lift head from block.




Fig. 2 Cylinder Head Bolt Location

NOTE — Bottom rear bolt is trapped due to clearance. Suspend bolt to ease removal. Also, this bolt must be installed and suspended prior to positioning head on block.

Installation — 1) Clean all gasket surfaces and position cylinder head and gasket over dowels on block. Install head bolts finger tight in locations as indicated in Fig. 2. Tighten bolts starting from center of cylinder head and working toward both ends.

2) Remove 2 bolts used as lifting handles and complete installation by reversing removal procedure.

VALVES**VALVE ARRANGEMENT**

E-I-E-I-E-I-E-I (Right Bank, front to rear).

I-E-I-E-I-E-I-E (Left Bank, front to rear).

HYDRAULIC VALVE LIFTER LEAKDOWN RATE

Use valve lifter leakdown rate tester, J-3074, to check for faulty lifters without removal from engine. Tool uses a feeler gauge of specific thickness placed between rocker arm and valve stem, causing valve spring pressure to force oil out of lifter. A spring, attached to tool and compressed against the valve spring retainer, ejects the feeler gauge when lifter has leaked down enough to allow valve to seat. Faulty lifter(s) can be easily located by observing length of time required for each lifter to leakdown thickness of feeler gauge. Run engine to allow lifters to fill with oil and check lifters as follows.

1) Remove distributor cap and align rotor to No. 1 firing position. Remove air cleaner. Disconnect negative battery cable, spark plug wires at plugs and remove wiring from tabs on rocker arm covers.

2) Remove rocker arm covers and check cylinder Nos. 1, 2, 5, 7 and 8 intake valves and Nos. 1, 3, 5, 6 and 8 exhaust valves.

3) Insert feeler gauge of tool between valve stem and at same time compress tool "popout" spring to tool stock against valve spring retainer.

NOTE — Install tool as quickly as possible to avoid unnecessary lifter leakdown.

4) Note interval that tool is held in place by valve spring pressure. Noisy lifter(s) will have shortest leakdown time.

5) Install components previously removed and start engine to fill lifters with oil. Repeat removal of components in step 1).

6) With distributor rotor in No. 4 firing position, check Nos. 3, 4 and 6 intake valves and Nos. 2, 4 and 7 exhaust valves, observing time.

7) Install components by reversing removal procedure.

HYDRAULIC VALVE LIFTER ASSEMBLY

Lifters are serviced as complete assemblies only and parts are not interchangeable between lifters. If lifters are disassembled for cleaning and inspection, reassemble and perform Hydraulic Valve Lifter Leakdown Rate procedure.

6.0 LITER V8 (Cont.)




Fig. 3 Exploded View of Hydraulic Lifter Assembly

VALVE GUIDE SERVICING

Wear Check (Hole Gauge Method) — With valve removed, measure top and bottom of guide with hole gauge. Measure gauge each time with outside micrometer. Standard valve guide is .343" (8.71 mm) diameter. Measure valve stem and subtract from largest guide measurement to obtain clearance. If greater than .005" (.13 mm), ream guide to next oversize.

Wear Check (Alternate Method) — Use 1/16" (1.5 mm) wide strip of .005" (.13 mm) brass shim stock on "no-go" basis. Bend one end of shim. Insert shim into valve guide no more than 1/4" (6.35 mm) with tip facing push rod side of head. If valve stem will enter guide, clearance is excessive and guide must be reamed to next oversize.

Servicing — Service valves are available in standard and .003", .006" and .013" (.08, .15 and .33 mm) oversize. If clearance is found to be excessive, guide should be reamed to next oversize using appropriate reamer. Valve with corresponding oversize stem should be installed. When installing oversize valves and guides, stamp oversize on cylinder head gasket surface.

VALVE SEAT

Wear Check — Using dial indicator and a solid, slightly tapered valve guide pilot, check roundness of each valve seat. Roundness should be within .004" (.10 mm).

NOTE — Pilot of correct size must be used, do not attempt to drive pilot into guide. Pilots with adjustable diameters for various size guides are not recommended.

Servicing — Grind valve seats to within .002" (.05 mm) dial indicator reading, whenever new valves are being installed or if roundness, seat width or full contact of valves is not as specified. Check valve seat width and seat location on valve. Valve seat width should be between 3/64-1/16" (1.19-1.59 mm). Valve seat should be cut so seat is 1/16" (1.59 mm) smaller in diameter than head of valve.

NOTE — Service valves should not have more than 1/16" (1.59 mm) side contact with valve seat and should not be ground. Service valves are ready to use as received. Grinding of valves by hand with grinding compound or lapping to seat valves is not recommended.

VALVE SPRINGS AND VALVE STEM OIL SEALS

NOTE — Valve stem oil seals are integral with spring retainers. If removed, spring retainer/oil seal assembly must be replaced.

Removal — 1) Remove rocker arm cover, rocker arm support bolts and rocker arm assemblies. Remove push rods in sequence for reinstallation in original positions. Remove spark plug from cylinder to be serviced and install air line with adapter tool (J-22794).

2) Install rocker arm support bolt into stand of cylinder being serviced. Install valve spring compressor tool (J-22765) over bolt and compress valve spring. Remove valve stem locks from valve stem and remove spring retainer/oil seal and valve spring. Discard spring retainer/oil seal.

NOTE — Do not remove air pressure as this will allow valve to fall into cylinder. If air pressure fails to hold valve closed during this operation, remove cylinder head for inspection.

Installation — Position valve spring over valve and install new spring retainer/oil seal. Compress valve spring and install valve stem locks. Remove spring compressor tool and bolt. Remove air pressure and adapter tool. Reverse removal procedure to complete installation.

ROCKER ARM ASSEMBLY

Contact surfaces of rocker arms and pivots must be coated with Lubriplate (or equivalent) upon reassembly and installed in original positions. Tighten flanged bolts alternately and evenly to prevent damaging rocker arms, pedestals and/or pivots.

NOTE — Valve selector assemblies are installed on Nos. 1, 4, 6 and 7 cylinders.

PISTONS, PINS & RINGS

OIL PAN

See *Oil Pan Removal at end of ENGINE Section.*

PISTON AND ROD ASSEMBLY

Removal — 1) Disconnect negative battery cable and remove cylinder heads. With piston covered and at bottom of stroke, remove ridges or deposits on upper end of cylinder bore.

6.0 LITER V8 (Cont.)

2) Remove oil pan, oil pickup tube and strainer assembly, discarding "O" ring. Remove rod cap. Install rubber hoses over connecting rod bolts to protect crankshaft and bore. Push piston and rod assembly out top of block and reinstall caps to connecting rods, matching stamped numbers.

Ring Installation — Install only replacement ring sets with molybdenum filler upper compression ring and multi-piece oil rings. Compression rings have locating dimples near ends on top side for easy identification. Install ring with top side dimple facing up. Piston ring gaps should be staggered 120°.

Installation — 1) Lightly coat pistons, rings and cylinder walls with engine oil. Install bearing inserts making sure bearing tangs are positioned in cap locating notches.

2) Install rubber hoses over connecting rod bolts. Using a ring compressor, position capless rod and piston in cylinder bore with notch toward front of engine (letter "R" on piston toward rear).

3) Guide connecting rod onto crankshaft journal, while tapping piston head with wooden hammer handle to seat connecting rod on journal. Remove rubber hoses from connecting rod bolts and install mating rod cap. Cap and rod numbers must align. Install rod cap nuts and tighten.

NOTE — Numbered sides of connecting rods on Nos. 1, 3, 5 and 7 must be on right side of engine and Nos. 2, 4, 6 and 8 on left side.

FITTING PISTONS

Measure piston $\frac{3}{16}$ " (4.76 mm) below cross slot or $\frac{1}{4}$ " (6.35 mm) below oil ring groove. Measure cylinders $1\frac{1}{8}$ " (28.5 mm) from top and perpendicular to centerline of face. Cylinder bores must be reconditioned to more than .010" (.25 mm) over-size.

PISTON PINS

Removal — 1) Position support fork of tool (J-24086-11) between connecting rod and piston. Install removal arbor (J-24086-8) through alignment hole in tool base.

2) Center piston, rod and pin assembly with removal arbor centered in tool arch (J-24086-10). Press piston pin out of connecting rod.

Installation — 1) Install pin guide (J-24086-4) through piston and into connecting rod. Hand tap pin guide into position for proper retention.

NOTE — Pin guide centers connecting rod in piston. When piston and components are positioned on fork of tool, pin guide will center assembly in tool. Using too small a pin guide will not center piston assembly in tool and damage may occur.

2) Install piston assembly into fork assembly of tool. Tool will support connecting rod at piston pin. Piston assembly must slide onto fork until pin guide contacts fork.

3) Adjust installing arbor (J-24086-9) to "G8" by turning numbered sleeve on lettered shaft. Turn knurled nut to lock numbered sleeve. See Fig. 4.

4) Insert installing arbor through hole in tool arch. Press piston pin into connecting rod until sleeve on installing arbor contacts

top of tool arch. Pin guide will fall out of connecting rod as piston pin is pressed in.

NOTE — Do not exceed 5000 Lbs. (22240 N) force when seating arbor sleeve against arch.




Fig. 4 Piston Pin Installation Tools

CRANKSHAFT & ROD BEARINGS**MAIN AND CONNECTING ROD BEARINGS**

Main Bearings — 1) Check main bearing clearances one at a time using Plastigage method. If bearings are being checked with engine in vehicle, crankshaft must be supported to take up clearance between upper bearing half and crankshaft.

2) Place strip of .005" (.13 mm) brass stock between lower bearing half and crankshaft bearing journal in bearing caps adjacent to bearing being checked.

NOTE — When reinstalling bearing caps with shims, lightly tighten attaching bolts to avoid damaging bearing caps.

3) If clearance is not within specifications, replace bearings. If new bearings do not bring clearance within specifications, replace crankshaft.

4) No. 1 upper and lower bearings are interchangeable. No. 2 and 4 upper bearings are interchangeable; No. 2 and 4 lower bearings are interchangeable. No. 3 and 5 upper and lower bearings are not interchangeable and must be installed in original positions. See Fig. 5.

6.0 LITER V8 (Cont.)




Fig. 5 Main Bearing Identification

Connecting Rod Bearings — After ensuring rod caps are marked for cylinder identification, remove rod caps. Use Plastigage for checking proper bearing clearances. If clearance is not within specifications, replace bearings. If new bearings do not bring clearance within specifications, replace crankshaft.

NOTE — When installing bearings, tangs on bearings must match notches in rod and cap.

THRUST BEARING ALIGNMENT

With all main bearing cap bolts finger tight, tap crankshaft forward, then rearward several times to align thrust bearings. Tighten all main bearing cap bolts.

REAR MAIN BEARING OIL SEAL

Removal — Remove engine oil pan and rear main bearing cap, discarding lower seal half removed from bearing cap. Rotate upper seal half by pushing on one end with sharp object and remove upper seal half from cylinder block. Inspect grooves in bearing cap and cylinder block to ensure both are clean, dry and free from burrs.

NOTE — Seal halves are identical and pre-lubricated with a film of wax for break-in. Do not remove or damage film.

Installation — 1) To install lower half of seal, slide either end into position at one end of bearing cap and place oil seal tool made from shim stock in groove at other end of bearing cap. Lip of seal must face front of engine. Install seal half using tool as a shoehorn ensuring seal is flush on each side. See Fig. 6.

NOTE — Make sure seal is pressed down firmly and is flush on each side to avoid possibility of leak at seal split line. Avoid pressing on lip as damage to sealing edge could result.

2) To install upper half of seal, position tool in groove of block. Lubricate seal and start into groove with lip facing forward. Rotate seal into position using care not to distort it.

3) Do not press on lip or sealing edge may be damaged. Also, both ends of seal should be flush at seal split line to avoid

leaks. Install bearing cap bolts and tighten. Complete installation by reversing removal procedure.




Fig. 6 Rear Main Bearing Oil Seal Installing Tool

CAMSHAFT

FRONT COVER OIL SEAL

Removal and Installation — Remove crankshaft pulley and hub. Using thin bladed screwdriver, pry out front cover oil seal and discard. Lubricate new oil seal, filling cavity with wheel bearing grease. Position seal on end of crankshaft with spring side toward engine. Using seal driver tool (J-22770), drive seal into front cover until it bottoms.

ENGINE FRONT COVER

Removal — Remove crankshaft pulley and hub. Loosen starter enough to gain access to oil pan bolts. Loosen oil pan bolts and lower front of oil pan. Remove lower radiator hose from water pump. Remove bolts securing front cover and lift off front cover and water pump as an assembly. Discard gasket.




Fig. 7 Engine Front Cover Bolt Locations

6.0 LITER V8 (Cont.)

Installation — Clean all gasket surfaces and install new front cover gasket over locating dowels on block. Use small amount of sealer to hold gasket in place. Install front cover and water pump assembly over end of crankshaft, aligning dowel holes in cover with dowels on block. Install bolts and tighten. See Fig. 7 for location of bolts.

NOTE — Be sure oil pan seal has not been damaged during front cover removal. Use gasket cement on seal areas.

TIMING CHAIN

Removal — Remove radiator, front cover, distributor, oil pump and fuel pump. Remove oil slinger from crankshaft. Remove bolts securing fuel pump eccentric to camshaft and remove eccentric. Remove bolts from camshaft sprocket and remove camshaft sprocket with chain attached.

Installation — 1) Install camshaft sprocket in timing chain with timing mark toward front. Place chain over crankshaft sprocket, aligning timing marks on both sprockets. See Fig. 8.

2) Hold camshaft sprocket in position and press sprocket on camshaft by hand, being sure index hole in camshaft is aligned with index hole in sprocket.

3) Install and tighten bolts securing camshaft sprocket to camshaft. Install and tighten fuel pump eccentric. Reverse removal procedure to complete installation.

NOTE — Engine was timed for No. 4 cylinder. Adjust distributor rotor for No. 4 firing position or turn crankshaft 360° and set ignition timing for No. 1 cylinder.




Fig. 8 Timing Chain Sprocket Alignment

CAMSHAFT

Removal — With timing chain and gears removed, remove valve lifters and slide camshaft forward out of engine using care to prevent damage to bearing bores.

Installation — 1) Apply a thin coat of rear axle lubricant to all camshaft lobes and bearing journals. Guide camshaft carefully into cylinder block.

NOTE — Extreme care must be used to prevent nicking or scratching camshaft bearings.

2) Install valve lifters. Insert camshaft sprocket in timing chain with timing mark toward front. Place chain over crankshaft sprocket and align timing marks on both sprockets. See Fig. 8. Install timing chain and gears, making sure index hole in camshaft lines up with index hole in sprocket.

CAMSHAFT BEARINGS

Removal — 1) With camshaft removed, place arbor (J-21054-2) on driver (J-25262-7) and position arbor shoulder against face of No. 1 bearing. Drive out bearing through rear of bearing bore with hammer. Discard bearing.

2) Install pilot (J-25262-6) in No. 1 bearing bore. Place arbor against No. 2 bearing and force bearing out rear.

3) Remove remaining bearings in same manner. Drive out rear cup plug behind No. 5 bearing, with No. 5 bearing.

Installation — 1) Install new cup plug in rear of No. 5 bearing bore and seal plug with permanent type sealer. Scribe reference mark on front face of each bore to indicate center oil passage position.

2) Slide arbor and driver through bearing bores until arbor is positioned between No. 4 and 5 bores. Position pilot in No. 1 cam bearing bore.

3) Place new bearing on arbor, position in No. 5 bore, aligning oil hole in bearing with scribe mark.

4) Install bearing in bore until last white line on driver is flush with front face of pilot. Use only line labeled "500". Repeat procedure to install Nos. 4, 3 and 2, using white lines labeled "500" as stopping points.

5) Install No. 1 bearing using only arbor and driver. Check alignment of oil holes.

ENGINE OILING

Crankcase Capacity — 6 quarts with filter; 5 quarts without changing filter.

Oil Filter — Replace at every oil change.

Normal Oil Pressure — 35 psi minimum at 30 MPH. Average pressure at idle is 10 psi.

Pressure Regulator Valve — Not adjustable.

ENGINE OILING SYSTEM

Right longitudinal header is fed through angular passage from oil filter and pump. See Fig. 9. Oil crosses to left longitudinal header through intersecting vertical passages above No. 2 camshaft bearing, continuing through left longitudinal header to oil pressure signal switch.

Crankshaft, Camshaft and Connecting Rods — Main bearings No. 2, 3 and 4 are lubricated from right longitudinal header through holes drilled in block. Main bearings No. 1 and 5 are lubricated in same manner from left header. Camshaft bearings are lubricated from corresponding main bearings through holes in block. Connecting rod bearings are lubricated from adjacent main bearing through holes in crankshaft.

6.0 LITER V8 (Cont.)

Lifters, Rocker Arms, Pistons and Pins — Longitudinal headers feed hydraulic valve lifters under pressure through drilled passages. From lifters, oil flows through hollow push rods to rocker arm pivot points, push rod tips and valve tips. Pistons, pins and cylinder walls are lubricated by oil splashed up from crankcase. Oil drains from cylinder heads into valve lifter compartment, returns to crankcase through hole in bottom of compartment.

OIL PUMP

Removal and Installation — Oil pump is mounted on right side near front of engine. Remove oil filter. Remove bolts securing pump to engine, leaving bolt nearest pressure regulator

until last. Clean and inspect all parts. See *Oil Pump Specifications*. Before reinstalling pump, pack with petroleum jelly. To install, tighten bolt nearest regulator, allowing oil pump to ride up with bolt. Tighten remaining bolts and install filter.

ENGINE COOLING

WATER PUMP

Removal — 1) Disconnect negative battery cable and drain radiator. Remove 2 screws from upper fan shroud and remove wiring harness. Remove 2 screws securing power steering pump reservoir to upper shroud and remove reservoir.

2) Remove staples from upper and lower shroud and remove upper shroud. Remove fan assembly. Remove all accessory belts. Remove A/C compressor and set aside with lines connected. Remove alternator and bracket from engine.

3) Loosen clamps and disconnect inlet and outlet hoses and coolant reservoir from pump. Remove crankshaft and water pump pulleys. Remove 7 screws and 3 nuts securing water pump.

Installation — If installing new water pump, transfer pulley from old pump. To ensure proper seal, clean all sealing surfaces. Apply a 1/8" bead of sealant to water pump sealing surface. While sealer is wet, install water pump and tighten attaching bolts. To complete installation reverse removal procedure.

NOTE — For further information on cooling system capacities and other cooling system components, see appropriate article in *ENGINE COOLING SYSTEMS* section.

Oil Pump Specifications

Application	Specification
Gear Backlash001-.013" (.025-.330 mm)
Gear-to-Body Clearance	⊙ .001-.004" (.025-.101 mm)
Reg. Valve-to-Bore Clearance	⊙ .0020-.0035" (.050-.089 mm)
Reg. Valve Spring Tension	9.3-10.5 lbs. @ 1.46" (41-47 N @ 37.08 mm)
Free Length	2.57-2.69" (65.27-68.32 mm)

⊙ — Wear limit is .005" (.13 mm).




Fig. 9 Engine Oiling System

General Motors V8 Engines

6.0 LITER V8 (Cont.) ENGINE SPECIFICATIONS

GENERAL SPECIFICATIONS

Engine	HP at RPM	Torque (Ft. Lbs. at RPM)	Compr. Ratio	Bore		Stroke		Displ.	
				In.	mm	In.	mm	Cu. Ins.	cc
6.0L (368")	140@3800	265@1400	8.2:1	3.8	96.52	4.06	103.12	368	6000

VALVES

Engine & Valve	Head Diam. In. (mm)	Face Angle	Seat Angle	Seat Width In. (mm)	Stem Diameter In. (mm)	Stem Clearance In. (mm)	Valve Lift In. (mm)
6.0L (368") Int.	1.75 (44.45)	44°	45°	.047-.063 (1.19-1.60)	.3413-.3420 (8.67-8.69)	⓪.0010-.0027 (.025-.068)	.457 (11.61)
Exh.	1.50 (38.10)	44°	45°	.047-.063 (1.19-1.60)	.3413-.3420 (8.67-8.69)	⓪.0010-.0027 (.025-.068)	.473 (12.01)

⓪ — Wear limit .005" (.13 mm)

PISTONS, PINS, RINGS

Engine	PISTONS		PINS		RINGS		
	Clearance In. (mm)	Piston Fit In. (mm)	Rod Fit In. (mm)	Rings	End Gap In. (mm)	Side Clearance In. (mm)	
6.0L (368")	⓪.0006-.0014 (.0015-.035)	.0002-.0004 (.005-.010)	Press Fit	1 & 2 3	.013-.023 (.33-.58) .015-.055" (.38-1.40)	.0017-.0040 (.043-.101) NONE	

⓪ — Measure at top of skirt. Clearance at bottom of skirt is .0014" (.035 mm)

CRANKSHAFT MAIN & CONNECTING ROD BEARINGS

Engine	MAIN BEARINGS				CONNECTING ROD BEARINGS		
	Journal Diam. In. (mm)	Clearance In. (mm)	Thrust Bearing	Crankshaft End Play In. (mm)	Journal Diam. In. (mm)	Clearance In. (mm)	Side Play In. (mm)
6.0L (368")	3.25 (82.55)	⓪.0005-.0026 (.013-.066)	No. 3	⓪.002-.012 (.05-.31)	2.50 (63.50)	⓪.0005-.0028 (.013-.071)	.008-.020 (.20-.51)

⓪ — Wear limit .0045" (.11 mm).

ⓑ — Wear limit .015" (.38 mm).

ⓒ — Wear limit .0035" (.09 mm).

CAMSHAFT

Engine	Journal Diam. In. (mm)	Clearance In. (mm)	Lobe Lift In. (mm)
6.0L (368") Int.0010-.0022 (.025-.056)	.266 (6.75)
Exh.			.275 (6.99)

VALVE SPRINGS

Engine	Free Length In. (mm)	PRESSURE Lbs. @ In. (N @ mm)	
		Valve Closed	Valve Open
6.0L (368") Int.	2.25 (57.15)	60-65@1.946 (267-289@49.5)	155-165@1.495 (689-733@38)
Exh.	2.25 (57.15)	60-65@1.946 (267-289@49.5)	155-165@1.495 (689-733@38)

6.0 LITER V8 (Cont.)

ENGINE SPECIFICATIONS (Cont.)

VALVE TIMING				
Engine	INTAKE		EXHAUST	
	Open (BTDC)	Close (ABDC)	Open (BBDC)	Close (ATDC)
6.0L (368")	21°	111°	73°	55°

TIGHTENING SPECIFICATIONS	
Application	Ft. Lbs. (N·m)
Camshaft Sprocket Bolt	18 (25)
Connecting Rod Cap Nuts	40 (55)
Cylinder Head Bolts (Special—Oiled)	95 (130)
Exhaust Manifold	
Long Bolts	35 (48)
Short Bolts	12 (16)
Flywheel-to-Converter	30 (40)
Flywheel-to-Crankshaft	75 (103)
Intake Manifold Bolts	30 (40)
Fuel Pump Eccentric Bolts	35 (48)
Main Bearing Cap Bolts	90 (125)
Rocker Arm Support Bolt	70 (96)
Transmission Housing-to-Block	35 (48)
Water Pump	7 (10)