

Alternators & Regulators

HITACHI ALTERNATORS

Datsun (With IC Regulator)
LUV
Subaru

DESCRIPTION

Hitachi alternators are conventional 3 phase, self rectifying type alternators. Six diodes (3 positive and 3 negative) are used to rectify current.

APPLICATION

Model	Hitachi Type No.
Datsun	
B210 & F10	
W/O Air Conditioning	LR150-36
W/Air Conditioning	LR160-46
200SX & 510	
W/O Air Conditioning	LR150-35
510	
W/Air Conditioning	LR160-47
620 Pickup	
W/O Air Conditioning	LR135-44
W/Air Conditioning	LR138-01
280Z & 810	LR160-42
LUV	LT135-30
Subaru	LT150-21

SPECIFICATIONS

Output@2500 Alternator RPM

Alternator	Amps	Volts
LT135-30	28	14
LR135-44	27.5	14
LR138-01	30	14
LT150-21	40	14
LR150-35	40	14
LR150-36	40	14
LR160-42	⓪60	14
LR160-46	45	14
LR160-47	45	14

⓪ — Output @ 500 RPM.

Alternator	Nominal Output Amps	Volts
LT135-30	35	12
LR135-44	35	12
LR138-01	38	12
LT150-21	50	12
LR150-35	50	12
LR150-36	50	12
LR160-42	60	12
LR160-46	60	12
LR160-47	60	12

TESTING

NOTE — Some testing is described as part of Overhaul procedure in this article. The following testing is performed with alternator on the vehicle.

ALTERNATOR SPEED TEST

Datsun Models — Ensure battery has a full charge, then connect a 30-volt voltmeter as shown in illustration, and test as follows:

- 1) Detach connectors at alternator. Connect a test probe from voltmeter positive terminal to "N" or "BAT" terminal. Connect




Fig. 2 Alternator Testing Connections for Datsun




Fig. 1 Disassembled View of Typical Hitachi Alternator

HITACHI ALTERNATORS (Cont.)

other test probe to ground. Check that voltmeter registers battery voltage.

2) Turn on headlights to high beam. Start engine and increase speed to approximately 1000 RPM and observe voltmeter. If voltmeter registers below 12.5 volts, alternator is defective. If above 12.5 volts, alternator is good.

Subaru Models – 1) Connect a voltmeter and leads to battery as shown in Fig. 3. Operate the alternator and turn off the switch "SW" when alternator speed reaches approximately 800 RPM. Increase speed in small increments while watching voltmeter deflection and read alternator speed when at 14 volts. Speed should be approximately 1000 RPM.

2) Make test connections using a 30-50 ampere variable resistor, battery, ammeter, and voltmeter as shown in Fig. 4. Operate alternator with switch "SW-1" closed. When alternator speed reaches approximately 800 RPM, set the variable resistor to maximum and turn on switch "SW-2". Increase alternator speed while maintaining a constant 14 volts by adjusting resistance. Read current at 2500 RPM and 5000 RPM. Readings should be 37-43 amperes at 2500 RPM and 48-54 at 5000 RPM.




Fig. 3 Alternator Testing Connections for Subaru

RESISTANCE & CONTINUITY TESTING

All Models – 1) Measure resistance, using an ohmmeter, across "F" and "E" terminals for rotor coil resistance. Rotor coil circuit is normal if resistance is 4-5 ohms. If resistance is high, there is poor contact between brushes and commutator. If no continuity exists between "F" and "E" terminals, there is either an open rotor coil circuit, brush sticking or a broken lead wire. If resistance is low, it indicates a rotor coil layer short or grounded circuit.

2) **NOTE** – The following test will not indicate a open state of the diodes. Tester will indicate a continuity regardless of diode conditions if tester leads are connected to the terminals with polarities reversed. Connect positive lead of tester to alternator "N" terminal and tester negative lead to alternator "A" terminal. If continuity is observed on the tester, there exists one or more shorted positive diodes.

3) Next, connect tester positive lead to alternator "E" terminal and tester negative lead to alternator "N" terminal. If continuity is present, it indicates that one or more of the negative diodes are shorted.




Fig. 4 Alternator Test Connections for Subaru

INTEGRATED CIRCUIT (IC) REGULATOR

Except for LUV and Subaru installations, an integrated circuit (IC) voltage regulator is used. This unit is soldered to the brush assembly mounted inside the alternator.

Testing – 1) Remove brush assembly and with suitable tester, connect wiring as shown in Fig. 6. If V-1 voltage is not within 10-13 volts, charge or replace battery as necessary. Disconnect lead at terminal "S" and check voltage between terminals "F" and "E". If less than 2.0 volts, regulator is functioning properly.




Fig. 5 Front and Rear Views of IC Regulator (Datsun)

2) Measure total voltage (V-3) of batteries 1 and 2. If not within 20-26 volts, recharge or replace. Gradually decrease variable resistance (Rv) from 300 ohms and check voltage (V-2) between terminals "E" and "F". At some point, V-2 should increase to equal V-1 measured in step 1). If no V-2 variation occurs as described, regulator is defective.

3) Measure voltage (V-4) between center tap of variable resistor (Rv) and terminal "E". With resistance set as in previous step, voltage should be 14.7 ± .5 volts at 68°F (20°C). At ex-

HITACHI ALTERNATORS (Cont.)

tremely high case temperatures, voltage may be 1 volt lower, while at extremely cold temperatures, voltage may be 1 volt higher.

4) Remove test lead from terminal "S" and connect to terminal "B". Repeat steps 2) and 3) and check for voltage (V-4) .5-2.0 volts higher than in step 3). If testing specifications are not met, it will be necessary to replace the IC regulator/brush assembly.




Fig. 6 Regulator Test Arrangement

OVERHAUL

DISASSEMBLY

1) Remove nut and take out pulley, fan, and washers. Pull out spacer. Remove screws securing brush holder and brush holder cover. Withdraw brush and brush holder. **NOTE** - Leave "N" lead wire connected to stator coil lead.

2) Unscrew through bolts and separate front and rear housings. Remove three set screws from bearing retainer and separate rotor from front cover. Pull rear bearing from rotor assembly, if replacement is necessary.

3) Remove diode cover and disconnect stator coil lead wire from diode terminal, using a soldering iron. Remove the diode assembly by unscrewing the terminal nut and diode-setting nuts. Remove stator from rear cover.

INSPECTION & REPAIR

Rotor - Apply tester probes to slip rings of rotor. If ohm reading is within specifications, rotor conduction is satisfactory. If not, a disconnection of field coil may exist. Next, apply probes to slip ring and rotor core, to check ground. If conduction exists, replace rotor assembly.

Stator - The stator is normal when there is conduction between individual stator coil terminals. When there is no conduction between terminals, cable is broken; replace stator assembly. If each lead wire of stator coil (including neutral wire) is not conductive with stator core, condition is satisfactory. If conduction exists, stator is grounded and must be replaced.

Diodes - 1) Perform a conduction test on all diodes, in both directions, using an ohmmeter. Test the conduction between each terminal and plate. Diode installed on "+" plate is a positive diode which allows current to flow from terminal to "+" plate only; current does not flow from "+" plate to the




Fig. 7 Rotor Field Coil Conduction Test

terminal. A diode installed on the "-" plate is a negative diode and allows current to flow from the "-" plate to the terminal only; current does not flow from the terminal to the "-" plate.

2) If current flows in both directions, the diode is short-circuited. If current does not flow in either direction, the diode is open. If any diode is defective, replace the entire diode assembly (individual diodes are not serviceable).

Brushes & Brush Springs - Inspect brushes for freedom of movement in holder. Clean brush holder if necessary. Check brushes for cracks and wear; replace if beyond limits (.28" or 7.0 mm for LT135-30, LT150-21 and LR160-42; .30" or 7.5 mm for all others). Check brush springs for corrosion, damage and proper tension (9-12.2 oz. with .08" or 2 mm protrusion from holder). Test brush holder to assure that no continuity exists between holders; replace if required.




Fig. 8 Brush Assembly with Wear Indicators

REASSEMBLY

Reinstall diode assembly and stator to rear cover. Connect lead wires of stator coil to terminals of diode assembly.

NOTE - Solder quickly to avoid damage to diodes. Reinstall diode cover. Reinstall rotor to front cover. Place assembly in vise and replace pulley and components. Insert and tighten housing through bolts. Assemble brushes to brush holder and insert holder into alternator. Perform, as previously described.