

300D DIESEL 5 CYLINDER

ENGINE CODING

ENGINE IDENTIFICATION

Engine identification number is stamped on left side of cylinder block. First six digits of this number are used for engine identification purposes.

Application	Chassis Type	Engine Code
300D	123.130	617.912

NOTE — If vehicle is equipped with air conditioning, it is not necessary to disconnect refrigerant hoses. Only detach compressor from its mounting and position compressor and hoses out of way.

ENGINE & CYLINDER HEAD

ENGINE

NOTE — The hood no longer has to be removed, to remove the engine. The hood can be opened to a 90° position and held in place by a locking mechanism located on the left hinge.

Removal — 1) Disconnect battery ground cable. Drain cooling system and remove engine oil cooler lines. Remove radiator guard and radiator, disconnect heater hoses.

2) Remove air intake silencer. Disconnect fuel hoses and vacuum hose to power brake. On models with power steering and level control, disconnect and plug oil lines.

3) Disconnect oil pressure gauge hose. Disconnect idle control cable and stop-start cable. Remove accelerator linkage.

4) Disconnect ground cable from engine to chassis and all other electrical leads. Disconnect gearshift linkage and exhaust pipe at manifold.

5) Loosen steering relay arm and move downward together with center tie rod and steering shock absorber. Disconnect hydraulic line from clutch slave cylinder.

6) Disconnect oil cooler lines between transmission and oil cooler.

7) Disconnect exhaust pipe support bracket at transmission. Loosen clamp on exhaust pipe and push downward.

8) Attach suitable lifting sling to engine. Mark position of rear engine crossmember in relation to chassis base panel, disconnect rubber mount at transmission and remove crossmember.

9) Disconnect speedometer cable. Disconnect propeller shaft and shaft plate from transmission. Push propeller shaft to rear after loosening clamping nut.

10) Disconnect plug from automatic transmission.

11) Remove bolts at both front engine mounts. Remove front limit stop. Loosen one screw and move power steering reservoir to one side.

12) Lift out engine at a 45° angle. To install, reverse removal procedures.

INTAKE & EXHAUST MANIFOLD

Intake Manifold — Remove air cleaner. Disconnect throttle linkage and bowden cable for idling control on throttle duct.

Unscrew vacuum line. Remove attaching nuts and intake manifold from cylinder head.

Exhaust Manifold — Disconnect exhaust pipe from manifold. Remove attaching nuts and lift off exhaust manifold.

CYLINDER HEAD

Removal — 1) Drain cooling system. Disconnect all water hoses attached to cylinder head. Remove vent line, air cleaner and rocker cover.

2) Disconnect vacuum line, injection lines and leakage oil line. Loosen fuel filter screws and move filter out of the way. Remove exhaust pipe from manifold.

3) Disconnect cable to glow plugs and heat sensor from water thermometer. Rotate camshaft until there is no load on rocker arms, and remove rocker arm assemblies (rear assembly for three cylinders; front assembly for two).

4) Remove top chain guide. Unscrew camshaft sprocket screw. Remove chain tensioner and camshaft sprocket.

5) Loosen and remove head bolts, working from outside toward inside of head. Remove four socket screws at front of head. Lift off head and gasket.




Fig. 1 Cylinder Head Tightening Sequence

Installation — 1) Rotate engine until No. 1 piston is at TDC of compression stroke. Install head gasket and cylinder head, torque head bolts to specifications (see illustration).

2) Install four socket screws in front of head. Connect ground lead for glow plugs to screw under main fuel filter. Insert Woodruff key in camshaft. Place shim on camshaft so mark aligns with mark of first camshaft bearing support.

3) Install camshaft sprocket and chain with tension on driving side of chain, using care not to move camshaft or crankshaft.

4) Check endplay of camshaft. See *Camshaft Bearing Replacement*. Install upper chain guide. Using a new seal, install chain tensioner filled with oil.

5) Install rocker arm assemblies (rear assembly for three cylinders; front for two). Rotate camshaft so there is no load on rocker arms while tightening. Adjust valve clearance with engine cold. See *Valve Clearance Adjustment*.

6) Reinstall remaining components in reverse of removal. Run engine until it has reached 176°F (80°C) and retighten cylinder head bolts, check tappet clearance. (Loosen each head bolt slightly, a bolt at a time, then retorque to specifications).

300D DIESEL 5 CYLINDER (Cont.)

VALVES

VALVE ARRANGEMENT

E-I-I-E-E-I-I-E-E-I (front to rear).

VALVE GUIDE SERVICING

- 1) Check valve guide bores and ensure they are not less than .3937" (10.00 mm) or larger than .3947" (10.025 mm). Remove all carbon before measuring guides.
- 2) Using a suitable drift, drive intake guide out toward top of head and exhaust guide toward combustion chamber.
- 3) Press in new guides from combustion side until specified distance is achieved. See Fig. 2. Check guide bores for free movement of valves, and remove any tight spots.




Fig. 2 Installed View of Valve Assemblies

- 4) Valve guides are available in standard and one oversize (coded red). An interference fit of .0004-.0015" (.010-.040 mm) is used. If guide does not meet specifications, install oversize part. Note that intake guides are 2.40" (60.96 mm) long and exhaust guides are 1.95" (49.53 mm) long.

Valve Guide Specification

Application	Guide O.D. In. (mm)	Cyl. Head Bore In. (mm)
Standard	.5522-.5527 (14.03-14.04)	.5511-.5518 (14.00-14.02)
Oversize (Red)	.5601-.5605 (14.23-14.24)	.5590-.5597 (14.20-14.22)

VALVE STEM OIL SEALS

- 1) Using a spring compressor, unscrew cap nut and lock nut from valve stem. Remove valve collar and spring.
- 2) Prepare a tool for removing oil seal. See Fig. 3. Using oil seal tool, lever oil seal off guide and stem.
- 3) Place plastic sleeve over threaded end of valve stem. Slide new oil seal in place, using oil seal tool. Install spring and collar. Screw lock nut and cap nut on end of valve stem.




Fig. 3 Valve Stem Oil Seal Tool

Remove rocker arms. Using a spring compressor, unscrew cap nut and lock nut. Remove valve spring collar and lift out spring. Check spring for wear or fatigue, replace as necessary. To install, reverse removal procedures with close wound coils next to cylinder head.

ROCKER ARM ASSEMBLIES

NOTE — Rocker arms are mounted in two groups. Rear group serves three cylinders; front group, two cylinders.

- 1) Remove air cleaner and tappet cover. Loosen rocker arm bracket bolts, rotate camshaft so there is no load on rocker arms being removed.




Fig. 4 Detailed View of Front Rocker Arm Assembly

- 2) Slide rocker arm brackets, rocker arms tightening clamp and spacer off of shaft. Inspect all parts for wear. Replace shaft, rocker bushing or rocker bracket if necessary. To install, reverse removal procedures.

VALVE CLEARANCE ADJUSTMENT

- 1) Adjust valves according to firing sequence (1-2-4-5-3). Rotate crankshaft until piston of valves to be adjusted is at

300D DIESEL 5 CYLINDER (Cont.)

TDC of compression stroke. Measure clearance between slide surface of rocker arm and cam base circle of camshaft. Cam lobe should be vertical to cam base circle.

2) To adjust, fit holding wrench on valve retainer. Loosen cap nut while holding hex nut. Adjust clearance by turning cap nut. After adjustment, lock the cap nut by tightening hex nut against it. Recheck valve clearance:

Valve Clearance Specifications

Valve	Inches(mm)
Intake	
Cold	⓪ .0039 (.10)
Warm	⓪ .0059 (.15)
Exhaust	
Cold	.012 (.30)
Warm	.014 (.35)

⓪ — Add .002" (.05 mm) additional clearance if ambient temperatures are below -4°F (-20°C) for extended periods.

PISTONS, PINS & RINGS

OIL PAN

NOTE — Two studs are provided at the front to make it easier to center oil pan on crankcase. Oil seal bore on oil pan is also machined to provide a common flat surface.

1) Remove oil pan cover, if equipped. Drain engine oil. Remove dipstick and tube. Detach cover plate from clutch housing. Remove oil pan bolts.

2) Loosen steering shock absorber and drag link and turn to one side. Unscrew drag link on intermediate steering and turn aside. Remove oil pan.

PISTON & ROD ASSEMBLY

Removal — 1) Remove cylinder head and oil pan. Unscrew connecting rod nuts. Tap rod bolts with a plastic mallet to loosen rod on crankshaft. Push piston and connecting rod assembly out top of cylinder block.

2) Remove piston pin circlips. Heat piston to 104-140° (40-60°C) and press out piston pins.

Installation — 1) Heat piston and reinstall wrist pin and circlips. Piston and wrist pin must be matched.

2) Install connecting rod and cap so cylinder numbers face left side of engine and arrow on piston crown faces forward.

NOTE — Piston must be installed facing proper direction or damage to the engine will occur.

3) Connecting rod bolts are of a special design, having an expansion shank which is used to measure bolt stress. If, after several tightenings, the expansion section of the bolt has reached a minimum diameter of .2834" (7.2 mm), the bolt must be replaced. When new, this shank portion should be .3307" (8.4 mm). When replacing, drive out old bolts and insert new ones into same spline pattern in rod cap. **NOTE** —

First tightening of NEW bolts is to 50.6 ft. lbs. (7.0 mkg); subsequent tightenings should be to 36 ft. lbs. (5.0 mkg).

4) Rotate crankshaft until piston to be measured is at TDC. Measure distance from top of cylinder block to piston crown. Piston must not protrude more than .035" (.90 mm), nor less than .004" (.10 mm) above block surface.

FITTING PISTONS

Measure piston and cylinder diameters to determine running clearance. Piston diameter is measured at 90° to piston pin bore near bottom of piston skirt. There are two compression rings and one oil ring. Install compression rings with marking, "top" or "F", and oil ring with marking, "GOE" or "F", facing upward.

CRANKSHAFT MAIN & CONNECTING ROD BEARINGS

MAIN BEARING SERVICE

NOTE — The 300D crankshaft has four counterweights and six main bearings.

Measure main bearing and connecting rod journals for out-of-round and taper. Out-of-round must not exceed .0002-.0004" (.005-.010 mm) and taper must not exceed .0004-.0006" (.010-.015 mm). Select proper undersize, if required, and grind crankshaft to following diameters:

Crankshaft Journal Diameters

Application	Main In. (mm)	Con. Rod In. (mm)
Standard	2.7541-2.7545 (69.95-69.96)	2.0454-2.0458 (51.95-51.96)
1st Undersize	2.7442-2.7446 (69.70-69.71)	2.0356-2.0360 (51.70-51.71)
2nd Undersize	2.7344-2.7348 (69.45-69.46)	2.0257-2.0261 (51.45-51.46)
3rd Undersize	2.7246-2.7249 (69.20-69.21)	2.0159-2.0163 (51.20-51.21)
4th Undersize	2.7147-2.7151 (68.95-68.96)	2.0060-2.0064 (50.95-50.96)




Fig. 5 Detail of Third Main Bearing Cap

300D DIESEL 5 CYLINDER (Cont.)

THRUST BEARING ALIGNMENT

Third main bearing cap has pin located thrust washers to adjust crankshaft end play. Measure end play and install thrust washer(s) required to give proper end play. Measure pin protrusion from main bearing cap to ensure it does not exceed .062" (1.57 mm) as illustrated (See Fig. 5). Standard and oversize thrust washers are available in the following sizes:

Thrust Washer Thicknesses

Application	In. (mm)
Standard	.078 (1.98)
1st Oversize	.080 (2.03)
2nd Oversize	.082 (2.08)
3rd Oversize	.084 (2.13)
4th Oversize	.086 (2.18)
5th Oversize	.088 (2.23)
6th Oversize	.090 (2.28)
7th Oversize	.092 (2.33)

REAR MAIN BEARING OIL SEAL SERVICE

1) With oil pan and crankshaft removed, insert fabric oil seal in groove in crankcase behind rear main bearing. Cut seal at parting face so that it protrudes slightly above parting face.

2) Install other half in oil pan groove, using tallow on seal halves. Reinstall crankshaft and oil pan. Rotate crankshaft to check tightness of seal. If seal is too tight, remove oil pan and crankshaft and roll down high spots with a hammer handle.

FRONT OIL SEAL

Removal - 1) Remove attaching bolt and crankshaft pulley. Attach a suitable puller and remove counterweight. Remove oil pan.

2) Press out seal ring and remove spacer from crankshaft.




Fig. 6 Sectional View of Crankshaft Front Oil Seal

Installation - 1) The 300D Diesel features a radial seal ring with a 360° shoulder and an oil pan with a machined oil seal bore area. Always use the 360° shouldered seal ring.

2) Lubricate seal lip with oil. Slide oil thrower ring onto crankshaft. Slip radial seal ring onto installation sleeve (130 589 00 61 00) and press seal in until it touches the crankcase face. Install a new hard-chromium plated spacer washer (615 031 01 51) on crankshaft.

3) Place oil pan on two centering studs at front of crankcase and complete installation, by installing components in reverse of removal procedures.

4) When installing vibration damper, use the collar screw (000 961 018 019) with three conical spring washers (127 993 00 26) instead of the collar screw with conical sleeve, used on the 300D models through Chassis No. 000984. See Fig. 6.

5) To install collar screw with spring washers on vehicles equipped with the old vibration damper and conical sleeve, either install a new vibration damper (617 030 01 03) or bore out old damper to accept spring washers. See Fig. 7 for dimensions when reboring damper.

Vibration Damper Boring Dimensions

Location	Inches (mm)
Diameter of Bore	1.922-1.938 (48.8-49.2)
Depth of Bore	.55 (14.0)




Fig. 7 Instructions for Reboring Vibration Damper

CAMSHAFT

CAMSHAFT

1) Remove camshaft sprocket and rocker arm assemblies. See Fig. 8. Disconnect external camshaft oiling tube.




Fig. 8 Rocker Arm Assemblies and Camshaft Bearings

300D DIESEL 5 CYLINDER (Cont.)

2) Remove camshaft bearing supports. Slide bearing supports off of camshaft. To install, reverse removal procedures.

CAMSHAFT BEARING REPLACEMENT

1) Inspect camshaft bearing journals for wear. If worn, grind bearing journals and fit undersize bearings.




Fig. 9 Detailed View of Camshaft




Fig. 10 Measuring Camshaft End Play

2) Bearing on No. 1 journal controls camshaft end play. Width of journal is 1.3385-1.3401" (34.0-34.03 mm). Place bearing on camshaft and install retaining ring. Using a feeler gauge, measure clearance between camshaft flange and bearing (see illustration). Lap bearing to proper fit. The following table lists camshaft bearing journal diameters for standard and undersize bearings:

Camshaft Journal Diameters

Application	Journal No. 1 In. (mm)	Journal No. 2, 3, & 4 In. (mm)
Standard	1.3763-1.3769 (34.96-34.97)	1.8290-1.8297 (46.46-46.47)
Intermediate (Grey)	1.3723-1.3730 (34.86-34.87)	1.8251-1.8257 (46.36-46.37)
1st Undersize (Red)	1.3664-1.3671 (34.71-34.72)	1.8192-1.8198 (46.21-46.22)

TIMING CHAIN REPLACEMENT

1) Remove rocker cover and glow plugs so that engine turns easily. Remove chain tensioner and rocker arm brackets.




Fig. 11 Timing Chain & Related Components

NOTE - Removal of rocker arm brackets is not imperative, but is recommended in order to avoid damage to valves or pistons, if, while turning engine, chain jumps over camshaft sprocket.

2) Grind off pins on a link of old chain and remove link. Using a master link, connect new chain to old chain on driving side of old chain.

NOTE - Install master link facing camshaft side of chain with spring lock closed end facing direction of rotation (see illustration).

3) Slowly turn engine in direction of rotation, feeding new chain in and old chain out uniformly. After chain threading is complete join ends of new chain with master link and make sure spring lock closed end is facing direction of rotation. Check that valve timing is correct. See Valve Timing. Reverse removal procedures for remaining components.

VALVE TIMING

1) Rotate No. 1 piston to TDC of compression stroke. Align camshaft timing mark with mark on No. 1 camshaft bearing support bracket (see illustration). Install camshaft sprocket.

2) If correct valve timing is not achieved when camshaft sprocket is installed, offset Woodruff keys are available to make timing corrections, see following table:

Offset Woodruff Keys

Offset	Crankshaft Correction
.0275" (.7 mm)	4°
.0354" (.9 mm)	6 1/2°
.0433" (1.1 mm)	8°
.0511" (1.3 mm)	10°

300D DIESEL 5 CYLINDER (Cont.)




Fig. 12 Camshaft Timing Mark Locations

ENGINE OILING

ENGINE OILING SYSTEM

Engine lubrication is provided by a gear type oil pump, which force feeds oil through an oil filter to oil gallery. From oil gallery, oil flows to main and connecting rod bearings. Pistons, wrist pins and connecting rod bushings are splash lubricated.

A vertical oil passage from oil gallery has a transverse passage which supplies oil to intermediate sprocket shaft and bearings. Another oil passage supplies oil to oil pump drive shaft and helical gear. Vertical passage also supplies oil to No. 1 camshaft bearing. An external oil tube attached to No. 1 camshaft bearing support lubricates other camshaft bearings and rocker arms.

Crankcase Capacity – 7.0 quarts including filter.

Oil Filter – Full-flow. Thermostat opens to oil cooler at 203°F (95°C). Clean main element every 3,000 miles. Replace by-pass element every 3,000 miles.

Normal Oil Pressure – 7.1 psi (.5 kg/cm²) at 700-800 RPM; 42 psi (3 kg/cm²) at 3000 RPM.

Pressure Regulator Valve – Non-adjustable.

OIL PUMP

Removal – Remove oil pan. Remove two attaching screws and lift out pump.

NOTE – Beginning at Chassis No. 31200 (Engine No. 012967), the yellow lock screw (M8) securing the thrust bushing in the oil pump drive was replaced with a black lock screw (M10). To improve the secure positioning of thrust bushing, the black screw (615 990 01 15) should be substituted at the earliest possible opportunity. Tighten lock screw to 11-19 ft. lbs. (1.5-2.5 mkg). See Fig. 13.

Disassembly – 1) Remove oil strainer. Unscrew lower pump body, and remove pump gears and shafts. Check clearances between gear-to-body and gear-to-cover.

2) If cast-in bushings in housing are worn, replace complete housing. Worn gears are replaced as an assembly. Assemble

upper and lower housing without a gasket. Install strainer with a new gasket. Check that pump turns freely.

NOTE – Beginning at Engine No. 027648, a new thrust bushing (615 180 00 44) with a thicker wall was adapted. The cover disc under the screw plug has been eliminated, and the "O" ring formerly located under the cover disc has been moved down onto the side of the thrust bushing. Parts are not interchangeable. Always use the black locking screw (615 990 01 15).

Installation – 1) Align drive shaft follower with helical gear and follower faces with respect to one another.

2) Insert oil pump with bracket and tighten mounting screws. Install oil pan.




Fig. 13 Location of Thrust Bushing Lock Screw

ENGINE COOLING

Thermostat – Opens at 78-82°F (26-28°C).




Fig. 14 Thermostat Housing Vent Screw

300D DIESEL 5 CYLINDER (Cont.)

Cooling System Capacity – 11.6 quarts.

NOTE – When filling engine with water, vent screw on thermostat housing must be removed until water flows from it. See Fig. 14.

WATER PUMP

Removal – 1) Drain cooling system below level of pump. Loosen hose clamps on top radiator hose. Remove radiator mounting bolts and push radiator forward.

2) Remove fan from drive pulley. Loosen nuts and adjusters on generator enough so fan belt may be removed. Unscrew and remove venting line between pump and cylinder head.

3) Water pump is a maintenance free type. When installing pump, check hub-to-flange and impeller-to-flange distance. See Fig. 15.




Fig. 15 Sectional View of Water Pump

ENGINE SPECIFICATIONS

GENERAL SPECIFICATIONS										
Year	Displ.		Carburetor	HP at RPM	Torque (Ft. Lbs. at RPM)	Compr. Ratio	Bore		Stroke	
	cu. ins.	cc					in.	mm	in.	mm
1978	183.4	3005	Fuel Inj.	77 @ 4000	115 @ 2400	21.0-1	3.58	91	3.64	92.4

VALVES							
Engine & Valve	Head Diam. In. (mm)	Face Angle	Seat Angle	Seat Width In. (mm)	Stem Diameter In. (mm)	Stem Clearance In. (mm)	Valve Lift In. (mm)
3005 cc Intake	1.563-1.571 (39.70-39.90)	30°	30°	.051-.063 (1.3-1.6)	.3906-.3913 (9.92-9.94)	.0030 (.075)
Exhaust	1.343-1.350 (34.10-34.30)	30°	30°	.098-.114 (2.5-2.9)	.3906-.3913 (9.92-9.94)	.0030 (.075)

VALVE SPRINGS			
Engine	Free Length In. (mm)	PRESSURE Lbs. @ In. (kg @ mm)	
		Valve Closed	Valve Open
3005 cc	1.988 (50.5)	58.2 @ 1.512 (26.4 @ 38.41)	116.8 @ 1.177 (53.0 @ 29.9)

CAMSHAFT ①			
Engine	Journal Diam. In. (mm)	Clearance In. (mm)	Lobe Lift In. (mm)
3005 cc No. 1	1.3763-1.3769 (34.96-34.97)	.0010-.0026 (.025-.066)
No. 2, 3, & 4	1.8290-1.8297 (46.46-46.47)	.0010-.0026 (.025-.066)

① – End play is .003-.006" (.070-.149)

300D DIESEL 5 CYLINDER (Cont.)

ENGINE SPECIFICATIONS (Cont.)

PISTONS, PINS, RINGS						
Engine	PISTONS		PINS		RINGS	
	Clearance In. (mm)	Piston Fit In. (mm)	Rod Fit In. (mm)	Rings	End Gap In. (mm)	Side Clearance In. (mm)
3005 cc	.0007-.0015 (.018-.038)	①	Push Fit	No. 1	.0079-.0138 (.20-.35)	.004-.005 (.100-.132)
				No. 2	.0079-.0138 (.20-.35)	.003-.004 (.070-.102)
				No. 3	.0098-.0157 (.25-.40)	.001-.002 (.030-.062)

① — Interference fit. See *Piston & Rod Assembly* in this article.

CRANKSHAFT MAIN & CONNECTING ROD BEARINGS							
Engine	MAIN BEARINGS				CONNECTING ROD BEARINGS		
	Journal Diam. In. (mm)	Clearance In. (mm)	Thrust Bearing	Crankshaft End Play In. (mm)	Journal Diam. In. (mm)	Clearance In. (mm)	Side Play In. (mm)
3005 cc	2.7541-2.7545 (69.95-69.96)	.0012-.0029 (.031-.073)	No. 3	.0039-.0090 (.10-.22)	2.0454-2.0458 (51.95-51.96)	.0012-.0029 (.031-.073)	.005-.010 (.12-.26)

VALVE TIMING				
Engine	INTAKE		EXHAUST	
	Open (ATDC)	Close (ALDC)	Open (BLDC)	Close (BTDC)
3005 cc	13.5°	15.5°	19°	17°

TIGHTENING SPECIFICATIONS

Application	Ft. Lbs. (mkg)
Cylinder Head	
Step 1	29 (4)
Step 2	43 (6)
Step 3①	65 (9)
Camshaft Bearing Caps	18 (2.5)
Glow Plugs	36 (5)
Prechamber in Cyl. Head	108-130 (15-18)
Connecting Rod Caps	29-36 (4-5)
Main Bearing Caps	65 (9)
Crankshaft Front Hex Bolt	195-239 (27-33)
Oil Pan Bolts	8 (1.1)
Oil Pump Lock Screw (M10)	11-19 (1.5-2.5)
Oil Pump Screw Plug	32-40 (4.5-5.5)
Camshaft Sprocket Bolt	58 (8)

① — After engine is warm, recheck for 65 ft. lbs. (9 mkg) torque.