

## RABBIT (GASOLINE), SCIROCCO & DASHER 4 CYLINDER

### ENGINE CODING

#### ENGINE IDENTIFICATION

Engine identification number is stamped on left side of engine block near ignition distributor.

#### Engine Codes

Application	Code
Rabbit/Scirocco with Fuel Injection .....	EH
Rabbit with Carburetor .....	FX
Dasher	
Man. Trans. ....	YG, YK
Auto. Trans. ....	YH

### ENGINE, CYLINDER HEAD & MANIFOLDS

#### ENGINE

**NOTE** — On Rabbit and Scirocco models only, engine and transaxle must be removed as an assembly.

**Removal, Rabbit & Scirocco with Man. Trans.** — 1) Disconnect battery ground cable. Drain coolant and remove radiator with air ducts and fan. If equipped with A/C, remove compressor and condenser and set aside without disconnecting hoses.

2) On carburetor equipped cars, remove fuel hose. On fuel injection models, remove injectors from manifold tubes of intake distributor. Disconnect all fuel lines except injector lines from fuel distributor. Remove injection control unit, air ducting and air cleaner.

3) Disconnect electrical wiring from the following: Ignition coil, oil pressure switch, distributor, temperature sending unit, alternator, fuel injection, starter and transmission.

4) Disconnect coolant hoses, accelerator cable, speedometer cable and clutch cable. Remove engine/transaxle front mount. Remove right side headlight cap.

5) Disconnect axle drive shafts and support with wire. Disconnect exhaust pipe from manifold and remove exhaust pipe support. Remove transmission rear mount and ground strap from body to transmission. Remove gear shift linkage.

6) Attach hoist to mount, cast at rear of cylinder head and lower alternator mount in front of engine. Disconnect engine carrier from body and remove left transmission mount. Lift engine and transmission out of vehicle.

7) Using suitable wrench (US 4463), remove TDC sensor (part of analysis system) from clutch housing. To separate transaxle from engine, turn flywheel until mark on flywheel aligns with mark on clutch housing. Remove drive shaft flange cover plate. Then, remove engine-to-transaxle bolts.

**Installation** — To install engine/transaxle assembly, reverse removal procedure and note the following: When attaching

engine to transaxle, align recess (window) in flywheel level with drive shaft flange. Lift assembly into vehicle. Loosely install right engine mount bolt and loosely attach left transaxle mount to transaxle. Align assembly and loosely attach remaining mounts. Tighten mounts.

**NOTE** — Mounts must be properly aligned and free of tension before tightening.

**Removal, Rabbit & Scirocco with Auto. Trans.** — 1) Disconnect battery. Drain coolant and remove radiator with air ducts and fan. If equipped with A/C, remove compressor and condenser and set aside without disconnecting hoses. On fuel injection models, remove injectors from manifold tubes of intake distributor. Disconnect all fuel lines except injector lines from fuel distributor. Remove mixture control unit, air cleaner, and intake air duct. Disconnect fuel return line and electrical plug from regulator. Disconnect accelerator cable from throttle housing assembly and wiring plug from auxiliary air regulator.

2) On carburetor equipped models, remove air cleaner and ducting. Disconnect fuel tank-to-engine fuel hose from fuel pump. Remove accelerator cable bracket screws from carburetor. Do NOT change settings when removing bracket. On all models, disconnect all engine electrical wiring.

3) Disconnect speedometer cable. Disconnect selector lever cable at transaxle. Disconnect throttle cable ball socket from lever and unhook accelerator cable from lever. On Scirocco models, remove right side headlight cap.

4) Disconnect axle drive shafts and support with wire. Disconnect exhaust pipe at manifold flange. Remove engine/transaxle rear mount. Remove cover from engine end of clutch housing. Remove torque converter from drive plate.

5) Fit engine hoist to eyes on cylinder head and slightly raise engine. Remove alternator if necessary. Remove front and left transaxle mounts. Remove right engine mount. Engine is free for removal.

6) Separate engine and transaxle. Make sure drive plate pulls cleanly away from converter and does not move cover off support.

**Installation** — To install engine/transaxle assembly, reverse removal procedure and note the following: After lifting assembly into vehicle, loosely install right engine mount bolt and attach left transaxle mount to transaxle. Install all other components while assembly is aligned prior to tightening to final torque.

**NOTE** — Mounts must be properly aligned and free of tension before tightening.

**Removal, Dasher** — 1) Disconnect battery and, if equipped with A/C, remove battery from car. Drain oil. Remove air cleaner. Disconnect clutch operating lever then disengage cable housing from bracket on engine mount. Disconnect and plug fuel inlet hose.

2) Remove fuse block mounting screws and bend open wiring harness clip. Tie fuel hose, clutch cable and fuse block out of way. Disconnect heater control cable. Remove front engine mount and mount support.

## RABBIT (GASOLINE), SCIROCCO &amp; Dasher 4 CYLINDER (Cont.)

3) Disconnect coil and any engine electrical items that might hinder engine removal. Disconnect all wires from fuel injection components. If equipped with A/C, remove compressor and condenser and set aside without disconnecting hoses. Drain coolant. Remove radiator.

4) Work under vehicle and disconnect electrical wires from starter. Remove starter. Disconnect exhaust pipe at manifold. Remove converter bolts through hole left by starter removal. Remove lower bolts that mount engine to transaxle.

5) Attach engine hoist. Raise engine until assembly hits steering rack housing. Support transaxle. Remove upper bolts mounting engine to transaxle. Pry engine from transaxle. Remove intermediate plate. Make sure torque converter is supported.

**Installation** — To install engine, reverse removal procedure. Make sure all fluid levels are correct. Adjust any cables removed.

## CYLINDER HEAD &amp; MANIFOLDS

**Removal** — 1) On cars with carburetors, remove air cleaner and ducting. On fuel injection models, disconnect duct connecting throttle valve housing with mixture control unit. On all models, remove camshaft drive belt and drain engine coolant. If equipped with A.I.R. (California models), disconnect air lines from connections on exhaust manifold.

**CAUTION** — Never drain coolant while engine is hot. Doing so could cause engine block or cylinder head to warp.

2) Disconnect exhaust pipe. Remove nuts and bolts that hold exhaust manifold and intake manifold (air intake distributor) to head. Remove manifolds. Remove upper alternator bolt and adjusting bracket. Disconnect all coolant hoses and temperature gauge wire. Remove spark plugs.

3) Remove valve cover. Remove head bolts. Start at either end and work toward center. If head is stuck, insert block of wood in each outboard exhaust port and pry head free.

**Installation** — To install, reverse removal procedure and note the following: Make sure head gasket is positioned with "OBEN" mark facing up. Tighten head bolts in sequence and steps shown.

## Cylinder Head Tightening Steps

Application	Ft. Lbs. (mkg)
Step One .....	22 (3.0)
Step Two .....	43 (6.0)
Step Three .....	54 (7.5)

**NOTE** — Polygon (12 point) socket head bolts are set to final torque while cold and do not need to be retorqued when hot. Tighten in sequence to 54 ft. lbs. (7.5 mkg) plus an additional 1/4 turn.




Fig. 1 Cylinder Head Tightening Sequence (Loosen in Reverse Order)

## VALVES

## VALVE ARRANGEMENT

E-I-E-I-I-E-I-E (front to rear).

## VALVE GUIDE SERVICING

1) Clean valve guides before making measurements. To measure guide, attach a suitable mounting device with a dial gauge (VW689/1) to mounting surface of cylinder head. Insert a new valve until end of stem is flush with end of valve guide.

2) Rock valve head against dial indicator and check amount of rock recorded. Maximum allowable rock is .039" (1 mm) for intake valves and .051" (1.3 mm) for exhaust valves. Proper valve guide diameter is .315"-.316" (8.01-8.04 mm).

3) Use a press and suitable adaptor (10-206) to remove and install valve guides. To remove guides, press out from combustion chamber side of head.

4) Coat new valve guides with engine oil. Press new guides into cold head from camshaft side. Make sure shoulder of guide meets firmly with top of cylinder head. Ream guides to uniform inside diameter.

**CAUTION** — Do not use more than 1 ton pressure once guide shoulder is seated or shoulder may break.

## VALVE SPRINGS

**NOTE** — Although normal maintenance on valve system is performed with head removed, it is possible to replace stem seals, keepers, retainers or broken springs with cylinder head installed.

**Removal (Head Installed)** — With camshaft and tappets removed, turn crankshaft until piston of cylinder you are working on is at BDC. Apply steady air pressure of at least 85 psi through spark plug hole adapter to keep valves seated. Compress spring with suitable tool (VW 541) and remove valve keepers. Remove and replace damaged or worn parts.

**Removal (Head Removed)** — With camshaft and tappets removed, use suitable compressor (VW 541) to depress retainer and remove keepers. Take out retainer and springs.

**Installation** — Check springs on spring tester and inspect for cracks or distortion. Reverse removal procedure and note the following: Lower edge of valve spring retainer should be chamfered to prevent valve stem scoring. If necessary, grind a

## RABBIT (GASOLINE), SCIROCCO & DASHER 4 CYLINDER (Cont.)

chamfer using stone or other suitable tool. When installing the springs, make sure closely spaced coils of outer springs are against spring seats.

### VALVE STEM OIL SEALS

With tappet, adjuster pad, keepers, springs, and spring seats removed, extract valve stem oil seal. When installing new seal, first position protective plastic sleeve on valve stem, lubricate seal, and use a suitable mandrel (10-204) to push seal onto valve guide.

### VALVE CLEARANCE ADJUSTMENT

1) Adjust valves with engine at normal operating temperature. Clearance adjustments are to be checked and made according to firing sequence (1-3-4-2). Rotate crankshaft until No. 4 cylinder valves overlap, then measure valve clearances of No. 1 cylinder.

2) If adjustment is necessary, use special tools 10-208 (disc removal tool) and VW546 (tappet depressing tool) to remove and install adjusting discs. Rotate camshaft until cam lobes no longer rest on adjusting discs of cylinder to be adjusted. Turn tappet until notches are at 90° to camshaft. Insert tool VW546 and depress tappet. Using tool 10-208, grasp tappet disc and rotate it out from under camshaft.

3) Thickness is stamped on bottom side of discs. Using clearance measurement, determine thickness of adjusting disc necessary to bring valve clearances within specifications. Discs are available in .0019" (.05 mm) increments from .1181" (3.0 mm) to .1673" (4.25 mm). Reverse removal procedure to install proper disc. Repeat procedure as required for remaining valves.




Fig. 2 Assembled View of Valve and Camshaft

### Valve Clearance Specifications

Application	In. (mm)
Intake	
Hot .....	.008-.012 (.20-.30)
Cold .....	.006-.010 (.15-.25)
Exhaust	
Hot .....	.016-.020 (.40-.50)
Cold .....	.014-.018 (.35-.45)

**NOTE** — Cold settings are given for reference as initial settings to be used during cylinder head rework. Final adjustments are to be made with engine at normal operating temperature. After head repairs, recheck valve clearances after 600 miles.

### PISTONS, PINS & RINGS

#### OIL PAN

**Removal** — On Rabbit and Scirocco, drain oil, remove bolts and remove oil pan. On Dasher, support engine from above with support bar and threaded rod. Remove nuts holding engine mounts on subframe and bolts holding subframe to body. Pull subframe downward to separate engine mounts and body. Drain oil, remove mounting bolts and remove oil pan.

**Installation** — To install, reverse removal procedure. Make sure gasket surfaces are clean before installing new gaskets.

#### PISTON & ROD ASSEMBLY

**NOTE** — Piston and rod assemblies can be removed with engine in vehicle. Manufacturer recommends engine removal for extensive overhaul work.

**Removal** — Mark cylinder number on crown of each piston. If necessary, mark arrows pointing toward front of block on piston crowns. Remove rod cap bolts and force piston out top of cylinder. Use wooden hammer handle for this operation. Mark connecting rods and bearing caps for proper reinstallation.

**NOTE** — If a ridge at top of cylinder prevents piston removal, use a ridge reamer to cut down the ridge. DO NOT force piston out of cylinder.

**Installation** — Turn crankshaft so No. 1 journal is at BDC. Install piston connecting rod assembly until ring compressor contacts block. Use a wood handle to push piston into cylinder. Install No. 4 Piston and rod assembly. Ensure tabs on bearing halves engage notch in rod and cap. Install and tighten caps on rods 1 and 4. Turn crankshaft 180° and install No. 2 and 3 rod assemblies and rod caps.

#### PISTON PINS

**Removal** — Use needle-nosed pliers to remove pin circlips. Press out pin and remove piston from rod. For installation purposes, note direction piston is fitted to rod.

## RABBIT (GASOLINE), SCIROCCO &amp; DASHER 4 CYLINDER (Cont.)

**Installation** — 1) Check pin fit in each piston. Piston pin must be a thumb-push fit in piston. If correct fit is not obtained, replace both pin and piston.

2) Check pin fit in connecting rod. Wear limit is .0015" (.04 mm). Rebush connecting rod and hone bushing to obtain correct clearance.

## FITTING PISTONS

1) Measure cylinder at three points: .39" (10 mm) from top and bottom, and at center of bore. Take measurements in line with thrust face and also at 90° to thrust face. Cylinder wear limit is .0028" (.07 mm) beyond standard dimensions; if this is exceeded, rebore cylinder and install oversize pistons.

2) Measure pistons at .63" (16 mm) from bottom of piston skirt (measuring 90° to pin bore). Combining this measurement with measurement of corresponding cylinder bore, note piston-to-cylinder clearance. If this exceeds .0028" (.07 mm), oversize pistons must be installed.




Fig. 3 Codes Stamped on Piston Head




Fig. 4 Piston Ring Installation — Word TOP Must Face Piston Crown

3) Place piston rings squarely in top of cylinder bore (above ring ridge) and measure end gap. Measure ring side clearance. Install rings on piston with end gaps 120° offset to each other (start with oil ring gap directly to the rear). Ensure stamp mark "TOP" on rings is facing upward.

## CRANKSHAFT MAIN &amp; CONNECTING ROD BEARINGS

## MAIN &amp; CONNECTING ROD BEARINGS

1) Push crankshaft toward one end and measure crankshaft end play at No. 3 (thrust) bearing. Main bearing caps are stamped "1" to "5" (front to rear), and must be returned to original positions upon reassembly. Measure end play (side play) of connecting rods. Remove all bearing caps and check bearing clearance using Plastigage method.

2) Measure crankshaft journals with a micrometer to determine if crankshaft is out-of-round. Maximum ovality permissible is .0012" (.03 mm). Install main inserts with bearing half having oil groove into block. Lubricate bearings and install caps.

## Crankshaft Journal Diameters

Size	Main Bearing In. (mm)	Con. Rod Bearing In. (mm)
Standard	2.126 (54.00)	1.81 (46.00)
1st US	2.116 (53.75)	1.80 (45.75)
2nd US	2.106 (53.50)	1.79 (45.50)
3rd US	2.096 (53.25)	1.78 (45.25)

## REAR MAIN BEARING OIL SEAL

**NOTE** — Rear main bearing oil seal may be replaced with engine in vehicle. Transmission and flywheel must be removed.

Insert screwdriver between crankshaft flywheel flange and inside lip of oil seal. Pry oil seal out. Install seal guide sleeve tool 2003 (or equivalent) over crankshaft flange. Start new seal over guide and into recess in seal carrier. Pull out guide tool and fit drive PLATE 2003 (or equivalent) with bolts to flywheel mounting flange. Tighten bolts evenly to seat seal.




Fig. 5 Using Special Tool to Install Rear Main Oil Seal

## RABBIT (GASOLINE), SCIROCCO & DASHER 4 CYLINDER (Cont.)

### FRONT MAIN BEARING OIL SEAL AND INTERMEDIATE SHAFT OIL SEAL

Remove camshaft belt. Remove crankshaft sprocket. Pry seal from seal carrier, being careful not to damage carrier. Use tool 10-219 (or equivalent) to remove seal (Fig. 6). Using suitable tool (10-203), press in new seal until flush with seal carrier. If tool 10-203 was used, remove it and use aluminum part of tool (or equivalent) to press seal in until recessed .080" (2 mm) from front of seal carrier.

**NOTE** — Same procedure applies to intermediate shaft oil seal except: Remove intermediate shaft sprocket. Only press new seal in until flush with seal carrier.

### CAMSHAFT

#### TIMING BELT

**NOTE** — Sprockets DO NOT have to be removed to replace camshaft drive belt.

**Removal** — Remove A.I.R. pump belt and alternator belt. Remove water pump pulley. Remove camshaft belt cover. Loosen camshaft drive belt tensioner lock nut. Turn adjuster counterclockwise to release tension on belt. Work belt off sprockets.




Fig. 6 Using Special Tool to Remove Front Oil Seal

**Installation** — 1) Rotate camshaft sprocket until index mark (punch mark) on camshaft sprocket is lined up with top surface of valve cover mounting flange. Make sure to align index marks on spark plug side.

2) Rotate crankshaft and intermediate shafts until index mark (punch mark) on intermediate shaft sprocket is positioned in "V" notch on crankshaft pulley.

**NOTE** — Make sure sprockets are not moved after belt has been removed.

3) Being careful not to move sprockets, fit belt from bottom first. Make sure there is no slack between sprockets. Tighten belt tensioner until belt can just be twisted 90°. Make twist half way between camshaft and intermediate sprockets. Tighten lock nut. Reverse removal procedure for remaining components.




Fig. 7 Crankshaft and Intermediate Shaft Index Marks Aligned with Notch on Crankshaft Pulley

#### CAMSHAFT

**Removal** — 1) Remove camshaft cover. Loosen and remove bearing caps in following sequence: 5, 1, and 3, then loosen bearing caps 2 and 4 diagonally. Bearing caps are numbered front to rear.

2) Check camshaft end play. Remove camshaft and lift out cam followers. Install camshaft using only bearing caps 1 and 5. Fit dial indicator so tip of gauge touches front of camshaft. Pry camshaft back and forth. Reading should not exceed .006" (.15 mm). If end play is beyond limits, replace either camshaft or cylinder head.

3) Check camshaft runout. Fit dial indicator so gauge pin is against camshaft center journal. Turn camshaft and record runout range. Runout must not exceed .0004" (.01 mm). Replace camshaft as necessary.

4) Inspect camshaft lobes for wear. Worn lobes usually indicate lack of lubrication. Check engine oiling passages to make sure they are not restricted. Replace worn camshafts and worn discs.

5) Inspect cam followers for signs of seizure or lack of lubrication. If any aluminum particles from head are found on cam followers, replace followers. Cylinder head must be replaced if any follower bores are worn or excessively rough.

**Installation** — Lightly lube cam follower bores, then fit followers in their original bores. Install adjusting discs. Place camshaft on cylinder head. Loosely attach No. 2 and No. 4 bearing caps. Gradually tighten caps. Fit No. 5 and No. 3 bearing caps. Install new oil seal in front of camshaft. Install No. 1 bearing cap. Make sure all caps are torqued to proper specifications.

#### VALVE TIMING

With timing belt removed as previously described, rotate crankshaft and intermediate shaft until index mark (punch mark) on intermediate shaft is positioned in "V" notch on crankshaft pulley (Fig. 7). This is firing point of No. 1 cylinder. Next, turn camshaft until marking on rear of camshaft sprocket is in line with cylinder head cover (Fig. 8). Replace timing belt.

## RABBIT (GASOLINE), SCIROCCO &amp; DASHER 4 CYLINDER (Cont.)




Fig. 8 Index Mark on Camshaft Sprocket Aligned with Cylinder Head Flange

## ENGINE OILING

**Crankcase Capacity** — On Rabbit and Scirocco models, 3.7 quarts with filter change. On Dasher models, 3.2 quarts with filter change.

**Oil Filter** — Replaceable spin-on type.

**Normal Oil Pressure** — 28 psi@2000 RPM (normal operating temperature).

## ENGINE OILING SYSTEM

Oiling system is a pressure feed type. A gear oil pump lifts oil from pan and pressure feeds it to crankshaft journals, camshaft bearings, and intermediate shaft. Other parts of system receive oil mist or splash for lubrication.

## OIL PUMP

**Removal** — 1) With oil pan removed (see OIL PAN in this article), remove pump mounting bolts. Remove oil pump, leaving pickup tube attached.

2) Separate pickup tube from pump. Check oil pump gear backlash. Clearance should be between .002-.008" (.05-.20 mm). If specification is exceeded, replace gears or pump.

3) Measure oil pump gear end play. If end play exceeds .006" (.15 mm), replace pump.

**Installation** — To install, reverse removal procedure. Make sure all mating surfaces are clean before installing gaskets. Oil pump drive shaft must align with distributor drive gear.

## ENGINE COOLING

## Cooling System Capacity

Application	Capacity
Rabbit/Scirocco .....	4.9 qts.
Dasher	
With Expansion Tank .....	6.9 qts.
Without Expansion Tank .....	6.4 qts.

**Thermostat** — Begins to open at 176° F (80° C) and is fully open at 200° F (94° C).

## WATER PUMP

**NOTE** — The front portion of water pump (shaft, seals, bearing, and housing) can be replaced separately. To do this camshaft drive belt and sprockets must be removed. To avoid removing drive belt, remove water pump as an assembly.

**Removal** — Drain coolant. Remove alternator belt and alternator. On some Calif. models A.I.R. pump must be removed. Remove bolt holding camshaft belt cover to pump. Disconnect hoses from water pump. Remove water pump bolts.

**Installation** — To install, reverse removal procedure and make sure to use new "O" ring in recess in pump mounting flange.

**NOTE** — Do not use sealer between water pump mounting flange and engine block.

## ENGINE SPECIFICATIONS

GENERAL SPECIFICATIONS										
Year	Displ.		Carburetor	HP at RPM	Torque (Ft. Lbs. at RPM)	Compr. Ratio	Bore		Stroke	
	cu. ins.	cc					in.	mm	in.	mm
1978										
Rabbit & Scirocco	88.9	1457	Fuel Inj. ①	②71@5800	③73@3500	8.0:1	3.13	79.5	2.89	73.4
Dasher	96.9	1588	Fuel Inj.	④78@5500	③83@3200	8.0:1	3.13	79.5	3.15	80

① — 34 PICT-5 carburetor on some Rabbits.

② — Calif. Models 70@5800 RPM.

③ — Calif. Models slightly less.

④ — Calif. Models 76@5500 RPM.

# Volkswagen Engines

## RABBIT (GASOLINE), SCIROCCO & DASHER 4 CYLINDER (Cont.)

### ENGINE SPECIFICATIONS (Cont.)

VALVES							
Engine & Valve	Head Diam. In. (mm)	Face Angle	Seat Angle	Seat Width In. (mm)	Stem Diameter In. (mm)	Stem Clearance In. (mm)	Valve Lift In. (mm)
All Models Intake	1.338 (33.9)	45°	45°	.079 (2.0)	.314 (7.98)	.001-.002 (.03-.05)	....
Exhaust	1.220 (31.0)	45°	45°	.095 (2.4)	.313 (7.95)	.002-.003 (.05-.07)	....

PISTONS, PINS, RINGS						
Engine	PISTONS		PINS		RINGS	
	Clearance In. (mm)	Piston Fit In. (mm)	Rod Fit In. (mm)	Rings	End Gap In. (mm)	Side Clearance In. (mm)
All Models	.0012 (.03)	Push Fit	.0004-.0008 (.01-.02)	Comp.	.012-.018 (.30-.45)	.0008-.002 (.02-.05)
				Oil	.010-.016 (.25-.40)	.0008-.002 (.02-.05)

CRANKSHAFT MAIN & CONNECTING ROD BEARINGS							
Engine	MAIN BEARINGS				CONNECTING ROD BEARINGS		
	Journal Diam. In. (mm)	Clearance In. (mm)	Thrust Bearing	Crankshaft End Play In. (mm)	Journal Diam. In. (mm)	Clearance In. (mm)	Side Play In. (mm)
All Models	2.126 (54)	.0011-.0033 (.028-.088)	No. 3	.003-.007 (.07-.17)	1.81 (46)	.0011-.0033 (.028-.088)	⓪.010 (.25)

⓪ - Wear Limit.

CAMSHAFT			
Engine	Journal Diam. In. (mm)	Clearance In. (mm)⓪	Lobe Lift In. (mm)
All Models	.....	.0008-.002 (.02-.05)	.....

⓪ - End play .006" (.15 mm)

VALVE SPRINGS			
Engine	Free Length In. (mm)	PRESSURE Lbs. @ In. (kg @ mm)	
		Valve Closed	Valve Open
All Models Inner	....	46-51@.719 (21-23@18.3)	....
Outer	....	96-106@.916 (43.5-48@22.3)	....

TIGHTENING SPECIFICATIONS	
Application	Ft. Lbs. (mkg)
Timing Belt Tensioner Lock Nut .....	33 (4.5)
Intermediate Sprocket Bolt .....	58 (8.0)
Crankshaft Sprocket Bolt .....	58 (8.0)
Water Pump Pulley Bolts .....	14 (2.0)
Crankshaft Pulley Bolts .....	14 (2.0)
Main Bearing Cap Bolts .....	47 (6.5)
Flywheel-to-Crankshaft Bolts .....	54 (7.5)
Connecting Rod Cap Bolts .....	33 (4.5)
Camshaft Sprocket Bolt .....	58 (8.0)
Camshaft Bearing Cap Nuts .....	14 (2.0)
Cylinder Head Bolts ⓪	
Cold .....	54 (7.5)
Hot .....	61 (8.5)
Manifolds-to-Cylinder Head .....	18 (2.5)
Oil Pump Mounting Bolts	
Socket Head Bolt .....	14 (2.0)
Hex Head Bolt .....	7 (1.0)
Oil Pan Bolts .....	7 (1.0)

⓪ - For 12-point socket bolts, tighten COLD only to 54 ft. lbs. (7.5 mkg), then 1/4 turn tighter.