

## DANA/SPICER FULL FLOATING AXLES

Chrysler Corp.  
 Ford Motor Co.  
 General Motors  
 International Harvester  
 Jeep

**NOTE** — The front drive axle on all four-wheel drive models is a Dana/Spicer Full-Floating axle. Some models may use other rear drive axles. See Contents Page.

### DESCRIPTION

Dana/Spicer axles come in different models for application in vehicles with a wide range of GVW ratings. Service and overhaul procedures for all full floating axle models are the same except for drive pinion depth and some torque specifications. The axle assembly has an integral differential carrier and an over-hung mounted drive pinion. The drive pinion depth, pinion bearing preload, and differential side bearing preload are all set by shims. Dana/Spicer axle assemblies are also available with semi-floating axles. See *Dana/Spicer Semi-Floating Axles in this Section*. Other than the unique parts required for front-wheel drive, driven front and rear axles are identical.

### AXLE RATIO & IDENTIFICATION

All Dana/Spicer axles have an integral carrier with a removeable rear cover plate. The cover plate has a unique shape that allows positive identification of Dana/Spicer axles on any model vehicle. See *illustration*. The axle ratio can be determined by dividing the number of teeth on the ring gear by the number of teeth on the pinion gear. The axle model is often cast on the differential housing, or it can be determined by measuring the diameter of the ring gear. See *following chart*.

#### Model Identification By Ring Gear Size

Ring Gear Diameter	Model Number
7.125" .....	30-XX
8.500" .....	44-XX
9.750" .....	60-XX
10.500" .....	70-XX




Fig. 1 Dana/Spicer Housing Cover Gasket for Identification Purposes

## REMOVAL & INSTALLATION

### FRONT AXLE SHAFTS & BEARINGS

**Removal (Chrysler Corp. Model 44FBJ Axle)** — 1) Remove wheel cover and cotter key. Loosen outer axle shaft nut. Raise vehicle and support with safety stands. Remove brake caliper.

**NOTE** — Do Not let caliper hang from brake line.

2) Remove outer axle shaft nut and washer. Place a suitable puller (C-4358) on wheel studs and install lug nuts. Tighten puller screw to remove rotor and hub assembly. Remove puller from hub.

3) Using a suitable bearing press (C-293-PA), pull outer bearing cone from hub. Discard outer seal. Remove six bolts from retainer and remove retainer from steering knuckle. If necessary, remove brake caliper adapter from steering knuckle.

4) Position a pry bar behind inner axle shaft yoke. Push bearings out of knuckle with pry bar. Remove "O" ring from steering knuckle if equipped. Carefully slide out axle shaft assembly.

**Inspection** — Check knuckle bore and inner seal surface for wear. Replace knuckle if necessary. Temporarily install bearing cups and spacers into knuckle bore. Place bearing retainer on steering knuckle. Tighten bolts to 30 ft. lbs. Insert a .004" feeler gauge between retainer ears and knuckle. If there is no clearance, replace knuckle.

**Installation** — 1) Apply RTV sealer to the seal surface of axle shaft. Measure in 3/8" from yoke shoulder of axle shaft. Using a center punch, stake surface at 1/4" intervals. This will ensure a tight fit of inner seal slinger.

2) Using a suitable driver, install seal slinger on outer axle shaft. Install seal with lip toward axle shaft spline. Carefully install axle shaft in the housing, taking care not to damage differential side gear seal.

3) Insert a pry bar through axle shaft "U" joint and wedge axle in all the way. Using a suitable driver tool and adapter (C-4398-1 and C-4398-2), install seal cup in knuckle. Make sure it bottoms fully. Do not remove tool now.

4) Using a suitable driver (C-4250) install a new outer seal in retainer plate. Place retainer plate in position over hub of rotor. Pack wheel bearings with suitable lubricant (MOPAR Lubricant Part No. 2525035).

5) Using a suitable pressing tool and adapters (C-4264-A), carefully press outer bearing onto hub. Remove pressing tool. Place grease coated outer bearing cup over outer bearing cone. Install spacer, inner bearing cup and cone.

6) Using pressing tool again (C-4246-A), carefully press bearing cones and cups into position. Remove pressing tool. Place a 1/4" bead of RTV sealer on chamfer of retainer face. This replaces "O" ring discarded during removal.

7) Carefully remove seal installing tool from knuckle bore. Make sure outer axle shaft remains centered. **CAUTION** — If axle shaft moves, make sure that lip of seal is still riding inside cups.

### DANA/SPICER FULL FLOATING AXLES (Cont.)

8) Place bearing retainer in hub and rotor so that lube fitting is facing directly forward. **NOTE** — Lube fitting **MUST** be facing forward. Install hub and rotor assembly on knuckle. Tighten bolts to 30 ft. lbs.

9) If removed, install brake adapter. Tighten bolts to 85 ft. lbs. Remove pry bar from "U" joint and install axle shaft washer and nut. Tighten nut to 100 ft. lbs. Install cotter key. Tighten nut to align cotter key holes if necessary.

10) Insert a grease gun through access hole in hub and rotor assembly. Fill with suitable lubricant (MOPAR Part No. 2525035) until grease flows through new inner seal at "U" joint area.

11) Remove lube gun. Rotate hub and rotor several times until grease flows from at least 50% of seal diameter. Install brake caliper assembly. Install wheel and tire. Lower vehicle.

**Removal (Chrysler Corp. Model 60 Axle) — 1)** Block brake pedal up. Raise vehicle and place on safety stands. Remove wheel and tire. Remove brake caliper. Do not let caliper hang from brake line.

2) Remove cap from center of hub. Remove snap ring. Remove flange nuts and lock washers. Remove drive flange and discard gasket. Straighten tang on lock ring. Remove outer lock nut, lock ring, inner lock nut and outer bearing. Carefully slide hub and rotor off spline.

3) Remove oil seal and inner bearing from hub. Remove bearing cups with a brass drift punch. Remove inner brake pad from adapter. Remove rotor splash shield, brake adapter and spindle to knuckle nuts. Remove spindle from steering knuckle. Slide out inner and outer axle shaft with bronze spacer, seal and oil slinger.

**Installation — 1)** Slide axle shaft into position. Place bronze spacer on axle shaft with chamfer side facing toward "U" joint. Install spindle, brake adapter and brake splash shield. Tighten nut to 50-70 ft. lbs.

2) Drive in bearing cups using a suitable installer. Lubricate bearings with suitable lubricant (MOPAR Lubricant Part No. 2525035). Install inner bearing in grease coated hub. Install new seal. Care must be taken not to damage seals.

3) Install hub and rotor assembly on grease coated spindle. Install outer bearing and inner lock nut. Adjust wheel bearing. See *Wheel Bearing Adjustment in WHEEL ALIGNMENT Section*. Install a new gasket on hub. Install drive flange lock washers and nuts. Install snap ring and cap in center of hub. Install brake caliper, wheel and tire and lower vehicle.

**Removal (Ford Bronco & F-150) — 1)** Raise vehicle and position on safety stands. Remove locking hub. See *Dana/Spicer Internal Locking Hub in this Section*. Remove disc brake caliper. Remove cap from center of hub. Remove snap ring. Pry out driving hub and spring. Remove wheel bearing lock nut, lock ring and adjusting nut.

2) Remove hub and rotor assembly. The outer wheel bearing and retainer will slide out with hub. Drive inner bearing cone and grease seal out of hub. Remove brake support bracket nuts. Remove dust shield and spindle. Pull axle shaft assembly out through hole in steering knuckle. Care must be taken not to damage seal.

**Installation — 1)** Install new seal and deflector on axle shaft. Install spacer on axle. Apply lubricant to exposed area of spacer. Slide axle into position taking care not damage seal in axle housing. Install brake dust shield, spindle and brake support bracket. Tighten nuts to 30-40 ft. lbs.

2) Lubricate bearings with suitable lubricant (Ford Spec. ESA-MIC75-B). Clean old grease from hub. Place inner bearing cone and roller in inner cup and install grease retainer. Carefully install hub and rotor assembly on spindle.

3) Install outer bearing cone and roller. Install adjusting nut. Adjust wheel bearings. See *Wheel Bearing Adjustment in WHEEL ALIGNMENT Section*. Install drive hub, spring and snap ring. Apply sealer to edge of grease cap. Install grease cap and locking hub. Install caliper, wheel and tire, and lower vehicle.

**Removal (Ford F-250) — 1)** Raise vehicle and position on safety stands. Remove locking hub. See *Dana/Spicer External Locking Hub in this Section*. Remove disc brake caliper. Remove cap from center of hub. Remove lock nut, washer and adjusting nut. Remove hub and rotor assembly. Outer wheel bearing will come off with hub.

2) Remove grease retainer and inner bearing cone and roller from hub. Remove bolts securing spindle to steering knuckle. Pull axle shaft assembly out through hole in steering knuckle. Care must be taken not to damage seal.

**Installation — 1)** Install new seal and deflector on axle shaft. Install spacer. Apply lubricant to exposed area of spacer. Slide axle into position, taking care not to damage seal. Install brake dust shield, spindle and brake support bracket. Tighten nuts to 30-40 ft. lbs.

2) Lubricate bearings with suitable lubricant (Ford Spec. ESA-MICA75-B). Clean old grease from hub. Place inner bearing cone and roller in inner cup and install grease retainer. Carefully install hub and rotor assembly on spindle.

3) Install outer bearing cone and roller. Install adjusting nut and adjust wheel bearings. See *Wheel Bearing Adjustment in WHEEL ALIGNMENT Section*. Install grease cap in center of hub. Install locking hub. Install caliper, wheel and tire, and lower vehicle.

**Removal (General Motors) — 1)** Raise vehicle and position on safety stands. Remove locking hub (if equipped). See *Dana/Spicer Internal Locking Hub in this Section*. Remove caliper. If equipped with "Full Time" four-wheel drive, remove cap from center of hub. Remove snap ring, drive gear and pressure spring.

2) On all models, remove lock nut, washer and adjusting nut from spindle. Slide off hub and rotor assembly. Outer wheel bearing and retainer will come off with hub. Remove inner bearing, cone and seal from hub using a brass drift punch. Remove inner and outer bearing cups (if necessary) using a brass drift punch. Remove spindle. Carefully pull axle shaft assembly out through hole in steering knuckle.

**Installation — 1)** Install axle shaft assembly in housing. Care must be taken not to damage seal. Install thrust washer with chamfered end toward slinger on axle. Install spindle. Tighten bolts to 25 ft. lbs. (K10 & K20) and to 60 ft. lbs. (K30).

## DANA/SPICER FULL FLOATING AXLES (Cont.)

2) Install inner and outer bearing cones in hub using suitable drivers. Lubricate cones and bearings with suitable wheel bearing lubricant. Install inner bearing in cone and install new seal. Install outer bearing and retainer in hub.

3) Position hub and rotor assembly on spindle. Install inner adjusting nut. Adjust wheel bearings. See *Wheel Bearing Adjustment* in WHEEL ALIGNMENT Section. Install locking hub (if equipped). Install pressure spring, drive gear, snap ring and grease cap, if vehicle has "Full Time" four-wheel drive. Install caliper, wheel and tire and lower vehicle.

**Removal (IHC) – 1)** Raise vehicle and position on safety stands. Remove wheel and tire. Remove disc brake caliper. Remove locking hub (if equipped). See *appropriate article in Locking Hubs* in this Section. If not equipped with locking hubs, remove dust cap, snap ring and drive flange.

2) On all vehicles, remove lock nut after bending lock tab. Remove inner adjusting nut and keyed thrust washer. Remove rotor and hub assembly. Remove spindle retaining nuts and remove spindle and bearing. Pull axle shaft out through steering knuckle.

**Installation –** Install axle shaft assembly in vehicle. Care must be taken not to damage seal in housing. Install spindle on steering knuckle. Thoroughly grease bearings and cups. Place rotor and hub assembly in position on spindle. Install inner adjusting nut. Adjust wheel bearings. See *Wheel Bearing Adjustment* in WHEEL ALIGNMENT Section. Install disc brake caliper. Install wheel and tire and lower vehicle.

**Removal (Jeep CJ Models) – 1)** Raise vehicle and place on safety stands. Remove caliper if equipped with disc brakes. Remove grease cap from center of hub. Remove snap ring. If equipped with disc brakes, remove hub cover and gasket. If equipped with drum brakes, remove axle flange bolts.

2) On all models, pull off axle flange using a suitable puller (J-25133). Remove outer nut, lock washer and inner adjusting nut. Remove bearing lock washer. Remove outer bearing, then remove rotor or brake drum.

3) If equipped with disc brakes, remove caliper mounting adapter and rotor splash shield. If equipped with drum brakes, remove brake backing plate. Remove spindle and spindle bearing. Remove axle shaft assembly. Drive inner bearing and seal out of hub if necessary.

**Installation – 1)** Make sure all components are thoroughly clean. Install axle shaft assembly. Make sure seal in axle housing is not damaged. Install spindle and spindle bearing. If equipped with drum brakes, install backing plate. If equipped with disc brakes, install mounting adapter and splash shield.

2) Lubricate and install outer bearing in hub. Install brake drum or rotor in position on spindle. Install washer and adjusting nut. Adjust wheel bearings. See *Wheel Bearing Adjustment* in WHEEL ALIGNMENT Section. Install drive flange and gasket.

3) Install flange or rotor attaching bolts. Install drive flange snap ring in groove at outer end of axle shaft. If equipped with disc brakes, install caliper and rotor hub cover. Install hub center grease cover. Install wheel and tire and lower vehicle.

**Removal (Jeep, Remaining Models) – 1)** Raise vehicle and position on safety stands. Remove wheel and tire. Remove dust cover from center of hub. Remove snap ring, drive flange, pressure spring and spring retainer.

2) Remove outer lock nut, lock washer and adjusting nut. If equipped with disc brakes, remove bolts attaching caliper to support shield and move caliper off rotor. On all models, remove rotor or brake drum. Outer wheel bearing and retainer will come off with hub. Remove inner bearing and seal from hub.

3) Remove spindle mounting bolts. Remove spindle. If equipped with disc brakes, remove support and splash shield. If equipped with drum brakes, remove backing plate. Remove axle shaft assembly.

**Installation – 1)** Install axle shaft assembly in housing. Care must be taken not to damage seal in housing. Install backing plate or caliper adapter in position. Install spindle and bearing. Install brake drum or rotor and hub assembly.

2) Install inner adjusting nut. Inner nut has peg on one side. Adjust wheel bearings. See *Wheel Bearing Adjustment* in WHEEL ALIGNMENT Section. Install spring retainer with cupped side toward center of vehicle. Install drive flange and snap ring. Install wheel and tire, dust cover, and lower vehicle.

## REAR AXLE SHAFTS & BEARINGS

**NOTE –** Close inspection of hub and axle type is necessary to determine which procedure below applies.

**Removal – 1)** Remove flange nuts from hub studs. Using a heavy hammer, rap sharply on center of axle flange to loosen tapered dowels (if equipped). Remove dowels. Rap center of flange again to cause flange and axle assembly to spring away from hub. Remove axle without using prying devices which might damage axle flange and hub mating surfaces. To service bearings, remove locking devices and bearing adjusting nut. Pull wheel straight off axle housing using care to avoid dropping bearing cones. Remove and discard seal(s). Remove bearing cones from hub or axle housing.




Fig. 2 Detail View of Tapered Dowels

# Drive Axles

## DANA/SPICER FULL FLOATING AXLES (Cont.)




Fig. 3 Sectional View of Axle Shaft & Bearings With Snap Ring Bearing Retainer




Fig. 4 Sectional View of Axle Shaft & Bearings With Machined Shoulder Bearing Retainer

2) Two methods are used to position outer bearing cup in hub: Seating cup against a machined shoulder, and seating cup against a removable snap ring set into a machined groove. To remove machined shoulder type, drive each bearing cup out of hub using a long drift or suitable tool. To remove snap ring type, remove inner cup with long drift. Remove snap ring with pliers. Using a suitable tool, drive outer bearing and cup out of hub.

**Installation** — To install machined shoulder type, drive or press inner and outer bearing cups into place using a suitable tool. Make sure that cups are firmly seated against shoulders in hub. To install snap ring type, insert outer bearing cone into hub. Insert bearing cup into hub and drive beyond snap ring groove. Install snap ring. Drive cone and cup assembly back against snap ring making sure that it is fully seated. Install inner bearing cup and cone. Install seals. Adjust wheel bearing. See *Rear Wheel Bearing Adjustment* in *WHEEL ALIGNMENT* Section.

### PINION FLANGE & SEAL

**NOTE** — Pinion seal can be serviced with axle assembly installed in vehicle.

**Removal** — Disconnect drive shaft and scribe a line down pinion shaft, flange, and nut. Remove nut and, using a suitable tool, remove flange. **CAUTION** — Do not hammer flange off. Damage to pinion gear, ring gear, and bearing could result. Pry seal from bore using care not to damage machined surfaces.

**Installation** — Lubricate cavity between seal lips with a high melting point lubricant. Install seal into bore making sure that it bottoms against shoulder. Place flange on shaft and draw it down with pinion nut. Tighten pinion nut to specifications. **CAUTION** — Failure to tighten pinion nut to full specifications will result in flange or pinion shaft failure. Install drive shaft.

### AXLE ASSEMBLY

**Removal** — Raise vehicle on hoist and support axle assembly to take weight off springs. Disconnect drive shaft at pinion flange and tie out of way. Remove hub and drum assembly. Disconnect vent tube (if equipped), and disconnect parking brake cable(s) and service brake hydraulic lines. Disconnect shock absorbers at axle brackets. Disconnect springs and remove axle.

**Installation** — Reverse removal procedure. Do not fully tighten shock absorbers nut until assembly is completed. Bleed hydraulic lines and adjust parking brake before moving vehicle.

### OVERHAUL

#### DISASSEMBLY

**NOTE** — Remove axle housing assembly before beginning overhaul.

1) Remove axles and housing cover. Be sure that side bearing caps are marked so that they can later be installed in their original positions. Remove bolts and side bearing caps. Use a housing spreader to spread differential housing .015-.020". Use a dial indicator to measure spread. **CAUTION** — Do not spread housing more than .020". Permanent damage to hous-

## DANA/SPICER FULL FLOATING AXLES (Cont.)

ing could result. Carefully pry differential case out of housing. Be careful not to damage machined surface of housing. Remove spreader immediately to prevent possibility of carrier taking a set.

2) If differential case is one piece, proceed as follows: Remove bolts holding ring gear to differential case, then tap ring gear off with soft-faced hammer. With a small punch, drive out lock pin. Remove differential shaft and thrust block. Remove differential pinion gears and thrust washers.

3) If differential case is two piece, proceed as follows: Remove bolts holding ring gear to differential case, then tap ring gear off with soft-faced hammer. Mark differential case halves to aid reassembly. Remove bolts and separate case halves. Remove pinion gear spider, pinion gears, side gears, and all thrust washers.




Fig. 5 Correct Procedure to Spread Differential Housing

4) Remove pinion nut. With suitable puller, remove pinion flange. Using soft-faced hammer, drive pinion shaft out of housing. **NOTE** — Pinion bearing adjusting shims may remain on pinion shaft, stick to bearing, or fall loose. Collect them and save them for reassembly. From pinion shaft bore, remove oil seal and bearing cone. A baffle or an oil slinger may also be present; record the order in which they were removed so that they may be installed correctly. Discard seal. Remove inner bearing cone and press pinion bearing off pinion shaft.

5) Using a suitable puller, remove side bearings from differential case. Often during removal of side bearings, shims between bearings and differential case are mutilated. If so, shims must be individually measured and their thicknesses recorded, so that new shim packs can be secured.

### REASSEMBLY & ADJUSTMENT

**Case Assembly** — 1) If differential case is one piece, proceed as follows: Place differential case in holding fixture or vise. Lubricate side and pinion gears and all thrust washers and install in case. Rotate side gears until holes in pinion gears and washers line up with holes in case. Install spacer block (if equipped) and differential pinion shaft. If old thrust washers are used, check for preload of side gears by measuring clearance between side gears and case. Clearance should be .000-.006"; if not, shims can be installed (in equal amounts on each side), or new thrust washers installed. Install lock pin and peen over hole to retain pin. Install ring gear and tighten bolts to specifications.

2) If differential case is two piece, proceed as follows: Lubricate all parts with differential lubricant. Install differential side gears and thrust washers, pinion gear spider, pinion gears, and thrust washers in differential case. Check for preload of side gears by measuring clearance between side gears and case. Clearance should be .000-.006"; if not, shims can be installed (in equal amounts on each side), or new thrust washers installed. Rejoin case halves using aligning marks made during reassembly. Tighten bolts to specifications. Install ring gear and tighten bolts to specifications.




Fig. 6 Using Dial Indicator to Measure Differential Endplay

2) Install differential side bearings. Assemble case in housing WITHOUT shims. Install bearing caps and tighten bolts just enough to seat bearing cups. Mount dial indicator to read at back of differential flange. Measure and record amount of side play of differential case by moving back and forth with a screwdriver (see illustration). The measurement will be used later to determine proper shim pack dimension. Remove case from housing.

**Pinion Depth & Bearing Preload** — 1) Pinion is adjusted by shims placed between inner bearing cup and housing, and by shims placed between pinion shaft shoulder and outer bearing. Shims behind inner bearing cup adjust position of pinion in relation to ring gear. Shims behind outer bearing adjust pinion inner and outer bearing preload.

2) If old pinion and ring gear assembly are used, proceed as follows: Install original shims and inner bearing cup. Install outer bearing cup. Press bearing cone onto pinion shaft and install shaft into housing. Install outer bearing cone, companion flange, and nut. Do not install outer shims or seal at this time. Tighten nut to obtain bearing preload of 10-30 ft. lbs. Use a suitable gauge to measure distance from ring gear center to machined button on end of pinion gear. Add or subtract shims from under inner bearing cup to obtain nominal dimension listed in specifications.

3) If new pinion and ring gear assembly are to be installed, proceed as follows: Determine pinion depth adjustment figure (see illustration) of old and new pinions and find shim adjustment figure from chart. Adjust original shim pack accordingly and proceed as in step 2).

4) Remove pinion flange and nut, and remove front pinion bearing cone. Install original preload shim pack. Lubricate and install bearing cone. Install pinion flange and nut and tighten to specifications while rotating pinion shaft. Place housing in position so that pinion shaft is vertical, pointing up. With INCH lb. wrench rotate shaft through several revolutions to measure

# Drive Axles

## DANA/SPICER FULL FLOATING AXLES (Cont.)

rotating torque. **NOTE** — Ignore torque needed to start shaft rotating. Check measurement against pinion bearing preload in specifications. To decrease preload, add shims; to increase preload; subtract shims. After adjustment is made, install oil seal and recheck pinion depth.




Fig. 7 Pinion & Ring Gear Marks Showing Pinion Depth Adjustment Figure

5) Front axles only: Check seals in axle housing bores. If condition is questionable, replace using suitable installer tool (see illustration). **NOTE** — When installing front axle shafts be sure that these seals are not dislodged.




Fig. 8 Correct Procedure to Install Inner Oil Seals

**Side Bearing Preload** — 1) With pinion installed in housing and depth and preload adjustments properly made, install differential case into housing and set dial indicator so that it reads at back of ring gear. Leave bearing cap bolts loose enough to allow movement of case. Insert screwdriver between bearing cap and housing at opposite end from ring gear. Jam case toward ring gear side and, with force still applied to case, set dial indicator to zero. Jam case the other way (making sure that ring and pinion gears mesh) and record reading. Repeat several times until readings are the same. This reading is amount of shims that will go between case and bearing on ring gear side. Install these shims.

2) From the figure originally recorded under Case Assembly, subtract amount of shims just installed on case. Add .015" for bearing preload and install new shim pack on end of case opposite ring gear.

Example: +.070" (Original Recorded Sideplay)  
 −.032" (Sideplay With Pinion Installed)  
 =.038" (Amount Left From Original Sideplay)  
 +.015" (Additional Amount For Bearing Preload)  
 =.053" (Amount Installed Opposite of Ring Gear)

3) Install spreader to housing, spread housing and install differential case. **NOTE** — Do not spread housing more than .020". Permanent damage to housing could result. Install differential assembly. Remove spreader and install bearing caps. Make sure that caps are in original position, then tighten caps evenly.

**Backlash & Final Assembly** — Mount dial indicator to housing and measure ring gear to pinion gear backlash in three places around ring gear (see specifications). Variation between readings should not exceed .002". Adjust to specifications by moving shims from one side of differential case to other, or by changing depth of pinion gear. Check tooth contact pattern (see Tooth Contact Pattern in this section). Install cover and tighten bolts to specifications.

Old Pinion	New Pinion								
	-4	-3	-2	-1	0	+1	+2	+3	+4
+4	+0.008	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0
+3	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001
+2	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002
+1	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003
0	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004
-1	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005
-2	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006
-3	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007
-4	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007	-0.008

PINION DEPTH SHIM ADJUSTMENT CHART

