

Engine Cooling Systems

CHRYSLER CORP.

COOLING SYSTEM CAPACITY

Application	Quarts
225"	
"AD" "AW", "PD" & "PW" Models	①13
D100, D150, D200 B100, B200, PB100 PB200, W150, W200	①13
D300, W300, B300, PB300, CB300 & MB300	①14
243" Diesel	
D150, W150, D200, W200	①13
318"	
D100, D150, W150	①17
B100, B200, PB100, PB200	①17
D200, W200, P300, W300	②17
B300, PB300, CB300, MB300	①17
360"	
D100, D150, W150, D200, W200, D300, W300	①16
B100, B200, PB100, PB200, B300, PB300, CB300, MB300	①15.5
400" & 440"	
D100, D150, D200, D300, D400, W150, W200, W300, W400	16
B100, B200, B300 PB100, PB200, PB300	①15.5
CB300, MB300	①15.5
① - Add 1 quart with Air Conditioning.	
② - Add 1½ quart with Air Conditioning.	

PRESSURE CAP

Application	PSI
All Models	16

THERMOSTAT

Application	①Initial Open	①Full Open
225" All	192-199	219
318"		
"AD" & "AW"	192-199	219
"PD" & "PW"	192-199	219
D100 & W100	192-199	219
B100 & 200	192-199	219
PB100 & 200	192-199	219
All Others	182-189	205
360", 400" & 440"		
"AD" & "AW"	192-199	219
"PD" & "PW"	192-199	219
D100 & W100	192-199	219
All Others	182-189	205
① - Specifications are in °F.		

WATER PUMP

"AD", "AW", "PD", "PW",
"D" & "W" Models

Removal (225" Engine) - On models without air conditioning, drain cooling system. Remove fan shroud (if equipped) and set back on engine. Loosen alternator, power steering pump and remove belts. Remove fan, spacer, pulley and bolts as an assembly. Remove fan shroud if equipped. Position lower hose clamp in center of by-pass hose. Disconnect heater hose and lower radiator hose from water pump. Remove water pump attaching bolts and water pump assembly.

Installation - Clean all gasket surfaces, install new hoses (as required) and gaskets. Reverse removal procedure, tighten bolts, adjust drive belt tension and refill cooling system.

Removal (V8 Engines) - 1) Drain cooling system. Remove fan shroud (if equipped) and set back on engine. Disconnect radiator hoses and oil cooler lines at radiator. Remove radiator attaching screws, air conditioning condenser attaching bolts (if necessary) and remove radiator and shroud from vehicle.

CAUTION - Cap or plug lines to prevent contamination of fluid or excessive loss of fluid.

2) Loosen alternator adjusting bolts and pivot bolt, power steering and air pump (if equipped), and remove all drive belts. On 318" and 360" engines without air conditioning, remove alternator bracket attaching bolts, swing alternator out of way and tighten pivot bolt. On 318" and 360" engines with air conditioning, remove idler pulley assembly, alternator and adjusting bracket.

3) Remove fan, spacer (or fluid drive) pulley and bolts as an assembly.

CAUTION - To prevent silicone fluid from draining into fan drive bearing and ruining the lubricant, do not place drive unit with shaft pointing downward.

4) On 318" and 360" engines, disconnect heater and by-pass hoses, remove compressor clutch assembly, remove compressor to front mounting bracket bolts and remove water pump to compressor front mount bracket bolts and bracket. On all engines, remove water pump attaching bolts and water pump assembly.

Installation - Clean all gasket surfaces, install new hoses (as required) and gaskets. Reverse removal procedure, tighten bolts, adjust drive belt tension and refill cooling system.

B, PB, CB, & MB MODELS

Removal (225" Engine) - Drain cooling system, loosen alternator, power steering pump or idler pulley, then remove all drive belts. Remove fan, spacer, pulley and bolts as an assembly. Position by-pass hose lower clamp in center of hose and disconnect heater hose. Remove water pump retaining bolts and water pump assembly.

Installation - Clean all gasket surfaces, install new hoses (as required) and gaskets. Reverse removal procedure, tighten bolts, adjust drive belt tension and refill cooling system.

CHRYSLER CORP. (Cont.)

Removal (318" & 360" Engines) – 1) Drain cooling system and, if equipped with air conditioning, remove radiator and shroud. Loosen alternator adjusting bolts and pivot bolt. Loosen power steering bolts. Remove all drive belts. On 318" and 360" engines without air conditioning, remove alternator bracket bolts to water pump. Swing alternator out of way and tighten pivot bolt.

2) On 318" and 360" engines with air conditioning, remove idler pulley assembly, alternator and adjusting bracket. On all models, remove fan, spacer (or fluid drive), pulley and bolts as an assembly.

CAUTION – To prevent silicone fluid from draining into fan drive bearing and ruining lubricant, do not place drive unit with shaft pointing downward.

3) Disconnect heater, by-pass and radiator hoses. Remove compressor clutch assembly, compressor-to-front mounting bracket bolts and water pump-to-compressor front mount bracket bolts and bracket. Remove water pump attaching bolts and water pump assembly.

Installation – Clean all gasket surfaces, install new hoses (as required) and gaskets. Reverse removal procedure, tighten bolts, adjust drive belt tension and refill cooling system.

Removal (400" & 440" Engines) – Disconnect fusible link in engine compartment, then drain cooling system. Loosen all drive belts, then remove crankshaft pulley. Remove fan shroud and set back on engine. Remove fluid fan drive bolts and set fluid fan drive and fluid fan assembly aside. Remove water pump retaining bolts and water pump assembly.

Installation – Clean all gasket surfaces, install new hoses (as required) and gaskets. Reverse removal procedure, tighten bolts, adjust drive belt tension and refill cooling system.

MOTOR HOME MODELS

Removal – 1) Radiator must be removed before removing water pump. The radiator removal procedure may vary depending on body style. The following general procedures apply to most body styles. Disconnect battery ground cable and drain cooling system. Disconnect upper and lower radiator hoses. Remove radiator filler extension, and disconnect oil cooler lines.

CAUTION – Cap or plug lines to prevent contamination of fluid or excessive loss of fluid.

2) Remove upper air baffle, both side baffles and coolant reserve tank. Remove fan shroud from radiator and position rearward on engine to provide maximum clearance. Remove radiator attaching bolts and remove radiator from vehicle.

3) Loosen power steering pump and alternator. Remove all drive belts. Remove fan and fluid fan drive as a unit.

CAUTION – To prevent silicone fluid from draining into fan drive bearing and ruining the lubricant, do not place drive unit with shaft pointing downward. Remove inlet hose, and loosen by-pass hose clamp (360" engine only). Remove water pump attaching bolts and water pump assembly.

Installation – Clean all gasket surfaces, install new hoses (as required) and gaskets. Reverse removal procedure, tighten bolts, adjust drive belt tension and refill cooling system.

TIGHTENING SPECIFICATIONS

Application	Ft. Lbs.
Water Pump Attaching Bolts.....	30
Fan Attaching Bolts.....	15-18
Fluid Fan Drive Bolts.....	15-18