

## 7.5L V8 ENGINE

### IDENTIFICATION CODING

#### ENGINE IDENTIFICATION

Engine is identified by a letter code, eighth digit of Vehicle Identification Number, located inside windshield on left upper side of instrument panel. The VIN number is also located on the Safety Compliance Certification Label located on left door lock pillar.

Engine Identification Codes	
Application	VIN Code
7.5L (460") .....	L

#### ENGINE REMOVAL

See *Engine Removal* at end of *ENGINE* Section.

### CYLINDER HEAD & MANIFOLD

#### INTAKE MANIFOLD

**Removal** – 1) Drain cooling system. Remove air cleaner and duct assembly, disconnect radiator and heater hoses at intake manifold and water pump and position out of way.

2) Disconnect and tag all vacuum lines for proper installation. Disconnect PCV valve and hose at right rocker arm valve cover. Disconnect spark plug wires at spark plugs and disconnect coil high-tension lead at coil. Remove distributor cap and spark plug wires as an assembly. Remove distributor.

3) Disconnect accelerator linkage at carburetor and speed control linkage bracket, if equipped, and position linkage out of way. Disconnect fuel line at carburetor.

4) Disconnect any electrical wiring to intake manifold and position out of way. Remove coil and bracket assembly. Remove attaching bolts and nuts and remove intake manifold and carburetor as an assembly.

**Installation** – 1) Clean and inspect manifold for cracks, damaged gasket surfaces, or other defects. Thoroughly clean all gasket surfaces and apply an oil resistant sealer to intake manifold and block seal surfaces (4 corners).

2) Position front and rear seals on cylinder block and new gaskets on cylinder heads. Ensure that holes in gaskets are aligned with holes in cylinder heads. Position gaskets in slots with end tabs over ribs on seals.

3) Lower intake manifold on engine and check for correct positioning of gaskets and seals before installing attaching bolts and nuts. Install bolts and nuts, then tighten in sequence shown in *Fig. 1*.

4) To install remaining components, reverse removal procedure. After engine has been started and allowed to reach normal operating temperature, retighten manifold attaching bolts and nuts.

#### CYLINDER HEAD


**Removal** – 1) Drain cooling system. Remove intake manifold as previously outlined. Disconnect exhaust pipe from exhaust manifold and remove bolt attaching alternator bracket to cylinder head.

2) If equipped with air conditioning, shut off compressor at service valves and remove valves and hoses from compressor. Remove nuts attaching compressor support bracket to water pump and bolts attaching compressor to upper mounting bracket and position compressor out of way. Remove upper mounting bracket from cylinder head.


3) If not equipped with air conditioning, remove bolts attaching power steering reservoir bracket to cylinder head. Position reservoir and bracket out of way.

4) Remove rocker arm covers. Remove rocker arms and push rods in sequence so they can be installed in their original positions. Remove cylinder head attaching bolts and remove cylinder heads and exhaust manifold as assemblies.

**Installation** – Clean old gasket material from cylinder heads and block. Position head gaskets on block and install cylinder heads. Tighten all head bolts in sequence in three steps. See *Fig. 2*. To install remaining components, reverse removal procedure. Adjust valve clearance.



**Fig. 1 Intake Manifold Tightening Sequence**



**Fig. 2 Cylinder Head Tightening Sequence**

## 7.5L V8 ENGINE (Cont.)

### VALVES

#### VALVE ARRANGEMENT

E-I-E-I-E-I-E-I (Left side, front to rear).  
I-E-I-E-I-E-I-E (Right side, front to rear).

#### VALVE GUIDE SERVICING

To ream guides for installation of valves with oversize stems, always use reamers in sequence and always reface valve seats after valve guides are reamed. Reamers are available .003" oversize with standard size pilot; .015" oversize reamer with .003" oversize pilot; .030" oversize reamer with .015" oversize pilot.

#### VALVE STEM OIL SEALS

Umbrella type oil seals are used on all valves. Lubricate valve stem with engine oil and install new valve stem seal with cup side down over valve guide using  $\frac{5}{8}$ " deep well socket and light mallet to seat seal on valve stem.

#### VALVE SPRINGS

**Removal** - 1) Remove air cleaner and duct assembly. Remove rocker arm cover, spark plug, rocker arms and push rod from cylinder to be serviced.

2) Install air line with adapter into spark plug hole. Use spring compressing tool to compress valve spring and remove retainer lock. See Fig. 3.




Fig. 3 Compressing Valve Spring for Removal

**NOTE** - If air pressure fails to hold valve closed, remove cylinder head and inspect valve seat area for damage. Remove and discard valve stem oil seal after removing spring retainer and valve spring.

**CAUTION** - Do not remove air pressure from cylinder as this will allow valve to drop into cylinder if piston has been forced to bottom of cylinder.

**Installation** - 1) With valve stem seals installed, place spring in position over valve and position spring retainer. Compress valve spring and install retainer locks.

2) Apply Lubriplate or equivalent to end of push rods and tip of valve stem. Install rocker arms and tighten bolts. To install remaining components, reverse removal procedure.

#### VALVE SPRING INSTALLED HEIGHT

Valve spring ends must be square within  $\frac{5}{64}$ " tolerance. Installed height of valve spring must not exceed specifications. Measure spring height from surface of cylinder head pad to underside of spring retainer. If installed height exceeds specifications, install spacer(s) below spring to reduce height to specified dimension. See Fig. 5.




Fig. 4 Checking Valve Spring Squareness

**CAUTION** - Reducing installed height below specifications can cause spring breakage and rapid wear of cam lobe.

#### Valve Spring Installed Height Specifications

Application	Installed Height
7.5L (All Valves)	$1\frac{51}{64}$ - $1\frac{53}{64}$ "




Fig. 5 Checking Valve Spring Installed Height

#### HYDRAULIC VALVE LIFTER ASSEMBLY

Lifters should be serviced as assemblies only as internal parts are matched sets and cannot be interchanged. If any part of lifter needs replacing, replace entire assembly. Leak down rate on lifters is 10-50 seconds at  $\frac{1}{16}$ " plunger travel using suitable leak down tester. See Fig. 6.

## 7.5L V8 ENGINE (Cont.)




Fig. 6 Disassembled View of Hydraulic Valve Lifter

### ROCKER ARM ASSEMBLY

Rocker arms are individually mounted with fulcrum bolts which are threaded into cylinder head. Inspect rocker arms, fulcrum seats, oil deflectors and fulcrum bolts for undue or excessive wear. Replace all parts that show fatigue. Before installing, apply Lubriplate or equivalent to top of valve stem, rocker arm and fulcrum seat. See Fig. 7.




Fig. 7 Rocker Arm Assembly

### HYDRAULIC VALVE LIFTER ADJUSTMENT

Repeated valve seat and face reconditioning will decrease valve stem to rocker arm clearance to point that if not compensated for, hydraulic valve lifters will cease to function. To compensate for dimensional changes in valve mechanism, a .060" shorter or .060" longer replacement push rod is available.

**NOTE** — Valve lifters must be completely collapsed when checking valve clearance.

1) Use suitable tool (T71P-6513-A or equivalent) to slowly collapse valve lifter until plunger is bottomed. Hold lifter down while checking valve clearance.




Fig. 8 Crankshaft Positions for Adjusting Hydraulic Valve Lifters

2) With No. 1 piston on TDC at end of compression stroke (position A in Fig. 8), check valve clearance on the following valves: No. 1 intake, No. 1 exhaust, No. 7 intake, No. 5 exhaust, No. 8 intake, No. 4 exhaust.

3) Rotate crankshaft to position B as shown in Fig. 8 and check valve clearance on the following valves: No. 4 intake, No. 2 exhaust, No. 5 intake, No. 6 exhaust.

4) Rotate crankshaft to position C as shown in Fig. 8 and check valve clearance on the following valves: No. 2 intake, No. 3 exhaust, No. 3 intake, No. 7 exhaust, No. 6 intake, No. 8 exhaust.

Collapsed Lifter Clearance		
Application	Desired	Allowable
7.5L (All Valves)	.100-.150"	.075-.175"

### PISTON, PINS & RINGS

#### OIL PAN

See Oil Pan Removal at end of ENGINE Section.

#### PISTON & ROD ASSEMBLY

**Removal** — 1) With cylinder heads and oil pan removed, use ridge cutter to remove any ridge or deposits from upper end of cylinder bores. Ensure piston is at bottom of stroke. Cover piston with cloth to collect cuttings.

**NOTE** — Never cut more than 1/32" from ring travel area of bore when removing ridge.

2) Ensure that all connecting rods and caps are marked so they can be installed in their original positions. Remove rod cap and push piston and rod assembly out top of cylinder taking care not to damage crankshaft journal or cylinder wall.

**Installation** — 1) Lightly coat cylinder bore, piston and rings with engine oil. Ensure that ring gaps are properly spaced as shown in Fig. 11. Install a ring compressor on piston.

## 7.5L V8 ENGINE (Cont.)

2) Install piston into respective cylinder bore with notch in piston head towards front of engine. Carefully push piston into cylinder until it is slightly below top of cylinder. Install connecting rod bearings. Coat bearings and crankshaft journal with oil. Pull piston and rod assembly down onto journal and install rod cap. Install rod cap nuts and tighten. See Fig. 9.




Fig. 9 Piston and Connecting Rod Assembly

### FITTING PISTONS

Measure piston at centerline of piston pin bore 90° to pin bore axis. Measure cylinder bore at right angle to centerline of crankshaft, below ring travel. Piston-to-bore clearance should be as shown in Pistons, Pins & Rings table. Check Piston Size Code Chart to determine correct size. Make sure both piston and cylinder block are at normal room temperature (70°F) when fitting.

Piston Size Code Chart	
Code	Piston Size
Red .....	4.3585-4.3591"
Blue .....	4.3597-4.3603"
.003" Oversize .....	4.3609-4.3615"

### PISTON PINS

Pins are a press fit in connecting rods. Use a suitable tool (T65L-6135-A) and arbor press as shown in Fig. 10 for removal and installation of piston pins. Pins are pressed through piston body and connecting rod until end of pin is 1/16"-1/8" below chamfer of pin bore in piston.

### FITTING RINGS

1) Position ring in the cylinder bore that it will be used in. Push ring down to point in bore where ring wear is not encountered. Use head of piston to position ring squarely in bore.

2) Measure gap between ends of ring using a feeler gauge, if not to specification, substitute another ring set until rings are within specification.

**CAUTION** — Use care to avoid damage to ring or cylinder bore.




Fig. 10 Removing and Installing Piston Pin




Fig. 11 Correct Spacing For Piston Rings

## CRANKSHAFT & ROD BEARINGS

### MAIN & CONNECTING ROD BEARINGS

**Connecting Rod Bearing** — After ensuring rod caps are marked for cylinder identification, remove rod caps (with crankshaft journal of cylinder to be checked at bottom of throw). Use Plastigage method to check for proper clearances. New bearings are available in standard, .001" and .002" undersize. Selective fitting is required on each rod. A standard bearing half may be used in combination with a .001" undersize or a .002" undersize with a .001" undersize. Coat bearing

## 7.5L V8 ENGINE (Cont.)

surfaces with oil, install rod cap and tighten. Rotate crankshaft after bearing replacement to ensure that bearings are not too tight.

**Main Bearings** – 1) Mark main bearing caps for identification before removal. Remove bearing caps and upper half of main bearing. Rotate crankshaft slowly in direction of engine rotation to force upper half of bearing out. See Fig. 12.

**NOTE** – Replace one bearing at a time, leaving other bearings secured until ready to be changed.

2) Determine crankshaft bearing journal clearance using Plastigage method. When checking main bearings, place jack under counterweight adjoining bearing being checked. Place Plastigage on bearing surface over full width of cap and about  $\frac{1}{4}$ " off center. Install cap and tighten to specified tightness. Remove cap and check with gauge provided. New bearings are available in standard, .001" and .002" undersize.




Fig. 12 Removal and Installation of Upper Main Bearing

3) To install upper main bearing, lubricate bearing with engine oil and place plain end of bearing over shaft on locking tang side of block. Insert bearing and rotate crankshaft in opposite direction of engine rotation until bearing tang is seated. Install bearing cap and tighten.

## THRUST BEARING ALIGNMENT

Install all bearing caps except thrust bearing cap and tighten bolts. Install thrust bearing cap with bolts finger tight. Pry crankshaft to front of engine and hold it forward while prying thrust cap to rear. Hold crankshaft forward and tighten cap bolts. Check crankshaft end play. See Fig. 13.

## REAR MAIN BEARING OIL SEAL

**Removal** – 1) Complete seal can be replaced without removing crankshaft. Remove oil pan and oil pump. Loosen all main bearing cap bolts and allow crankshaft to drop slightly, but not to exceed  $\frac{1}{32}$ ".

2) Remove rear main bearing cap and remove oil seal from bearing cap and block. On block half of seal, use seal removing tool or place small sheet metal screw in one end of seal and pull on screw to remove seal. Extreme care must be taken to prevent scratching or damaging crankshaft seal surface.

3) Remove oil seal retaining pin from bearing cap and discard (if equipped). Replacement seal does not use pin.

**Installation** – 1) Clean oil seal groove. Dip new seal halves in engine oil. Carefully install block upper seal half into groove. Ensure undercut (lip) side of seal is toward front of engine. Install by rotating seal on crankshaft journal until approximately  $\frac{3}{8}$ " of seal protrudes from parting surface. See Fig. 14.

2) Tighten remaining bearing caps. Install lower half of seal in rear main bearing cap so that  $\frac{3}{8}$ " protrudes above parting surface. Apply light coat of oil resistant sealer to rear of top mating surface of bearing cap. Install cap and tighten bolts.

**CAUTION** – Avoid shaving any rubber from outside diameter of seal by bottom edge of groove. Do not allow oil to get into seal area.





Fig. 13 Aligning Thrust Bearing

## 7.5L V8 ENGINE (Cont.)



**Fig. 14** Installing Crankshaft Rear Oil Seal

### CAMSHAFT

#### ENGINE FRONT COVER

**NOTE** — Always replace front cover oil seal after removing front cover.

**Removal** — 1) Drain cooling system and crankcase. Remove fan and radiator shroud. Disconnect radiator hoses at engine and oil cooler lines at radiator and remove radiator.

2) Remove all drive belts and water pump pulley. Remove air conditioning compressor support (if equipped). Remove crankshaft pulley from vibration damper. Remove bolt attaching crankshaft damper and remove damper using suitable puller. Remove Woodruff key.

3) Loosen by-pass hose at water pump and disconnect heater return tube at water pump. Disconnect and plug fuel lines at fuel pump and remove fuel pump.


4) Remove bolts attaching front cover to cylinder block. Using a thin blade knife, cut oil pan seal flush with cylinder block face prior to separating cover from block. Remove front cover and water pump as an assembly.

**Installation** — 1) Coat gasket surface of oil pan with sealer. Cut and position required section of a new seal on oil pan. Apply sealer to front cover and cylinder block gasket surfaces.

2) Position front cover on cylinder block. Install front cover to seal alignment tool in proper position as shown in Fig. 15.

**NOTE** — Use care when installing cover to avoid seal damage or possible misalignment.

3) Install cover attaching bolts, and while pushing in on alignment tool, tighten oil pan-to-cover bolts, and cover-to-cylinder block bolts. To install remaining components, reverse removal procedure.




**Fig. 15** Aligning Front Cover

#### FRONT COVER OIL SEAL

With engine front cover removed, drive out old oil seal with pin punch and clean seal recess in front cover. To install, coat new seal with grease and install seal using installing tool T68P-6700-A (or equivalent). See Fig. 16.

**NOTE** — After installation, ensure seal spring remains in proper position.



**Fig. 16** Installing Front Cover Oil Seal

#### TIMING CHAIN & SPROCKETS

**Removal** — With engine front cover removed, crank engine until timing marks on sprockets are aligned as shown in Fig. 17. Remove camshaft sprocket cap screw, washer, 2-piece fuel pump eccentric and front oil slinger. Slide timing chain and sprockets forward and remove as an assembly.

**Installation** — Assemble timing chain and sprockets so sprocket timing marks are aligned as shown in Fig. 17. Install chain and sprockets as an assembly to crankshaft and camshaft. To install remaining components, reverse removal procedure and lubricate timing chain with engine oil.

# Ford V8 Engines

## 7.5L V8 ENGINE (Cont.)




Fig. 17 Aligning Timing Marks

### CAMSHAFT

**Removal** - 1) Remove timing chain and sprockets and intake manifold. Remove rocker arm covers and back off all rocker arm bolts. Turn rocker arms sideways and remove push rods and valve lifters, keeping them in order for installation in their original positions.

2) Remove radiator and bolts attaching air conditioning condenser (if equipped) to chassis. Carefully move condenser to rest on left fender. Remove grille. Remove camshaft thrust plate attaching bolts and carefully remove camshaft from front of engine.

**Installation** - Oil camshaft journals and apply Lubriplate or equivalent to cam lobes. Carefully slide camshaft into position and install thrust plate attaching bolts. To install remaining parts, reverse removal procedure. See Fig. 18.




Fig. 18 Exploded View of Camshaft Assembly

### CAMSHAFT BEARINGS

With engine removed and placed in work stand, remove camshaft, flywheel, rear cover plate and crankshaft. Remove camshaft rear bearing bore plug by drilling  $\frac{1}{2}$ " hole in center of plug. Pull plug with tool T59L-100-B and T50T-100-A (or equivalent). Remove bearing using proper size expanding collet and back-up nut assembled on expanding mandrel. Use same procedure to install bearings. Oil holes in bearings and cylinder block should be aligned. Front bearings should be installed .040-.060" from face of cylinder block. Coat new rear bore plug with sealer and install. See Fig. 19.

### CAMSHAFT END THRUST

To check end play, push camshaft towards rear of engine. Install dial indicator so that indicator point is on camshaft sprocket attaching screw. Pull camshaft forward and check dial indicator reading to obtain end play. If end play is excessive, replace camshaft thrust plate.




Fig. 19 Replacing Camshaft Bearings

### ENGINE OILING


**Crankcase Capacity** - 5 qts., add 1 qt. with filter change.

**Oil Filter** - Change filter after first 6,000 miles and at alternate oil changes thereafter. To install, coat gasket with oil, screw filter onto adapter by hand until snug, then tighten an additional  $\frac{1}{2}$  turn.

**Normal Oil Pressure** - With engine at normal operating temperature, oil pressure should be 40-65 psi at 2,000 RPM.

**Pressure Regulator Valve** - In pump body. Not adjustable.

## 7.5L V8 ENGINE (Cont.)



**Fig. 20 Engine Oiling System**

### ENGINE OILING SYSTEM

Distributor driven oil pump provides full pressure lubrication to all camshaft and crankshaft bearings. Engine feeds oil through hydraulic valve lifters and hollow push rods to rocker arms and upper valve train area. Timing chain and sprockets are lubricated by drainage from No. 1 camshaft bearing. See Fig. 20.

### OIL PUMP

Oil pump is rotor type, mounted inside oil pan on lower left corner of block. Oil pump is driven by distributor through an intermediate shaft.

**Disassembly** – 1) With oil pump removed, remove cover screws and separate cover from pump body. Remove oil pump outer rotor and rotor shaft assembly from pump housing.

2) Remove cotter pin securing relief valve plug. To remove plug, drill a small hole in plug and insert a self-tapping screw. Use pliers to remove plug from housing as shown in Fig. 21. Remove spring and valve from housing.


**Reassembly** – 1) Clean, inspect and oil all parts thoroughly. Check all clearances (see specification chart). Install relief valve, spring and plug in housing.

2) Press plug in until it seats, then install cotter pin. Install outer rotor and rotor shaft into housing. Install cover and tighten cover bolts.


### Oil Pump Specifications

Application	Specification
Relief Valve Spring Tension .....	20.6-22.6 lbs. @ 2.49"
Relief Valve Clearance .....	.0015-.0030"
Drive Shaft-to-Housing Clearance .....	.0015-.0030"
Rotor End Play Clearance .....	.004" Max.
Outer Race-to-Housing Clearance .....	.001-.013"


**NOTE** – Identification marks should face same direction. Rotor and shaft assembly, and outer rotor are serviced as an assembly.



**Fig. 21 Removing Oil Pump Relief Valve Plug**



**Fig. 22 Checking Clearance for Outer Race-to-Housing**



**Fig. 23 Checking Rotor End Play**

# Ford V8 Engines

## 7.5L V8 ENGINE (Cont.)

### ENGINE SPECIFICATIONS

#### GENERAL SPECIFICATIONS

Year	Displ. Cu. Ins.	Carburetor	HP at RPM	Torque (Ft. Lbs. at RPM)	Compr. Ratio	Bore	Stroke
1981	460"	4-Bbl.	.....	.....	.....	4.36"	3.85"

#### VALVES

Engine & Valve	Head Diam.	Face Angle	Seat Angle	Seat Width	Stem Diameter	Stem Clearance	Valve Lift
7.5L Int.	2.075-2.090"	44°	45°	.060-.080"	.3416-.3423"	.0010-.0027"	.436"
7.5L Exh.	1.646-1.661"	44°	45°	.060-.080"	.3416-.3423"	.0010-.0027"	.481"

#### PISTONS, PINS, RINGS

Engine	PISTONS		PINS		RINGS		
	Clearance	Piston Fit	Rod Fit	Rings	End Gap	Side Clearance	
7.5L	.0022-.0030"	.0002-.0004"	Interference Fit	1 2 3	.010-.020" .010-.020" .010-.035"	.0019-.0036" .002-.004" Snug	

#### CRANKSHAFT MAIN & CONNECTING ROD BEARINGS

Engine	MAIN BEARINGS				CONNECTING ROD BEARINGS		
	Journal Diam.	Clearance	Thrust Bearing	Crankshaft End Play	Journal Diam.	Clearance	Side Play
7.5L	2.9994-3.0002"	①.0008-.0015"	No. 3	②.004-.008"	2.4992-2.5000"	③.0008-.0015"	.010-.020"

- ① — Allowable clearance is .0008-.0026".  
 ② — Service limit is .012".  
 ③ — Allowable clearance is .0008-.0025"

#### VALVE SPRINGS

Engine	Free Length	PRESSURE (LBS.)	
		Valve Closed	Valve Open
7.5L	2.06"	76-84 @ 1.81"	218-240 @ 1.33"

#### CAMSHAFT

Engine	Journal Diam.	① Clearance	Lobe Lift
7.5L Int.	2.1238-2.1248"	.001-.003"	.252"
7.5L Exh.	2.1238-2.1248"	.001-.003"	.278"

- ① — End play is .001-.006"

#### TIGHTENING SPECIFICATIONS

Application	Ft. Lbs.
Cylinder Head Bolts	
Step One .....	80
Step Two .....	110
Step Three .....	130-140
Main Bearing Cap Bolts .....	95-105
Connecting Rod Cap Bolts .....	40-45
Intake Manifold Bolts .....	22-32
Exhaust Manifold Bolts .....	28-33
Flywheel-to-Crankshaft Bolts .....	75-85
Engine Front Cover Bolts	
5/16" .....	12-18
7/16" .....	45-55
Camshaft Sprocket Bolts .....	40-45
Crankshaft Pulley Bolts .....	35-50
Oil Pan-to-Cylinder Block Bolts	
1/4" .....	7-9
5/16" .....	9-11
Rocker Arm Cover Bolts .....	5-6
Camshaft Thrust Plate .....	9-12
Damper-to-Crankshaft .....	70-90
Oil Filter Insert-to-Block .....	45-55
Oil Pump-to-Cylinder Block .....	22-32
Rocker Arm Bolt-to-Cylinder Head .....	18-25