

## 7.4 LITER V8

### IDENTIFICATION CODING

#### ENGINE IDENTIFICATION

Engine code letter is suffix of engine Identification Number. Number is stamped on pad at front top center of cylinder block, forward of intake manifold.

#### ENGINE IDENTIFICATION CODES

Application	Code
7.4L (454") 4-Bbl. ....	TKA,TKB,TKC,TKD,TKF,TKH

#### ENGINE REMOVAL

See Engine Removal at end of ENGINE Section.

### CYLINDER HEAD & MANIFOLD

#### INTAKE MANIFOLD

##### Removal

1) Drain cooling system. Remove air cleaner. Disconnect battery ground cable. Disconnect upper radiator hose and heater hose at manifold. Disconnect water pump by-pass at water pump. Disconnect PCV hose at valve cover.


2) Disconnect accelerator linkage and fuel inlet line at carburetor. Disconnect vacuum line at distributor. Remove distributor cap and mark rotor position. Remove distributor. Remove air cleaner bracket, accelerator return spring bracket and accelerator bellcrank.

3) If equipped with air conditioning, remove compressor and bracket without disconnecting lines and lay aside. Remove upper alternator mounting bracket. Remove intake manifold bolts and pry manifold loose. Remove manifold with carburetor attached and discard all gaskets.

##### Installation

To install intake manifold, clean all gasket surfaces and install gaskets on cylinder heads. Install new end seals on cylinder block. Install manifold and tighten bolts in sequence. Install distributor noting marked position of rotor. To complete installation, reverse removal procedure.

Fig. 1: Intake Manifold Tightening Sequence



Tighten bolts gradually to 30 ft. lbs. (41 N.m)

#### CYLINDER HEAD

##### Removal


1) Remove intake manifold as previously outlined. Remove alternator lower mounting bolt and lay alternator aside. Remove carburetor air heater from

exhaust manifold (if equipped). Remove spark plugs, disconnect exhaust pipes at manifolds and remove manifolds.

2) Disconnect PCV hose from valve cover. Remove valve covers. Loosen rocker arm nuts and pivot rocker arms to side. Remove push rods. Identify push rods to ensure that they are installed in original positions.

3) Drain cylinder block of coolant. Remove all cylinder head bolts. Pry cylinder head loose from cylinder block and remove cylinder head.

Fig. 2: Cylinder Head Tightening Sequence



Tighten bolts gradually to 80 ft. lbs. (108 N.m)

##### Installation

Reverse removal procedure to install cylinder heads. Ensure that gasket surfaces on head and cylinder block are clean and that cylinder head bolts threads and threads in block are clean. If cylinder head gasket is steel type, coat both sides with a sealer. Asbestos gasket requires no sealer. Coat cylinder head bolt threads with sealer. Tighten cylinder head bolts in sequence shown in illustration.

### VALVES

#### VALVE ARRANGEMENT

E-I-E-I-E-I-E-I (Left bank, front to rear).

I-E-I-E-I-E-I-E (Right bank, front to rear).

#### VALVE GUIDE SERVICING

If valve stem-to-guide clearance is excessive, guides are removable and can be replaced, or valves with oversize stems are available. Use a reamer (J-7049) to ream guides to correct size for oversize valve stems.

#### VALVE STEM OIL SEALS

An umbrella type oil seal is installed on valve stem before valve spring is installed. See Valve Springs.

#### VALVE SPRINGS

##### Removal

With cylinder head removed, compress valve spring and remove valve keepers. Release spring compressor and remove retainer, spring, damper, seal and valve rotators (if equipped on exhaust).

##### Installation

To install valve springs, reverse removal procedure. Lubricate and install valve stem oil seal on valve stem before installing remaining components.

#### VALVE SPRING INSTALLED HEIGHT

Valve spring installed height is measure from top of shim at bottom of spring, or spring seat to top of valve spring. If distance exceeds specified height, install a 1/16" (1.6 mm) thick shim. Installed height should never be more than 1/16" (1.6 mm) less than specified height.

# General Motors V8 Engines

## 7.4 LITER V8 (Cont.)

### VALVE SPRING INSTALLED HEIGHT

Application	Height
7.4L .....	1.797" (45.6 mm)


### ROCKER ARM STUDS

Push rod guides are attached to cylinder head by rocker arm studs. Replace as necessary and tighten studs. Coat threads on cylinder head end of new stud with sealer.

lifter must be replaced. Position check ball on small hole in bottom of plunger. Insert check ball spring on seat in ball retainer and position retainer on ball so that spring seats on ball. Using a screwdriver, press plunger into position.

2) Slide lifter body over spring and plunger, lining up oil feed holes. Fill assembly with SAE 10 oil and depress plunger to stop. With plunger depressed, insert a  $\frac{1}{16}$ " (1.6 mm) drift punch into feed holes. Release plunger and refill with SAE 10 oil. Install metering valve, push rod seat and retainer. Depress push rod seat and remove drift punch.

Fig. 3: Exploded View of Valve Spring Assembly



Some engines have a rotator on each exhaust valve.

### VALVE CLEARANCE ADJUSTMENT

1) Rotate engine until timing marks are aligned and No. 1 cylinder is in firing position. Back off rocker arm adjusting nuts on number one intake and exhaust rocker arms until play in push rod is detected. Now tighten rocker arm nut until play in push rod is just eliminated, then tighten adjusting nut one full turn more. With engine at number one firing position, adjust intake valves 1, 2, 5 and 7 and exhaust valves 1, 3, 4 and 8.

2) Rotate engine to number 6 firing position and follow same procedures for adjusting valves. With engine at number 6 firing position, adjust intake valves 3, 4, 6 and 8 and exhaust valves 2, 5, 6 and 7.

### PISTONS, PINS & RINGS

#### OIL PAN REMOVAL

See Oil Pan Removal at end of ENGINE Section.

#### PISTON & ROD ASSEMBLY

##### Removal

1) With oil pan, oil pump and cylinder heads removed, remove any ridge in top of cylinder bore with a ridge reamer. Check connecting rod and cap for identification marks or numbers and identify if necessary.

2) Remove connecting rod cap nuts and rod cap. Push piston and rod assembly up and out of cylinder block. It will be necessary to rotate crankshaft to various positions to facilitate removing piston and rod assemblies.

**NOTE:** When cleaning pistons, DO NOT wire brush any part of piston assembly.

### HYDRAULIC VALVE LIFTER ASSEMBLY

#### Disassembly

Depress plunger in lifter with a push rod and pry out retainer with a small blade screwdriver. Remove push rod seat and metering valve. Remove ball check valve and spring by prying ball retainer loose with a small blade screwdriver.

#### Reassembly

1) Thoroughly clean and inspect all components. If any components are worn or damaged, complete

Fig. 4: Cutaway of a Hydraulic Valve Lifter





Fig. 5: Piston Ring Gap Positioning



Stagger ring gaps to minimize compression loss.

## 7.4 LITER V8 (Cont.)

### Installation

1) Before installing piston and rod assembly, position ring gaps in positions shown in illustration. Place connecting rod in bore with bearing tang slots facing away from camshaft.

2) Lubricate rod bearings, cylinder bore and crankshaft journal. Compress piston rings and push piston and rod assembly into position. Install rod cap and tighten rod cap nuts to specifications.


### FITTING PISTONS

1) With piston and rod assemblies removed, wipe cylinder bores clean and measure diameter of cylinder with a dial indicator. If cylinder is worn or is tapered more than .005" (.127 mm), cylinder must be bored for oversize pistons.

2) If bore is worn or tapered less than .005" (.127 mm), cylinder can be cleaned and honed, and .001" (.0254 mm) oversize pistons may be installed. If cylinders are bored, various oversize pistons are available.

3) To check fit of rings in cylinder bore, insert ring in cylinder bore and push ring into bore 2" with head of piston and measure ring end gap with a feeler gauge. Before installing rings on pistons, ensure ring grooves are clean of carbon and inspect grooves for nicks or burrs. Install rings with gaps staggered.

Fig. 6: Piston Pin Installation & Removal



### PISTON PINS

#### Removal

With piston and rod assembly removed, press out piston pin using removal and installation tool J-24086 (or equivalent), and an arbor press. Separate piston from connecting rod.

#### Installation

Check clearance of pin in piston. If clearance exceeds .001" (.0254 mm) over specified clearance, piston

and pin must be replaced. Position piston on rod so that valve notch in top of piston faces to opposite side of bearing tang slots in connecting rod. Lubricate piston pin and press in using same tools as outlined in removal procedure. Check piston for freedom of movement on piston pin.

## CRANKSHAFT & ROD BEARINGS

### MAIN & CONNECTING ROD BEARINGS

**NOTE:** Following procedures are performed with oil pan and oil pump removed.

#### Connecting Rod Bearing

1) Mark or identify rod cap to rod before removing rod cap nuts. With rod nuts removed, remove rod cap and bearing. Push up on piston and rod assembly and remove bearing from rod. Inspect bearings for wear or damage and replace as necessary.

2) Check crankshaft rod bearing journal for out-of-round or taper conditions. If crankshaft is out-of-round or tapers more than .001" (.0254 mm), crankshaft must be removed and ground for undersize bearings.

3) Check crankshaft clearance using the Plastigage method. If clearance exceeds specifications, a .001" (.0254 mm) or .002" (.0508 mm) undersize bearing may be installed to obtain correct clearance. If clearance is still excessive, crankshaft must be removed and ground for undersize bearings. Connecting rod bearings are available .010" (.254 mm) and .020" (.508 mm) undersize.

4) To install bearings, clean crankshaft journal and bearing surface in rod. Insert bearing in rod and cap. Lubricate journal and pull piston and rod assembly down, aligning bearing on journal. Install rod cap noting identification marks and tighten rod nuts evenly and to specifications.

#### Main Bearings

1) Main bearings are selective fit by manufacturer during production. A standard size bearing may be used in combination with a .001" (.0254 mm) undersize bearing to obtain correct clearance. This combination will decrease clearance .0005" (.0127 mm).

2) If correct clearance could not be obtained during production, a crankshaft with .009" (.2286 mm) undersize main bearing journals is fitted. A .009" (.2286 mm) or .010" (.254 mm) bearing may be used to obtain correct clearance.

3) If engine is fitted with a crankshaft with .009" (.2286 mm) undersize main bearing journals, it will be identified by a "9" stamped in crankshaft counterweight along with large spot of light green paint. The bearing cap will also be painted.

4) Main bearings may be removed and replaced with crankshaft still installed in engine. Mark or identify main bearing caps to cylinder block before removing caps. Bearings are removed from cylinder block using a bearing removal tool. Install tool in oil hole in crankshaft and rotate crankshaft clockwise.

5) Crankshaft clearance, taper or out-of-round conditions can be checked using the Plastigage method. If clearance exceeds specifications, a .001" (.0254 mm) or .002" (.0508 mm) undersize bearing may be installed to obtain correct clearance. Both bearings must be replaced on any journal not within specifications.

# General Motors V8 Engines

## 7.4 LITER V8 (Cont.)


6) If correct clearance cannot be obtained or journal tapers or is out-of-round more than .001" (.0254), crankshaft must be removed and ground for undersize bearings. Bearings are available in standard, .001", .002", .009", .010" and .020" (.0254, .0508, .2286, .254, & .508 mm) undersize.

7) To install bearings, ensure crankshaft journal and bearing surface in cap and block are clean. Lubricate journal and install bearing cap. If bearings were removed with crankshaft still installed, use bearing removal and installation tool inserted in crankshaft oil hole to install upper bearing. Install main cap noting identification marks and tighten main bearing bolts evenly and to specifications.

### THRUST BEARING ALIGNMENT

Pry crankshaft forward as far as possible and check crankshaft end play with a feeler gauge inserted between front of rear main bearing and crankshaft. Replace rear main bearing if end play is not to specification.

**Fig. 7: Checking Crankshaft End Play**



Use a feeler gauge to check for maximum of .006-.010" (.152-.254 mm) end play.

### REAR MAIN BEARING OIL SEAL

#### Removal


Remove rear main bearing cap and pry out old seal. Remove upper half of seal by tapping end with brass punch until end of seal protrudes enough to be removed with pliers.

#### Installation

1) Fabricate an installation tool as shown in illustration. Coat seal lips and seal bead of upper seal with motor oil. Keep ends of seal dry of oil and position tool between crankshaft and seal seat in cylinder block. Position seal between tip of tool and crankshaft.

**NOTE:** Installation tool must remain in position until seal is positioned with both ends flush with block.

**Fig. 8: Rear Main Oil Seal**




Oil seal lip faces inside of engine.

2) Roll seal around crankshaft, using tool as a "shoehorn" to protect seal from sharp corner of seal seat surface. Make sure oil seal lip is positioned towards front of engine.

3) Remove tool, taking care not to remove seal. Install lower half of seal in bearing cap, using tool as a "shoehorn" again, feed seal into cap using light pressure with thumb and finger.

4) Install bearing cap with sealant applied to face, taking care to keep sealant off split line.

**Fig. 9: Rear Main Seal Installation Tool**



## CAMSHAFT

### ENGINE FRONT COVER

#### Removal

Remove fan belt, fan and pulley. Remove radiator shroud and water pump. Remove accessory drive pulley and harmonic balancer retaining bolt. Remove harmonic balancer with a puller. Remove cover retaining screws and pull cover forward slightly. Using a sharp knife, cut oil pan front seal flush with cylinder block. Remove cover and gasket.

#### Installation

1) Clean cover, oil pan and cylinder block gasket surfaces. Cut tabs off new oil pan front seal. Install seal in front cover, pressing seal tips in holes provided in cover. Apply a 1/8" bead of RTV sealer to joint formed at oil pan and cylinder block. Install new cover gasket and coat with sealer.

2) Position front cover over crankshaft, press downward against oil pan and push over dowel pins. Slightly tighten two bolts in oil pan, install and tighten remaining bolts. Tighten two oil pan bolts. Lubricate seal contact surface on harmonic balancer and pull into position using a puller. Install and tighten harmonic balancer bolt. Reverse removal procedure to install remaining components.

## 7.4 LITER V8 (Cont.)

### FRONT COVER OIL SEAL

#### With Cover Removed

Pry seal out of cover with a screwdriver. Install new seal with open end of seal toward inside of cover and drive into position. Support cover at seal area before driving in seal.

#### With Cover Installed

With harmonic balancer removed, pry seal out of front cover. Install seal with open end of seal toward engine and drive into place with a driver (J-22102) and a hammer.

### TIMING CHAIN & SPROCKETS

#### Removal

Remove front engine cover as previously outlined. Crank engine over until timing marks on camshaft and crankshaft sprockets are aligned. Remove bolts securing camshaft sprocket to camshaft and pull off sprocket with timing chain. A light blow with a plastic hammer will dislodge sprocket.

#### Installation

To install new crankshaft sprocket, pull into place with mounting bolts. Install camshaft sprocket and timing chain, making sure timing marks on sprockets are aligned. Install and tighten sprocket bolts. Install front cover.

### CAMSHAFT

#### Removal

Remove intake manifold, engine front cover and timing chain as previously outlined. Remove valve covers and loosen all rocker arms until push rods and valve lifters can be removed. Remove grille and radiator. Remove fuel pump and push rod. Screw two bolts into camshaft and withdraw camshaft.

#### Installation

Lubricate camshaft journals and lobes with motor oil. If a new camshaft is being installed, coat

camshaft lobes with Molykote. Position camshaft to align timing marks on sprockets. Install remaining components as previously outlined. Adjust hydraulic valve lifters.

### CAMSHAFT BEARINGS

Use camshaft bearing installation and removal tool (J-6098) to remove bearings. Install front and rear bearings first by driving toward center of cylinder block. Align oil holes in first 4 bearings with oil holes in bearing bore in block. Position rear camshaft bearing oil hole at or near the 6 o'clock position.

### CAM LOBE LIFT

With valve cover removed, remove rocker arm. Mount dial indicator on cylinder head. Position indicator stem on push rod with an adapter (J-8520). Rotate engine slowly until lifter is on heel of camshaft and set dial indicator to "0". Rotate engine slowly until push rod is at fully raised position. Dial indicator will give total camshaft lobe lift. Lift should be within specifications.

### ENGINE OILING

#### Crankcase Capacity

6 quarts (5.7 liters). Add 1 quart (.95 liter) with filter change.

#### Oil Pressure

40 psi at 2000 RPM.  
(2.81 kg/cm<sup>2</sup> at 2000 RPM.)

#### Oil Filter

Replace every other oil change or more often under dusty conditions.

#### Pressure Regulator Valve

In oil pump body, nonadjustable.

### ENGINE OILING SYSTEM

Full pressure lubrication through a full flow oil filter is supplied by a gear-type oil pump. Main oil gallery feeds oil through drilled passages to camshaft and crankshaft to lubricate bearings. Valve lifter gallery feeds the valve lifters, which feed the rocker arms through hollow push rods.

### OIL PUMP

#### Removal & Disassembly

Remove pump-to-rear main cap bolt and remove pump and extension shaft. Remove pump cover attaching screws and pump cover. Remove pressure regulator from pump cover. Mark gears so they may be reassembled with same tooth indexing. Remove idler gear, drive gear and shaft from pump body. Do not disassemble pickup screen and pipe. Screen and pipe are serviced as an assembly with the pump.


**NOTE:** If pump gears or body are damaged or worn, replacement of entire pump assembly is necessary.

#### Reassembly & Installation

Check all parts for fit and wear. Reverse removal and disassembly procedure to assemble and install. Check operation of pump before installation.

**NOTE:** Bottom of screen must be parallel with bottom of pan.

Fig. 10: Timing Chain Sprocket Alignment



# General Motors V8 Engines

## 7.4 LITER V8 (Cont.)

### ENGINE COOLING

#### WATER PUMP

##### Removal

1) Disconnect negative battery ground cable. Drain cooling system and remove accessory drive belts. Remove fan hub attaching bolts. Remove fan and pulley.

2) Remove bolts attaching lower alternator brace to water pump and swing brace out of way. Remove upper alternator brace from water pump. Remove lower radiator hose, heater hose and bypass hose from water pump. Remove water pump attaching bolts and water pump.

##### Installation

Transfer heater and bypass hose fittings to new water pump. Clean all gasket mating surfaces. Apply a 1/8" bead of silicone to gasket surfaces. Reverse removal procedure to complete installation.

**NOTE:** For further information on cooling system capacities and other cooling system components, see appropriate article in ENGINE COOLING SYSTEMS Section.

#### TIGHTENING SPECIFICATIONS

Application	Ft. Lbs. (N.m)
Cylinder Head Bolts .....	80 (108)
Intake Manifold Bolts .....	30 (41)
Exhaust Manifold Bolts .....	20 (27)
Main Bearing Cap Bolts .....	110 (149)
Flywheel Bolts .....	65 (88)
Connecting Rod Cap Nuts .....	50 (68)
Camshaft Sprocket Bolt .....	20 (27)
Rocker Arm Stud .....	50 (68)
Water Pump Bolts .....	30 (41)
Oil Pump Bolts .....	65 (88)
Harmonic Balancer Bolt .....	85 (115)

## ENGINE SPECIFICATIONS

### GENERAL SPECIFICATIONS

Year	Displ.		Carburetor	HP at RPM	Torque Ft. Lbs. @RPM	Compr. Ratio	Bore		Stroke	
	cu. ins.	liters					in.	mm	in.	mm
1982	454	7.4	4-Bbl.	.....	.....	8.5:1	4.250	107.95	4.000	101.6

### VALVES

Engine & Valve	Head Diam. In. (mm)	Face Angle	Seat Angle	Seat Width In. (mm)	Stem Diameter In. (mm)	Stem Clearance In. (mm)	Valve Lift In. (mm)
7.4L Int.	2.065 (52.45)	45°	46°	.031-.063 (.787-1.60)	<sup>1</sup> .3715-.3722 (9.44-9.45)	.0010-.0027 (.025-.069)	.398 (10.11)
Ext.	1.720 (43.69)	45°	46°	.063-.094 (1.60-2.39)	<sup>1</sup> .3713-.3720 (9.43-9.45)	.0012-.0029 (.030-.074)	.430 (10.92)

<sup>1</sup> — Standard size valve specifications only. Always check stem clearance to determine valve guide and stem wear.

### PISTONS, PINS, RINGS

Engine	PISTONS	PINS		RINGS		
	Clearance In. (mm)	Piston Fit In. (mm)	Rod Fit In. (mm)	Rings	End Gap In. (mm)	Side Clearance In. (mm)
7.4L	.003-.004 (.076-.102)	.0025-.0035 (.0064-.0089)	<sup>1</sup> .0013-.0021 (.033-.053)	1	.010-.020 (.254-.508)	.0017-.0032 (.043-.081)
				2	.010-.020 (.254-.508)	.0017-.0032 (.043-.081)
				3	.015-.055 (.381-1.397)	.005-.0065 (.127-.165)

<sup>1</sup> — Interference fit.

# General Motors V8 Engines

7-119

## 7.4 LITER V8 (Cont.)

### ENGINE SPECIFICATIONS (Cont.)

#### CRANKSHAFT MAIN & CONNECTING ROD BEARINGS

Engine	MAIN BEARINGS				CONNECTING ROD BEARINGS		
	Journal Diam. In. (mm)	Clearance In. (mm)	Thrust Bearing	Crankshaft End Play In. (mm)	Journal Diam. In. (mm)	Clearance In. (mm)	Side Play In. (mm)
7.4L	<sup>1</sup> 2.7481-2.7490 (69.80-69.82) <sup>2</sup> 2.7476-2.7486 (69.79-69.81)	<sup>1</sup> .0013-.0025 (.033-.064) <sup>2</sup> .0024-.0040 (.061-.102)	No. 5	.006-.010 (.152-.254)	2.1990-2.200 (55.85-55.88)	.0009-.0025 (.023-.064)	.013-.023 (.330-.584)

<sup>1</sup> — Journal No. 1, 2, 3 & 4.

<sup>2</sup> — Journal No. 5.

#### CAMSHAFT

Engine	Journal In. (mm)	Clearance In. (mm)	Lobe Lift In. (mm)
7.4L Int.	1.9482-1.9492 (49.48-49.50)	.....	2343 (5.95)
Exh.	1.9482-1.9492 (49.48-49.50)	.....	.2530 (6.43)

#### VALVE SPRINGS

Engine	Free. Length In. (mm)	PRESSURE Lbs. @ In. (kg @ mm)	
		Valve Closed	Valve Open
7.4L	2.12 (53.85)	84-96@1.80 (38-44@45.72)	210-230@1.40 (95-104@35.56)