

## TUNE-UP

XJ6L

### ENGINE IDENTIFICATION

Engine number is stamped on top of cylinder block at rear of engine. Number is also stamped on Commission Plate, which is located in the engine compartment. Suffix following engine number indicates compression ratio, "L" — Low.

### COMPRESSION PRESSURE

Check compression pressure with engine at normal operating temperature, throttle valve wide open, all spark plugs removed and coil wire disconnected. Compression pressure is normal if all cylinders are within 5 psi (.35 kg/cm<sup>2</sup>) of each other.

### VALVE CLEARANCE

1) With camshaft covers removed, rotate camshafts and record clearance between heel of each cam lobe and its respective tappet. If adjustment is necessary, rotate camshaft and install valve timing gauge (C.3993) before removing final camshaft retaining nut. If required, disconnect sprockets from camshafts.

**NOTE** — DO NOT rotate engine while camshaft sprockets are disconnected.

2) Remove camshaft bearing caps and lift off camshaft. Remove each tappet that requires adjustment and note its location for reassembly in its original position. Remove adjusting pad and measure thickness.

3) Use measured pad thickness and difference between measured valve clearance and specified clearance to calculate required thickness of new adjusting pad. Adjusting pads are available in increments of .001" (.03 mm) from .085" (2.16 mm) to .110" (2.79 mm) and are marked with letters from "A" to "Z" respectively.




Fig. 1 Position of Valve Timing Gauge

4) Insert correct adjusting pads and install tappets. Attach camshafts (using timing gauge). Torque camshaft bearing cap nuts to 9 ft. lbs. (1.2 mkg), connect camshaft sprockets, and install camshaft covers.

### Valve Clearance Specifications

Application	Clearance In. (mm)
All Models (Intake & Exhaust)	.012-.014 (.30-35)

### VALVE ARRANGEMENT

Left Side — All Exhaust  
Right Side — All Intake

### SPARK PLUGS

Application	Gap In. (mm)	Torque Ft. Lbs. (N·m)
All Models	.035 (.9)	27 (36)

### Spark Plug Type

Application	Champion No.
All Models	N12Y

### HIGH TENSION WIRE RESISTANCE

Carefully remove high tension wires from spark plugs and distributor cap. Using an ohmmeter, check resistance of each wire while gently twisting wire. If resistance is not to specifications, or fluctuates from infinity to any value, replace wire.

#### Resistance (Ohms) Per Wire

Application	Resistance
All Models	25,000-30,000

### DISTRIBUTOR

All models are equipped with a breakerless, electronic ignition system.

Air Gap ..... ① .006-.008" (.15-.20)

① — Measured between timing rotor and pick-up module.

### IGNITION TIMING

Check or adjust ignition timing with engine at normal operating temperature, idle speed set to specification and distributor vacuum line connected. If timing is not correct, loosen distributor clamp bolt and rotate distributor to achieve specified timing. Then tighten clamp bolt.

#### Ignition Timing Specifications (Degrees BTDC@RPM)

Application	Timing
All Models	4@800

## TUNE-UP (Cont.)




Fig. 2 Ignition Timing Mark Location




Fig. 3 Firing Order and Distributor Rotation

### IDLE SPEED & MIXTURE

**NOTE** — Mixture adjustment is NOT a part of normal tune-up procedure and should not be performed unless fuel injection parts are replaced or vehicle fails emissions testing.

- 1) Connect a tachometer and CO% meter to engine (at exhaust manifold test points). Run engine until normal operating temperature is reached.
- 2) Adjust idle with air volume screw at overrun valve housing. Use 7/32" Allen wrench and turn clockwise to lower idle; counterclockwise to raise engine idle.
- 3) Remove plug on airflow meter to locate mixture adjustment screw. Disconnect oxygen sensor and allow engine to idle for 1 minute to stabilize mixture.
- 4) Turn mixture screw clockwise to richen mixture and counterclockwise to lean mixture. If correct setting cannot be attained, check all electrical connections and all hoses for proper location.
- 5) Replace oxygen sensor lead and disconnect test instruments.

### Idle Speed & CO Level

Application	Idle RPM	CO %
All Models .....	750-850 .....	.5-1.5

### FUEL PUMP PRESSURE

Pressure .....	36 psi (2.5 kg/cm <sup>2</sup> )
----------------	----------------------------------

### EXHAUST EMISSION SYSTEMS

See EXHAUST EMISSION SYSTEMS section.

## GENERAL SERVICING

### IGNITION

#### DISTRIBUTOR

All models are equipped with Lucas Opus Electronic Ignition System.

### FUEL SYSTEMS

#### FUEL INJECTION

All models are equipped with Lucas-Bosch fuel injection.

### ELECTRICAL

#### BATTERY

Application	Amp. Hr. Rating
All Models .....	75

**Battery Location** — Battery is located in right rear corner of engine compartment.

#### STARTER

All models are equipped with Lucas pre-engaged Starters.

Free Speed Amperage

All Models .....	100 at 5000-6000 RPM
------------------	----------------------

## GENERAL SERVICING (Cont.)

### ALTERNATOR

Application	Rated Amp. Output
All Models .....	60

### ALTERNATOR REGULATOR

Lucas — Non-Adjustable; Integral with Alternator.

### FILTERS

Filter	Service Intervals (Miles)
Oil Filter .....	Replace every 6000
Air Filter .....	Replace every 12,000
Engine Breather Filter .....	Replace every 12,000
Fuel Filter .....	Replace every 12,000

### BELT ADJUSTMENT

Belt	① Deflection
Fan/Steering Pump .....	Self-Adjusting
Alternator .....	.15" (3.8 mm)
A/C Compressor .....	.17" (4.3 mm)

① — Deflection is with pressure applied midway on longest belt run.

### CAPACITIES

Application	Quantity
Crankcase (Includes Filter) .....	8.7 qts.
Cooling System .....	19.5 qts.
Auto. Trans. (ATF Type F) .....	7.5 qts.
Rear Axle (SAE 90 EP) .....	3.3 pts.
Fuel Tank	
Right Side .....	11.8 gals.
Left Side .....	11.8 gals.