

HONDA (Cont.)

Accord — Fuse block is located under the dashboard on drivers side. Block contains 10 fuses. One row of 8 and a row of 2. Numbers 9 & 10 are the 2 fuses in a separate row, along with 2 spares and 1 spare main fuse. Circuits protected are as follows, from top to bottom:

- ① — 10 Amp. Windshield Wiper/Washer.
- ② — 10 Amp. Voltage Regulator, Fuel Pump.
- ③ — 10 Amp. Turn Signals, Back-Up Lights, Fuel Gauge.
- ④ — 15 Amp. Headlight High Beam.
- ⑤ — 15 Amp. Headlight Low Beam.
- ⑥ — 15 Amp. Taillights, Instrument Lights

- ⑦ — 10 Amp. Cig. Lighter, Clock Interior Lights.
- ⑧ — 15 Amp. Hazard Warning Lights, Horn, Stop Lights.
- ⑨ — 15 Amp. Heater.
- ⑩ — 15 Amp. Radio, Rear Window Defroster.

IN-LINE FUSES

One large 55 Amp. in-line fuse is installed in main battery cable to prevent damage to main wiring harness. Fuse is located in engine compartment near battery.

JAGUAR**FUSE BLOCK**

XJ6 Models — Fuse block is located behind instrument panel. Access to fuses is obtained by turning access panel retaining pin counterclockwise until it unlocks. Panel will then drop slightly and bottom edge may be lifted clear of opening. Circuits protected are as follows:

- ① — 20 Amp. Fog Lights
- ② — 15 Amp. Hazard Warning System
- ③ — 35 Amp. Map & Interior Lights, Cigar Lighter, Clock, Trunk Light
- ④ — 15 Amp. Back Up Lights, Gauges
- ⑤ — 15 Amp. Turn Signals
- ⑥ — 35 Amp. Stop Lights, Battery Cooling, Horn Relay, Windshield Washer
- ⑦ — 15 Amp. Instrument Lights
- ⑧ — 15 Amp. Left Side Marker and Tail Lights
- ⑨ — 15 Amp. Right Side Marker and Tail Lights
- ⑩ — 50 Amp. A/C and Heater Relay
- ⑪ — 20 Amp. Windshield Wipers
- ⑫ — 15 Amp. Air Conditioning

XJS Models — Fuse block is located under dashboard on right side. Circuits protected are as follows:

- ① — 25 Amp. Fog Lights

- ② — 15 Amp. Hazard Warning
- ③ — 35 Amp. Map & Interior Lights, Cigar Lighter, Electric Aerial, Clock, Seat Belt Warning Light.
- ④ — 10 Amp. Instrument Lights
- ⑤ — 15 Amp. Turn Signals
- ⑥ — 10 Amp. Back Up Lights
- ⑦ — 10 Amp. Panel Switches, License Light, Trunk Light, Gear Selector Light, Cigar Lighter Light, Fibre Optic Unit
- ⑧ — 10 Amp. Left Side Marker & Tail Lights
- ⑨ — 10 Amp. Right Side Marker & Tail Lights
- ⑩ — 50 Amp. Air Conditioning Motor
- ⑪ — 35 Amp. Windshield Wipers & Washer, Horn Relay, Cooling Fan relay, A/C Relay & Clutch
- ⑫ — 35 Amp. Heated Back Light

XJ12 — Fuse Information not available at time of publication.

IN-LINE FUSES

Head Lights — High beam is protected by a 25 Amp. in-line fuse and low beam is governed by a 10 amp in-line fuse.

Horn Relay — Circuit is protected by a 35 Amp. in-line fuse.

LANCIA**FUSE BLOCK**

Fuse block is fitted to the engine compartment and is provided with a pressure tight cover. Block contains 11 fuses. Circuits protected are, from right to left:

- ① — 8 Amp. Right Front Side Light, Right License Light, Rear Left Side Light
- ② — 8 Amp. Engine Compartment Light, Trunk Light, Cigar Lighter, Front Left & Rear Right Side Lights, Instrument Light, Left License Light
- ③ — 8 Amp. Right Low Beam Headlight
- ④ — 8 Amp. Left Low Beam Headlight
- ⑤ — 8 Amp. Right High Beam Headlight
- ⑥ — 8 Amp. Left High Beam Headlight, High Beam Indicator
- ⑦ — 8 Amp. Stop Lights, Windshield Washer Motor, Radio

- ⑧ — 16 Amp. No. 14 Solenoid Switch, Heating & Ventilation Booster, Windshield Wipers
- ⑨ — 16 Amp. No. 12 Solenoid Switch, Turn Signals, Coil, Handbrake Warning Light, Instrument & Warning Lights, Cooling Fan Switch
- ⑩ — 8 Amp. Courtesy Light, Door Lights, Clock, Glove Box Light
- ⑪ — 25 Amp. Horn, Cigar Lighter, Clock, Heated Rear Window

IN-LINE FUSES

In-line fuses protect engine cooling fan (16 Amp), air conditioning booster fan (16 Amp), and an air conditioning compressor solenoid switch (25 Amp). Auxiliary fuse box is located near the left inner wheel well.