

PORSCHE (Cont.)

911 Models — Connecting terminals and wires of all instruments are accessible from luggage compartment side of instrument panel after luggage compartment carpet is removed.

1) Disconnect and detach all cables and wire from instrument that is to be removed. In case of speedometer, also remove drive shaft knurled nut and withdraw shaft from speedometer.

2) Remove small knurled nuts securing instrument, remove retaining clamp and take instrument out from passenger compartment side.

TURN SIGNAL FLASHER (911 MODELS)

Flasher is located adjacent to fuse block in luggage compartment, and is a plug in type.

STOP LIGHT SWITCH

To adjust switch, loosen jam nut and adjusting screw. Clamp a piece of sheet metal .16" (4 mm) thick between brake pedal lever and pedal stop at brake pedal center. Turn adjusting screw until brake lights operate. Remove switch and lock adjusting screw. Reinstall switch and check switch operation.

RENAULT

CAUTION — Disconnect battery ground cable prior to removal of instrument cluster.

INSTRUMENT CLUSTER

Le Car — Disconnect speedometer cable in engine compartment. Unclip instrument panel cowl and remove. Press left and right side clips until support plate is cleared and remove instrument panel. Disconnect 2 electrical junction blocks and speedometer cable.

SPEEDOMETER & GAUGES

Speedometer and all gauges may be removed after instrument cluster is removed.

STOP LIGHT SWITCH

Mechanically operated switch attached to the steering column

SAAB

CAUTION — Disconnect battery ground cable prior to removal of instrument cluster.

INSTRUMENT CLUSTER

99 Models — Remove safety padding. Remove four self tapping screws. Disconnect speedometer cable and wiring. Remove bulb holders. Lift out instrument cluster.

900 Models — Remove steering wheel. Remove 4 switch panel screws and properly mark location for reinstallation. Tilt switch panel back out of way. Remove left speaker and defroster grill. Reach behind instrument cluster and disconnect electrical connections and speedometer cable. Remove cluster retaining screws and remove cluster assembly.

SPEEDOMETER & GAUGES

Speedometer and all gauges may be removed after first removing instrument cluster.

TURN SIGNAL FLASHER

Located under instrument panel on left hand side of steering column.

STOP LIGHT SWITCH

Mechanical type mounted on brake pedal bracket.

SUBARU

CAUTION — Disconnect battery ground cable prior to removal of instrument cluster.

INSTRUMENT CLUSTER

Remove instrument cluster cover screws and remove cover with rear window defogger switch. Remove cluster retaining screws and tip cluster out. Disconnect speedometer cable and wiring harness, then remove cluster.

SPEEDOMETER & GAUGES

Speedometer and all gauges may be removed after first removing instrument cluster.

HAZARD WARNING & TURN SIGNAL FLASHER

Located under instrument panel.

STOP LIGHT SWITCH

Mechanical type mounted on brake pedal bracket. Adjust switch so there is .24-.55" (6-14 mm) free pedal movement before switch turns on brake lights.