

VOLKSWAGEN (Cont.)

- ③ - 8 Amp. Left Low Beam.
- ④ - 8 Amp. Right Low Beam.
- ⑤ - 8 Amp. Left High Beam, High Beam Indicator.
- ⑥ - 8 Amp. Right High Beam.
- ⑦ - 8 Amp. Accessories.
- ⑧ - 8 Amp. Emergency Flasher, Interior Lights.
- ⑨ - 16 Amp. Accessories.
- ⑩ - 16 Amp. Windshield Wipers, Rear Window Defogger
- ⑪ - 8 Amp. Horn, Stop Lights, Brake Warning Light.
- ⑫ - 8 Amp. Turn Signals Warning Lights, Back-Up Lights.

Rabbit & Scirocco - Fuse block is located under instrument panel on left side of vehicle and contains 15 fuses in one centralized unit. Two additional in-line fuses are used as follows: An 8 Amp. fuse located above fuse block, protects Rear Window Wiper. A 16 Amp. fuse located above fuse block, protects Electric Fuel Pump. Circuits protected by fuses in block are:

- ① - 8 Amp. Left Headlight Low Beam.
- ② - 8 Amp. Right Headlight Low Beam.
- ③ - 8 Amp. Left Headlight High Beam and Indicator.
- ④ - 8 Amp. Right Headlight High Beam.
- ⑤ - 16 Amp. Rear Window Defogger.
- ⑥ - 8 Amp. Stop Lights, Hazard Warning Flasher.
- ⑦ - 8 Amp. Interior Lights, Cigar Lighter.
- ⑧ - 8 Amp. Turn Signal System.
- ⑨ - 8 Amp. Back Up Lights, Shift Console Light, Horn

- ⑩ - 16 Amp. Fresh Air Fan.
- ⑪ - 8 Amp. Windshield Wiper & Washer
- ⑫ - 8 Amp. Luggage Compartment & License Plate Lights.
- ⑬ - 8 Amp. Right Parking, Tail & Side Marker Lights.
- ⑭ - 8 Amp. Left Parking, Tail & Side Marker Lights
- ⑮ - 25 Amp. Radiator Fan

Dasher - Fuse block is located on the left side behind the dashboard bin and contains 15 fuses. One additional fuse is located above fuse No. 7. A 16 Amp. fuse protects the Fuel Pump Relay. An additional fuse above the relay panel protects the rear wiper on wagon models (8 Amp.). Circuits protected by fuses in the block are, from left to right:

- ① - 8 Amp. Left Low Beam.
- ② - 8 Amp. Right Low Beam.
- ③ - 8 Amp. Left High Beam & Warning Light.
- ④ - 8 Amp. Right High Beam.
- ⑤ - 16 Amp. Rear Window Defogger.
- ⑥ - 8 Amp. Stop Lights, Hazard Warning Flasher.
- ⑦ - 8 Amp. Cigar Lighter, Clock, Radio, Interior Light.
- ⑧ - 8 Amp. Turn Signals
- ⑨ - 8 Amp. Horn, Backup Lights, Shift Console Light
- ⑩ - 16 Amp. Fresh Air Fan
- ⑪ - 8 Amp. Windshield Wipers, Washers, Rear Washer
- ⑫ - 8 Amp. License Plate Light.
- ⑬ - 8 Amp. Right Tail, Parking & Side Marker Lights.
- ⑭ - 8 Amp. Left Tail, Parking & Side Marker Lights.
- ⑮ - 25 Amp. Radiator Fan

VOLVO

FUSE BLOCK

240 and 260 Series - Fuse block is located in left kick panel behind cover. Fuses are numbered from top to bottom and space is provided for spare fuses at bottom of block. Circuits protected are:

- ① - 8 Amp. Lighter, Rear Wiper, Mirrors, Antenna
- ② - 16 Amp. Horn, Wipers, Washers
- ③ - 16 Amp. Heater Fan
- ④ - 8 Amp. Warning Buzzers
- ⑤ - 8 Amp. Fuel Pump (Feed Pump)
- ⑥ - 8 Amp. Brake Lights, Courtesy Light Relay
- ⑦ - 16 Amp. Main Fuel Pump
- ⑧ - 8 Amp. Courtesy Lights
- ⑨ - 8 Amp. Hazard Flashers
- ⑩ - 16 Amp. Power Windows
- ⑪ - 16 Amp. Overdrive, Defogger
- ⑫ - 8 Amp. Backup Lights, Power Window Relay, Heated Driver's Seat, A/C
- ⑬ - 8 Amp. Gauges, Turn Signals, Belt Warning, Fuel Injection Relay
- ⑭ - Spare
- ⑮ - 8 Amp. Left Parking and Marker Lights, License Light
- ⑯ - 8 Amp. Right Parking and Marker Lights, Headlight Buzzer, Instrument Panel Lights