


Fuses & Circuit Breakers

CHRYSLER CORP.

Dodge
Plymouth


FUSE PANEL

"B" & "PB" Models - Located under bottom edge of instrument panel to right of steering column.




"B" & "PB" MODELS FUSE PANEL

"M" Models - Location of fuse panel can vary according to manufacturer of body.



"M" MODELS FUSE PANEL

"D", "W", "AD", "AW", "PD", "PW" Models - Located behind glove box door.



"D", "W", "AD", "AW", "PD", "PW" MODELS FUSE PANEL

CIRCUIT BREAKERS

"M" Models - Circuit breaker is integral with headlight switch.

All Other Models - Circuit breaker is integral with headlight switch. Additional circuit breaker is incorporated into windshield wiper switch.

FUSIBLE LINKS

All Models - Fusible link is placed in wiring harness of main charging circuit.