





- Ⓜ - Radio Antenna Switch (Down).
- Ⓛ - Radio Antenna Motor (Up).
- Ⓚ - Radio Dial Light.

Ⓛ - Instr. Panel R. Dir. Ind. (when used).

Ⓜ - Instr. Panel L. Dir. Ind. (when used).