

1972 Distributor Specifications

FORD MOTOR CO. CENTRIFUGAL ADVANCE SPECIFICATIONS

NOTE - FOR ENGINE RPM AND DEGREES, MULTIPLY SPECIFICATIONS BELOW BY 2.

Distributor Part No. (Exc. Calif.)	Distributor Part No. (Calif. Only)	Rot. Ⓢ	Automatic Advance (Distr. Degrees & RPM)				
			Degs. @ 500 RPM	Degs. @ 750 RPM	Degs. @ 1000 RPM	Degs. @ 1500 RPM	Degs. @ 2000 RPM
72HF-DC 72HF-FA	72HF-DC 72HF-SC 72IF-TA	C C C C	1/2-2 1/2 1/2-2 1/2 0-1/2 0-1/2	5 1/2-7 1/2 5 1/2-7 1/2 0-1 1 1/2-3 1/2	6 1/2-8 1/2 6 1/2-8 1/2 3-5 5 1/2-7 1/2	9 1/2-11 1/2 9 1/2-11 1/2 8 1/2-10 7 1/2-9 1/2	12-14 11 1/2-14 13 1/2-15 1/2 10-12
72IF-YA D2AF-BA D2AF-CA D2AF-KA		C C CC CC	0-1/2 0-1 0-1 1-3	1 1/2-3 1/2 1 1/2-4 0-1 1/2 5 1/2-7 1/2	5 1/2-7 1/2 3-5 4 1/2-6 1/2 6 1/2-8 1/2	7 1/2-9 1/2 4 1/2-7 7-9 1/2 8 1/2-10 1/2	10-12 6-8 1/2 8 1/2-11 10 1/2-12 1/2
D2AF-NA D2AF-PA D2AF-RA	D2AF-MA	CC CC CC CC	0-1 0-1 0-1 1/2-2 1/2	1 1/2-3 1/2 1 1/2-3 1/2 1 1/2-4 2-4	7-9 7-9 6 1/2-8 1/2 3 1/2-5 1/2	10 1/2-12 1/2 10 1/2-12 1/2 8 1/2-11 6 1/2-9	11 1/2-14 11 1/2-14 11-13 1/2 9 1/2-12
D2DF-AA D2DF-CA	D2AF-SA D2DF-BA	CC C C C	1/2-2 1/2 0-2 0-2 0-1	2-4 4 1/2-6 1/2 4 1/2-6 1/2 3-5	3 1/2-5 1/2 7-9 7-9 7 1/2-9 1/2	6 1/2-9 9-11 1/2 9-11 1/2 9 1/2-12	9 1/2-12 11-13 1/2 11-13 1/2 10 1/2-12 1/2
D2DF-DA	D2DF-EA D2DF-FA	C C C CC	1/2-2 1/2 0-1 0-1 0-1	5-7 3-5 0-1 2-4	9-11 7 1/2-9 1/2 4 1/2-7 4 1/2-6 1/2	10 1/2-12 1/2 9 1/2-12 10 1/2-12 1/2 6-8	11-13 1/2 10 1/2-12 1/2 11-13 1/2 7-9 1/2
D2MF-EA	D2MF-FA	CC CC	0-1 0-1/2	2-4 0-1/2	4 1/2-6 1/2 2 1/2-4 1/2	6-8 8-10 1/2	7-9 1/2 11 1/2-13 1/2
D20F-AA D20F-DA	D20F-FA	C C	0-1 1/2 0-1	5-7 1 1/2-3 1/2	5 1/2-7 1/2 4-6	7-9 7-9	8-10 1/2 8-10 1/2
D20F-HA	D20F-JA	CC CC CC	0-1 0-1 0-1/2	0-2 0-2 0-1 1/2	5-7 2 1/2-4 1/2 7 1/2-9 1/2	7 1/2-9 1/2 7 1/2-9 1/2 8-10 1/2	8 1/2-11 8 1/2-11 11 1/2-13 1/2
D20F-LA D20F-PA		C	0-2 1/2	6-8		10-12 1/2	12 1/2-15
D2VF-AA D2VF-BA D2ZF-AA	D20F-RA D2VF-BA	CC CC CC CC	0-1 0-1 0-1 0-1 1/2	0-1 1/2 1 1/2-3 1/2 1-3 2 1/4-4 1/4	4 1/2-6 1/2 5 1/2-7 1/2 6 1/2-8 1/2 4 1/2-6 1/2	7 1/2-9 1/2 7-9 7 1/2-10 8-10	8 1/2-11 8-10 1/2 9-11 1/2 10-12 1/2
D2ZF-EA D2ZF-GC D2ZF-JA D2SF-EA	D2ZF-CA D2ZF-FA D2ZF-HA	CC CC CC CC CC	0-1 0-1/2 0-1/2 0-1 0-1 0-1	3 1/2-5 1/2 0-1 1/4 0-1 1/4 0-1 1 1/2-3 1/2 0-1 1/2 0-1 1/2	6 1/2-8 1/2 0-1 3/4 0-1 3/4 0-2 4 1/2-6 1/2 2 1/2-4 1/2 2 1/2-4 1/2	8 1/2-10 1/2 5 1/2-8 1/4 5 1/2-8 1/4 4 1/2-6 1/2 10-12 7 1/2-9 1/2 4 1/2-6 1/2	10 1/2-12 1/2 10 1/2-13 10 1/2-13 8 1/2-11 12-14 1/2 11 1/2-13 6-8 1/2

Ⓢ - C (Clockwise), CC (Counterclockwise) viewed from rotor end. Ⓢ - Part No. stamped on housing.

1972 Distributor Specifications

FORD MOTOR CO. VACUUM ADVANCE & RETARD SPECIFICATIONS

NOTE - FOR ENGINE RPM AND DEGREES, MULTIPLY SPECIFICATIONS BELOW BY 2.

Distributor Part No. (Exc. Calif.)	Distributor Part No. (Calif. Only)	Rot. Ⓢ	Vacuum Advance (Distr. Degrees) Operate Distributor @ 1000 RPM			Vacuum Retard (Distr. Degrees) Operate Distributor @ 1000 RPM		
			In. Hg. 5	In. Hg. 15	In. Hg. 20	In. Hg. 5	In. Hg. 15	In. Hg. 20
72HF-DC 72HF-FA	72HF-DC 72HF-SC 72IF-TA	C C C C	0-2 0 0-2 1/2 0-2 1/2	5 1/2-7 1/2 5 1/2-7 1/2 5 1/2-7 1/2 5-8	5 1/2-7 1/2 5 1/2-7 1/2 5 1/2-7 1/2 5-8	0 0 0 0	1/2-4 1/2-4 1/2-4 0-1 1/2	2-4 2-4 2-4 3 1/2-7
72IF-YA D2AF-BA D2AF-CA D2AF-KA	72IF-YA D2AF-BA D2AF-CA D2AF-KA	C C CC CC	0-2 1/2 0-1 0-1 1/2 0-1	5-8 6 1/2-9 1/2 2 1/2-5 1/2 6 1/2-9 1/2	5-8 6 1/2-9 1/2 2 1/2-5 1/2 6 1/2-9 1/2	0 0-3 1/2 0-2 1/2 0-3	0-1 1/2 4 1/2-7 3 1/2-7 4-7	5-7 5-7 5-7 5-7
D2AF-NA D2AF-PA D2AF-RA	D2AF-MA	CC CC CC CC	0-1 0-1 0-1 1/2 0-1 1/2	5-8 5-8 6 1/2-9 1/2 7 1/2-10 1/2	5-8 5-8 6 1/2-9 1/2 7 1/2-10 1/2	0-2 0-2 0-2 0-2	2-4 2-4 3 1/2-7 2-4	2-4 2-4 5-7 2-4
D2DF-AA D2DF-CA	D2AF-SA D2DF-BA	CC C C C	0-1 1/2 0-1 0-1 0-1	3-6 1/2 1-4 1/2 1-4 1/2 1-4 1/2	3-6 1/2 4 1/2-7 1/2 4 1/2-7 1/2 4 1/2-7 1/2	0-2 0-4 0-4 0-4	2-4 5-7 5-7 5-7	2-4 5-7 5-7 5-7
D2DF-DA D2MF-EA	D2DF-EA D2DF-FA	C C C CC	0-1 0-1 0-2 1/2 0-1	4 1/2-7 1/2 1-4 1/2 4 1/2-7 1/2 1 1/2-4 1/2	4 1/2-7 1/2 4 1/2-7 1/2 4 1/2-7 1/2 5 1/2-9	0-2 0-4 0-4 0-2 1/2	2-4 5-7 2-4 2-4	2-4 5-7 2-4 2-4
D2OF-AA D2OF-DA	D2MF-FA	CC CC C C	0-1 0-2 1/2 0-3 0-3	1 1/2-4 1/2 6 1/2-9 1/2 6 1/2-9 1/2 6 1/2-9 1/2	8 1/2-11 1/2 10 1/2-12 1/2 6 1/2-9 1/2 6 1/2-9 1/2	0-2 1/2 0-5 0-6 0-4	2-4 5-7 5-7 2-4	2-4 5-7 5-7 2-4
D2OF-HA D2OF-LA D2OF-PA	D2OF-EA	CC CC CC C	0-1 1/2 0-1 1/2 0-2 1/2 0-1	2 1/2-5 1/2 2 1/2-5 1/2 6 1/2-9 1/2 4-7 1/2	2 1/2-5 1/2 2 1/2-5 1/2 10 1/2-12 1/2 6 1/2-9 1/2	0-2 1/2 0-2 1/2 0-4 0-2 1/2	3 1/2-7 3 1/2-7 2-4 4-7	5-7 5-7 2-4 5-7
D2VF-AA D2VF-BA D2ZF-AA	D2OF-RA D2VF-BA	CC CC CC CC	0-1 1/2 0-1 0-1 0-1 1/2	2 1/2-5 1/2 1-4 2 1/2-5 1/2 5 1/4-8 1/2	2 1/2-5 1/2 8 1/2-11 1/2 9-12 10-12	0-2 1/2 0-1 0-1 0-1	3 1/2-7 2-6 2-6 2-6	5-7 5-7 5-7 5-7
D2ZF-EA D2ZF-GC D2ZF-JA D2SF-EA	D2ZF-CA D2ZF-FA D2ZF-HA	CC CC CC CC CC	0-1 0-3 0-3 0-2 1/2 0-2 1/2 0-3 0-1	0-2 2 1/2-5 1/2 2 1/2-5 1/2 6 1/2-9 1/2 6 1/2-9 1/2 6-9 1-4	7-10 2 1/2-5 1/2 2 1/2-5 1/2 6 1/2-9 1/2 6 1/2-9 1/2 8 1/2-11 1/2	0-1 1/2 0-4 1/2 0-4 1/2 0-5	2-4 5-7 5-7 5-7	2-4 5-7 5-7 5-7

Ⓢ - C (Clockwise), CC (Counterclockwise) viewed from rotor end. Ⓢ - Part No. stamped on housing.